TECHVISION USA



MOBILE APPS FREE MOBILE APPS FOR ANDRIOD AND IOS



FREE TECH SUPPORT

FAST SERVICE SUPPORT





Foreword

General

This manual introduces the functions, configuration, general operation, and system maintenance of network camera.

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
	Indicates a potential risk which, if not avoided, may result in property damage, data loss, lower performance, or unpredictable result.
© <u>_</u> TIPS	Provides methods to help you solve a problem or save you time.
	Provides additional information as the emphasis and supplement to the text.

Revision History

Version	Revision Content	Release Date
V2.0.5	 Updated "4.5.1.1.8 Illuminator". Updated "4.7.3.2 Local". Added "5.19.6 Setting Disarming". 	June 2020
V2.0.4	 Updated "4.5.1.4 Splicing". Updated "5.14 Setting Vehicle Density". Updated "5.12 Setting People Counting". 	May 2020
V2.0.3	Added note in "4.7.3.2 Local".	May 2020
V2.0.2	 Modified the contents of "5.16 Setting ANPR". Added modeling in "5.11 Setting Face Detection". 	December 2019
V2.0.1	Added "5.5 Setting Smart Motion Detection".	August 2019

Version	Revision Content	Release Date
V2.0.0	 Consolidated the outline, and added baseline and safety contents, and some intelligent functions such as face recognition and ANPR. Deleted some old function such as stereo vision. 	July 2019
V1.0.4	 Updated the chapters of "5.12 Setting People Counting" and "5.13.1 Heat Map". Add VR mode of Fisheye device. Add video metadata function. 	March 2019
V1.0.3	Added Stereo Analysis function.	November 2018
V1.0.2	 Added chapters of "3 Device Initialization". and "Stereo vision." Updated the chapters of "4.8.4 Account", and "4.6.7 SNMP". 	October 2017
V1.0.1	First release.	September 2016

About the Manual

- The manual is for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related jurisdictions. For detailed information, refer to the paper manual, CD-ROM, QR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurring when using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

Electrical Safety

- All installation and operation shall conform to your local electrical safety codes.
- The power source shall conform to the Safety Extra Low Voltage (SELV) standard, and supply power with rated voltage which conforms to Limited power Source requirement according to IEC60950-1. Note that the power supply requirement is subject to the device label.
- Make sure that the power supply is correct before operating the device.
- A readily accessible disconnecting device shall be incorporated in the building installation wiring.
- Prevent the power cable from being trampled or pressed, especially the plug, power socket and the junction extruded from the device.

Environment

- Do not aim the device at strong light to focus, such as lamp light and sun light; otherwise it might cause over brightness or light marks, which are not the device malfunction, and affect the longevity of Complementary Metal-Oxide Semiconductor (CMOS).
- Do not place the device in a damp, dusty extremely hot or cold environment, or the locations with strong electromagnetic radiation or unstable lighting.
- Keep the device away from any liquid to avoid damage to the internal components.
- Keep the indoor device away from rain or damp to avoid fire or lightning.
- Keep sound ventilation to avoid heat accumulation.
- Transport, use and store the device within the range of allowed humidity and temperature.
- Heavy stress, violent vibration or water splash are not allowed during transportation, storage and installation.
- Pack the device with standard factory packaging or the equivalent material when transporting the device.
- Install the device in the location where only the professional staff with relevant knowledge of safety guards and warnings can access. The accidental injury might happen to the non-professionals who enter the installation area when the device is operating normally.

Operation and Daily Maintenance

- Do not touch the heat dissipation component of the device to avoid scald.
- Carefully follow the instructions in the manual when performing any disassembly operation about the device; otherwise, it might cause water leakage or poor image quality due to unprofessional disassembly. Please contact after-sale service for desiccant replacement if there is condensed fog on the lens after unpacking or when the desiccant turns green. (Not all models are included with the desiccant).
- It is recommended to use the device together with lightning arrester to improve lightning protection effect.
- It is recommended to ground the device to enhance reliability.
- Do not touch the image sensor (CMOS) directly. Dust and dirt could be removed with air blower, or you can wipe the lens gently with soft cloth that is moistened with alcohol.
- You can clean the device body with soft dry cloth, and for stubborn stains, use the cloth with

mild detergent. To avoid possible damage on device body coating which could cause performance decrease, do not use volatile solvent such as alcohol, benzene, diluent and so on to clean the device body, nor can strong, abrasive detergent be used.

• Dome cover is an optical component. Do not touch or wipe the cover with your hands directly during installation or operation. For removing dust, grease or fingerprints, wipe gently with moistened oil-free cotton with diethyl or moisten soft cloth. You can also remove dust with an air blower.

- Strengthen the protection of network, device data and personal information by adopting
 measures which include but not limited to using strong password, modifying password
 regularly, upgrading firmware to the latest version, and isolating computer network. For
 some device with old firmware versions, the ONVIF password will not be modified
 automatically along with the modification of the system password, and you need to upgrade
 the firmware or manually update the ONVIF password.
- Use standard components or accessories provided by manufacturer and make sure that the device is installed and maintained by professional engineers.
- The surface of the image sensor should not be exposed to laser beam radiation in an environment where a laser beam device is used.
- Do not provide two or more power supply sources for the device unless otherwise specified. A failure to follow this instruction might cause damage to the device.

Table of Contents

Foreword
Important Safeguards and Warnings III
1 Overview
1.1 Introduction1
1.2 Network Connection 1
1.3 Function
1.3.1 Basic Function1
1.3.2 Intelligent Function
2 Configuration Flow
3 Device Initialization
4 Basic Configuration
4.1 Login
4.2 Live
4.2.1 Live Interface
4.2.2 Encode bar
4.2.3 Live View Function Bar
4.2.4 Window Adjustment Bar14
4.2.4.1 Adjustment
4.2.4.2 Zoom and Focus
4.2.4.3 Fisheye
4.3 PTZ Operation
4.3.1 Configuring External PTZ Protocol
4.3.2 Configuring PTZ Function
4.3.2.1 Preset
4.3.2.2 Tour
4.3.2.3 Scan
4.3.2.4 Pattern
4.3.2.5 Pan
4.3.2.6 PTZ Speed
4.3.2.7 Idle Motion
4.3.2.8 PowerUp
4.3.2.9 PTZ Limit
4.3.2.10 Time Task
4.3.2.11 PTZ Restart
4.3.2.12 Default
4.3.3 Calling PTZ
4.3.3.1 PTZ Control

4.3.3.2 PTZ Function	
4.4 Playback	
4.4.1 Playback Interface	
4.4.2 Playing back Video or Picture	
4.4.3 Clipping Video	
4.4.4 Downloading Video or Picture	
4.4.4.1 Downloading A Single File	
4.4.4.2 Downloading Files in Batches	
4.5 Camera	
4.5.1 Conditions	
4.5.1.1 Conditions	
4.5.1.1.1 Interface Layout	
4.5.1.1.2 Picture	
4.5.1.1.3 Exposure	
4.5.1.1.4 Backlight	
4.5.1.1.5 WB	
4.5.1.1.6 Day & Night	
4.5.1.1.7 Zoom and Focus	50
4.5.1.1.8 Illuminator	51
4.5.1.1.9 Defog	53
4.5.1.1.10 Fisheye	53
4.5.1.1.11 Image Correction	54
4.5.1.1.12 Splicing Mode	55
4.5.1.2 Profile Management	55
4.5.1.3 Zoom and Focus	57
4.5.1.4 Splicing	57
4.5.2 Setting Video Parameters	57
4.5.2.1 Video	
4.5.2.2 Snapshot	60
4.5.2.3 Overlay	61
4.5.2.3.1 Configuring Privacy Masking	61
4.5.2.3.2 Configuring Channel Title	
4.5.2.3.3 Configuring Time Title	63
4.5.2.3.4 Configure Text Overlay	
4.5.2.3.5 Configure Font Attribute	
4.5.2.3.6 Configure Picture Overlay	65
4.5.2.3.7 Configure Custom Overlay	
4.5.2.3.8 Configuring OSD Info	
4.5.2.3.9 Configuring Counting	

4.5.2.3.10 Configuring Structured Statistics	68
4.5.2.3.11 Configuring Ranging	68
4.5.2.3.12 Configuring ANPR	69
4.5.2.3.13 Configuring Face Statistics	70
4.5.2.4 ROI	70
4.5.2.5 Path	71
4.5.3 Audio	72
4.5.3.1 Configuring Audio Parameter	72
4.5.3.2 Configuring Alarm Audio	73
4.6 Network	74
4.6.1 TCP/IP	74
4.6.2 Port	77
4.6.3 PPPoE	78
4.6.4 DDNS	79
4.6.5 SMTP (Email)	80
4.6.6 UPnP	83
4.6.7 SNMP	84
4.6.8 Bonjour	87
4.6.9 Multicast	87
4.6.10 802.1x	88
4.6.11 QoS	88
4.6.12 Access Platform	89
4.6.12.1 P2P	89
4.6.12.2 ONVIF	90
4.6.12.3 RTMP	90
4.7 Storage	91
4.7.1 Setting Storage Plan	
4.7.2 Setting Schedule	
4.7.3 Setting Destination	
4.7.3.1 Path	
4.7.3.2 Local	
4.7.3.3 FTP	
4.7.3.4 NAS	
4.8 System	
4.8.1 General	
4.8.2 Date & Time	
4.8.3 Splicing	
4.8.4 Account	
4.8.4.1 Adding a User	

4.8.4.2 Adding User Group	
4.8.4.3 ONVIF User	103
4.8.5 Safety	105
4.8.5.1 System Service	105
4.8.5.2 HTTPS	106
4.8.5.3 Firewall	110
4.8.6 Peripheral	
4.8.6.1 Serial Port Settings	
4.8.6.2 External Light	113
4.8.6.3 Wiper	114
5 Event	116
5.1 Setting Alarm Linkage	116
5.1.1 Alarm Linkage	116
5.1.1.1 Setting Period	116
5.1.1.2 Record Linkage	117
5.1.1.2.1 Setting Record Plan	117
5.1.1.2.2 Setting Record Control	118
5.1.1.2.3 Setting Record Linkage	119
5.1.1.3 Snapshot Linkage	120
5.1.1.3.1 Setting Snapshot Plan	120
5.1.1.3.2 Setting Snapshot Linkage	121
5.1.1.4 Relay-out Linkage	121
5.1.1.5 Email Linkage	121
5.1.1.6 PTZ Linkage	
5.1.1.7 White Light Linkage	
5.1.1.8 Audio Linkage	
5.1.2 Subscribing Alarm	
5.1.2.1 About Alarm Types	
5.1.2.2 Subscribing Alarm Information	123
5.2 Setting Smart Track	
5.2.1 Setting Calibration Parameters for Smart Track	
5.2.2 Enabling Alarm Track	125
5.3 Setting Panoramic Calibration	126
5.4 Setting Video Detection	128
5.4.1 Setting Motion Detection	128
5.4.2 Setting Video Tamper	130
5.4.3 Setting Scene Changing	131
5.5 Setting Smart Motion Detection	132
5.6 Setting Audio Detection	

5.7 Setting Smart Plan	135
5.8 Setting IVS	136
5.8.1 Global Configuration	136
5.8.2 Rule Configuration	138
5.9 Setting Crowd Map	142
5.9.1 Global Configuration	142
5.9.2 Rule Configuration	143
5.10 Setting Face Recognition	146
5.10.1 Setting Face Detection	146
5.10.2 Setting Face Database	148
5.10.2.1 Creating Face Database	148
5.10.2.2 Adding Face Picture	150
5.10.2.2.1 Single Adding	150
5.10.2.2.2 Batch Importing	152
5.10.2.3 Managing Face Picture	154
5.10.2.3.1 Modifying Face Information	154
5.10.2.3.2 Deleting Face Picture	155
5.10.2.4 Face Modeling	155
5.10.3 Setting Face Recognition Alarm Linkage	157
5.10.4 Viewing Face Recognition Result	157
5.10.4.1 Viewing Result in the Live Interface	157
5.10.4.2 Viewing Result by Search Function	158
5.11 Setting Face Detection	159
5.12 Setting People Counting	162
5.12.1 People Counting	162
5.12.2 Calibration Configuration	166
5.12.3 Queuing	167
5.12.4 Viewing People Counting Diagram	169
5.12.5 Viewing People Counting Report	171
5.13 Setting Heat Map	172
5.13.1 Heat Map	172
5.13.2 Viewing Heat Map Report	173
5.14 Setting Vehicle Density	174
5.15 Setting Stereo Analysis	177
5.15.1 Setting Rules for Stereo Analysis	177
5.15.2 Calibration Configuration	180
5.16 Setting ANPR	
5.16.1 Scene Configuration	
5.16.2 Setting Picture Overlay	183

	Operation Manual
5.16.3 Viewing ANPR Report	
5.17 Setting Video Metadata	
5.17.1 Scene Configuration	
5.17.2 Setting Picture Information	
5.17.3 Viewing Video Metadata Report	
5.18 Setting Relay-in	
5.19 Setting Abnormality	
5.19.1 Setting SD Card	
5.19.2 Setting Network	
5.19.3 Setting Illegal Access	
5.19.4 Setting Voltage Detection	
5.19.5 Setting Security Exception	
5.19.6 Setting Disarming	
6 Maintenance	
6.1 Requirements	
6.2 Auto Maintain	
6.3 Resetting Password	
6.4 Backup and Default	
6.4.1 Import/Export	
6.4.2 Default	
6.5 Upgrade	
6.6 Information	
6.6.1 Version	
6.6.2 Log	
6.6.3 Remote Log	
6.6.4 Online User	
Appendix 1 Cybersecurity Recommendations	

1 Overview

1.1 Introduction

IP camera (Internet Protocol camera), is a type of digital video camera that receives control data and sends image data through internet. They are commonly used for surveillance, requiring no local recording device, but only a local area network. IP camera is divided into single-channel camera and multi-channel camera according to the channel quantity. For multi-channel camera, you can set the parameters for each channel.

1.2 Network Connection

In the general IPC network topology, IPC is connected to PC through network switch or router.




Figure 1-1 General IPC network

Get IP address by searching on ConfigTool, and then you can start accessing IPC through network.

1.3 Function

Functions might vary with different devices, and the actual product shall prevail.

1.3.1 Basic Function

Real-time Monitoring

- Live view.
- When live viewing the image, you can enable audio, voice talk and connect monitoring center for quick processing on the abnormality.
- Adjust the image to the proper position by PTZ.
- Snapshot and triple snapshot abnormality of the monitoring image for subsequent view and processing.

- Record abnormality of monitoring image for subsequent view and processing.
- Configure coding parameters, and adjust live view image.

Record

- Auto record as schedule.
- Play back recorded video and picture as needed..
- Download recorded video and picture.
- Alarm linked recording.

Account

- Add, modify and delete user group, and manage user authorities according to user group.
- Add, modify and delete user, and configure user authorities.
- Modify user password.

1.3.2 Intelligent Function

Alarm

- Set alarm prompt mode and tone according to alarm type.
- View alarm prompt message.

Smart Track

- Set calibration and parameters for smart track and enable alarm track.
- Switch between smart track and speed dome auto track.

Video Detection

- Motion detection, video tampering detection and scene changing detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

Smart Motion Detection

- Avoid the alarms triggered by the environment changes.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

Audio Detection

- Audio input abnormal detection and intensity change detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

IVS

- Supports traffic congestion detection and parking upper limit detection.
- View the vehicle statistic data on the Live interface.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, and snapshot.

Crowd Map

- View crowd distribution in real time for the timely arm to avoid accidents like stampede.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

Face Detection

- Detect face and display the related attributes on the live interface.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

Face Recognition

- After detecting face, make comparison between the detected face with the face in face database, and activates alarm output.
- Query the recognition result.

People Counting

- Count the people flow in/out the detection area, and generate report.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

Heat Map

- Count cumulative density of moving objects.
- View report of heat map.

Vehicle Density

- Supports traffic congestion detection and parking upper limit detection.
- View the statistic data on the Live interface.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, and snapshot.

Stereo Analysis

- Include fall detection, violence detection, people No. error, people approaching detection, and stay detection.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

ANPR

- Recognize plate number in detection area, and display the related information on live interface.
- When an alarm is triggered, the system links alarm output and snapshot.

Video Metadata

- Snap people, non-motor vehicle and vehicle, and display the related information on the live interface.
- When an alarm is triggered, the system links alarm output.

Alarm Setting

- The alarm is triggered when an external alarm input device inputs alarm.
- When an alarm is triggered, the system performs linkages such as recording, alarm output, sending email, PTZ operation, and snapshot.

Abnormality

- SD card error, network disconnection, illegal access, voltage detection and security exception.
- When SD card error or illegal access is triggered, the system links alarm output and sending email.
- When network disconnection alarm is triggered, the system links recording and alarm output.
- When the input voltage is more or less than the rated voltage, the alarm is triggered and the system links sending email.

2 Configuration Flow

For the device configuration flow, see Figure 2-1. For details, see Table 2-1. Configure the device according to the actual situation.




Figure 2-1 Configuration flow

Table 2-1	Description	of flow

Configuration		Description	Reference
Login		ogin Open IE browser and enter IP address to log in to the web interface, The camera IP address is 192.168.1.108 by default.	
Initialization		Initialize the camera when you use it for the first time.	"3 Device Initialization"
	IP address	Modify IP address according to network planning for the first use or during network adjustment.	"4.6.1 TCP/IP"
Basic parameters	Date & time	Set date and time to ensure the recording time is correct.	"4.8.2 Date & Time"
	lmage parameters	Adjust image parameters according to the actual situation to ensure the image quality.	"4.5.1 Conditions"
	Detection rules	Configure the necessary detection rules, such as video detection and IVS.	"5 Event"
Intelligent Event	Subscribe alarm	Subscribe alarm event. When the subscribed alarm is triggered, the system will record the alarm on the alarm tab.	"5.1.2 Subscribing Alarm"

3 Device Initialization

Device initialization is required for the first use. This manual is based on the operation on the web interface. You can also initialize device through ConfigTool, NVR, or platform devices.

 \square

- To ensure the device safety, keep the password properly after initialization and change the password regularly.
- When initializing device, keep the PC IP and device IP in the same network.
- <u>Step 1</u> Open IE browser, enter the IP address of the device in the address bar, and then press Enter key.

 \square

The IP is 192.168.1.108 by default.


Figure 3-1 Device initialization

evice Initialization		
Username	admin	
Password		The minimum pass phrase length is 8 characters
Confirm Password	Weak Middle Strong	
	Use a password that has 8 to 32 characters number(s) and symbol(s) with at least two k special symbols like ** ; : &)	
Email Address	To reset password, please input properly or	update in time.
	Save	

<u>Step 2</u> Set the password for admin account.

Parameter	Description
Username	The default username is admin.
Password	The password must consist of 8 to 32 non-blank characters and
Confirm password	contain at least two types of characters among upper case, lower case, number, and special character (excluding ' "; : &). Set a high security level password according to the password security notice.
	Enter an email address for password reset, and it is selected by default.
email	When you need to reset the password of the admin account, a security code for password resetting will be sent to the reserved email address.

Step 3 Click Save.



1. NOTICE		
IMPORTANT	NOTICE. PLEASE READ CAREFULLY:	
('Agreement'	") sets forth the terms and conditions under which You are licensed to use the Software. By installing, copying,	
downloading	g the Software or using the same by any other means, you are deemed to have accepted this Agreement. If you do not	
agree with it	in whole or in part, you do not have the right to use this Software, in which case you should immediately stop installing,	
copying the s	Software or using the same by any other means.	
2. DEFINITIO	DNS	
'Software' m	eans information management program(s) or supporting document(s) consisting of several modules or functions.	
Supporting of	document(s) includes all or part of the source codes and object codes of the Software, as well as the images,	
photographs	s, icons, animations, audio, video, music, words and codes incorporated therein; it also includes all relevant paper or	
electronic int	formation and technical documentation which describe the functions, characteristics, contents, quality, tests, customer	
manuals us	ser acreements, etc. ('Software Product' or 'Software')	
I have rea	ad and agree to all terms	

<u>Step 4</u> Select the I have read and agree to all terms check box, and then click Next.

	Figure 3-3 Easy4ip
Easy4ip	
🔽 Easy4i	ip
Regist	ter device to EASY4IP and then suitable for user to apply for cloud account. It can realize cloud service such as remote
surveil	llance, device record, alarm, cloud storage, using device to manage cloud.
	Please scane the QR code on the actual interface.
	Scall and Dowilload EASTHE AFF
	Next
	Scan and Download EASY4IP APP

<u>Step 5</u> You can register the camera to Easy4ip, select the check box as needed, and then click **Next**.

Figure 3-4 Online upgrade

nlin	e Upgrade
	Auto-check for updates
	Notify automatically when updates available. The system checks for updates every day.
	Online Upgrade is a service that provides you with firmware updates by cloud. This service will collect device information in order to
	inform you about available firmware updates. Such information may include your device name, firmware version and device
	identification numbers. Such information is processed for the sole purpose of informing you about firmware updates.
	Save

<u>Step 6</u> Select the upgrading method as needed.

If you select **Auto-check for updates**, the system checks new version once a day automatically. There will be system notice on **Upgrade** interface and **Version** interface if any new version is available.

 \square

Select **Setting** > **System** > **Upgrade** > **Online Upgrade**, and you can enable the auto-check function.

Step 7 Click Save.

Device initialization is completed.

4 Basic Configuration

The chapter introduces the basic configuration, including login, live view, PTZ operation, playback operation, camera configuration, network configuration, storage configuration and system configuration.

4.1 Login

This section introduces how to log in to and log out of the web interface. This section takes IE Explorer 9 as an example.

 \square

- You need to initialize the camera before logging in to the web interface. For details, see "3 Device Initialization".
- When initializing the camera, keep the PC IP and device IP in the same network.
- Follow the instruction to download and install the plug-in for the first login.
- <u>Step 1</u> Open IE browser, enter the IP address of the camera (192.168.1.108 by default) in the address bar and press Enter.

	5	3		
_	_	-	-	
	Username:			
	Password:			Forgot password?
	[Login	Cancel]

Figure 4-1 Login

<u>Step 2</u> Enter the username and password. The username is admin by default

<u> _ ...</u>

Click **Forget password?**, and you can reset the password through the email address that is set during the initialization. For details, see "6.3 Resetting Password".

Step 3 Click Login.

- Live: Click Live, and you can view the real-time monitoring image.
- Playback: Click **Playback**, and you can play back or download recorded video or image files.
- Setting: Click **Setting**, and you can configure the basic and intelligent functions of the camera.
- For the camera with multiple channels, through selecting channel numbers, you can set the parameters of the channels.
- Alarm: Click **Alarm**, and you can subscribe and view alarm information.

- Logout: Click Logout to go to login interface.
- The system will sleep automatically after idling for a period of time.




Figure 4-2 Live

4.2 Live

This section introduces the layout of the interface and function configuration.

4.2.1 Live Interface

This section introduces system menu, encode bar, live view function bar, and window adjustment bar.

Log in and click the Live tab.

\square

The functions and interfaces of different models might vary, and the actual product shall prevail.





Table 4-1 Description of function bar

No.	Function	Description
1	Encode bar	Sets stream type and protocol.
2	Live view	Displays the real-time monitoring image.
3	Live view function bar	Functions and operations in live viewing.
4	Window adjustment bar	Adjustment operations in live viewing.

4.2.2 Encode bar

For encode bar, see Figure 4-4.





- **Main Stream**: It has large bit stream value and image with high resolution, but also requires large bandwidth. This option can be used for storage and monitoring. For details, see "4.5.2.1 Video".
- **Sub Stream**: It has small bit stream value and smooth image, and requires less bandwidth. This option is normally used to replace main stream when bandwidth is not enough. For details, see "4.5.2.1 Video".
- **Protocol**: You can select the network transmission protocol as needed, and the options are **TCP**, **UDP** and **Multicast**.

 \square

Before selecting Multicast, make sure that you have set the Multicast parameters.

4.2.3 Live View Function Bar

For the live view function bar, see Table 4-2.

Icon	ble 4-2 Description of li	Description	
		Manually position the tracking speed dome to the selected location of corresponding panoramic camera. Click the icon and click or select randomly on	
T	Manual Position	 the image of panoramic camera channel, the tracking speed dome will automatically position the selected location. For multi-sensor panoramic network camera + PTZ camera, before enabling manual position, make sure that you have enabled alarm track and smart track calibration. For details, see "5.2 Setting Smart Track". For panoramic network camera, before enabling manual position, make sure that you have enabled panoramic linkage. For details, see "5.3 Setting Panoramic Calibration". 	
Œ	Regional Focus	Select channel image of the tracking speed dome, click the icon and click or select randomly on the channel image of the tracking speed dome, and then the speed dome can realize auto focus upon the selected region.	
O	Wiper	Controls the wiper of the camera. Click the icon to enable or disable wiper function.	
	Ranging	Click the icon, select a point on the ground, and the distance between the camera and the selected point will be displayed. Before using this function, you need to set the installation of device first. For details, see "4.5.2.3.11 Configuring Ranging".	
-	Gesture	Controls PTZ by operating the mouse on the live view of tracking speed dome. Select the live view of tracking speed dome, click the icon, press left-button and drag image to control PTZ. And you can zoom the image through rolling mouse wheel.	
\bigcirc	Manual Track	Click the icon, and select tracking target on the live view of tracking speed dome, the camera tracks the selected target automatically.	

Table 4-2 Description of live view function bar

lcon	Function	Description
	Vehicle Density	Click the icon, and select an area on the live image, the camera will automatically count the number of the vehicles in the selected area, and display the number on the Live interface.
	Relay-out	 Displays alarm output state. Click the icon to force to enable or disable alarm output. Alarm output state description: Red: Alarm output enabled. Grey: Alarm output disabled.
ø	White Light	Display the white light state. Click the icon to enable or disable the white light forcibly.
.	Alarm	Display alarm sound state. Click the icon to enable or disable the alarm sound forcibly.
	Crowd Map	 Click the icon to display the crowd map on the Live interface. Only after enabling the function, can you see the icon on the Live interface. The positions of the icon might vary depending on models.
•	Digital Zoom	 You can zoom video image through two operations. Click the icon, and then select an area in the video image to zoom in; right-click on the image to resume the original size. In zoom in state, drag the image to check other area. Click the icon, and then scroll the mouse wheel in the video image to zoom in or out.
	Snapshot	Click the icon to capture one picture of the current image, and it will be saved to the configured storage path.
	Triple Snapshot	Click the icon to capture three pictures of the current image, and they will be saved to the configured storage path.

Operation Manual

lcon	Function	Description	
6	Record	Click the icon to record video, and it will be saved to the configured storage path. About viewing or configuring storage path, see "4.5.2.5 Path".	
[+]	Easy Focus	 see "4.5.2.5 Path". Click the icon, the AF Peak (focus eigenvalue) and AF Max (max focus eigenvalue) are displayed on the video image definition, it displays during focus. AF Peak: The eigenvalue of image definition. AF Max: The best eigenvalue of image definition. The smaller the difference between AF peak value and the AF max value, the better the focus is. Easy focus closes automatically after five minutes. 	
	Audio	Click the icon to enable or disable audio output.	
Ų	Talk	Click the icon to enable or disable the audio take.	

4.2.4 Window Adjustment Bar

4.2.4.1 Adjustment

This section introduces the adjustment of image. For details, see Table 4-3.

Icon	e 4-3 Description of adjus	Description
	Image Adjustment	 Click the icon, and then the Image Adjustment interface is displayed at the right side of the Live interface. You can adjust brightness, contrast, hue, and saturation. The adjustment is only available on the web interface, and it does not adjust the camera parameters. Mile (Brightness adjustment): Adjusts the overall image brightness, and changes the value when the image is too bright or too dark. The bright and dark areas will have equal changes. Mile (Contrast adjustment): Changes the value when the image brightness is proper but contrast is not enough Mile adjustment): Makes the color deeper or lighter. The default value is made by the light sensor, and it is recommended. Mile adjusts the image saturation, this value does not change image brightness.
100%	Original Size	Click the icon, , and it changes to, and then the video displays with original size; click, and the video displays with adapted size.
X	Full Screen	Click the icon to enter full screen mode; double-click or press Esc to exit.
W:H	W:H	Click the icon to resume original ratio or change ratio.

Table 4-3 Description of adjustment bar

lcon	Function	Description
	Fluency	 Click the icon to select the fluency from Realtime, Fluency and Normal. Realtime: Guarantees the real time of the image. When the bandwidth is not enough, the image might not be smooth. Fluency: Guarantees the fluency of the image. There might be delay between live view image and real-time image. Normal: It is between Realtime and Fluency.
⊕ ₀	Rule Info	Click the icon, and then select Enable to display smart rules and detection box; select Disable to stop the display. It is enabled by default.
PTZ	PTZ	Click the icon, and the PTZ control panel is displayed at the right side of the Live interface. You can control and call PTZ function. For details, see"4.3.3 Calling PTZ".
Ŧ	Zoom and Focus	Adjust focal length to zoom in and out video image. Click the icon, and the Zoom and Focus configuration interface is displayed at the right side of the Live interface. You can control and call PTZ function. For details, see "4.2.4.2 Zoom and Focus".
0	Fisheye	Click the icon, and then the fisheye configuration interface is displayed at the right side of the Live interface. For details, see "4.2.4.3 Fisheye".
	Face	 Click the icon, and the face detection or face recognition results are displayed on the Live interface. For face recognition, see "5.10.1 Setting Face Detection". For face detection: see "5.11 Setting Face Detection".
	ANPR	Click the icon, and the ANPR results are displayed on the Live interface. For details, see "5.16 Setting ANPR".
٢	Video Metadata	Click the icon, the video metadata results are displayed on the Live interface. For details, see "5.17 Setting Video Metadata".

lcon	Function	Description
	Window Layout	When view multi-channel image, you can select display layout.
1	Crowd Map	Click the icon and select the Enable check box. The Crowd Map interface is displayed. For details, see"5.9 Setting Crowd Map".

4.2.4.2 Zoom and Focus

You can adjust focal length to zoom in or out video image; by adjusting focus manually, automatically or within a certain area, you can change image clarity or correct adjusting errors.



The focus would adjust automatically after zooming in or out.




Figure 4-5 Zoom and focus

Table 4-4 Description of zoom and focus

Parameter	Description	
Zoom	 Changes the focal length of the camera to zoom in or out the image. 1. Set the Speed value. The Speed is the adjustment range in one click. The larger the value is, the more the image would zoom in or out in one click. 2. Click or hold + or - button, or drag the slider to adjust zoom. 	
Focus	 Adjusts the optical back focal length to make the image clearer. 1. Set the Speed value. The Speed is the adjustment range in one click. The larger the value is, the more the adjustment in one click. 2. Click or hold + or – button, or drag the slider to adjust focus. 	

Parameter	Description		
Auto Focus	Adjusts image clarity automatically.		
Restore All	Restores focus to default value and corrects errors. You can restore the focus if the image has poor clarity or has been zoomed too frequently.		
Regional Focus	Focus on the subject of a selected area. Click Regional Focus , and then select an area in the image, the camera performs auto focus in that area.		
Refresh	Get the latest zoom setting of the device.		

4.2.4.3 Fisheye

You can select the installation mode, display mode and VR mode of fisheye devices as needed. For details, see Table 4-5.

- Install Mode: Select the installation mode according to the actual situation.
- **Display Model**: Select the display mode of live view.
- VR Mode: Select VR mode to display images in stereo mode.



Table 4-5 Description of fisheye configuration

Parameter	Description		
Installation mode	Includes ceiling mount, wall mount, and ground mount.		
Display mode	 The display model of the current image. There are different display modes for each installation mode. Ceiling: 1P+1, 2P, 1+2, 1+3, 1+4, 1P+6, 1+8. Wall: 1P, 1P+3, 1P+4, 1P+8. Ground: 1P+1, 2P, 1+3, 1+4, 1P+6, 1+8. The image will be on original size by default when switching installation mode. 		
Ceiling/Wall/Gro und mount	Original image The original image before correction.		

Parameter	Description		
	↓ 1P+1	 360° rectangular panoramic image screen + independent sub-screens. You can zoom or drag the image in all the screens. You can move the start point (left and right) on rectangular panoramic image screen. 	
	t → 2P	 Two associated 180° rectangular image screens, and at any time, the two screens form a 360° panoramic image. It is also called dual-panoramic image. You can move the start point (left and right) on the two rectangular panoramic image screens, and the two screens link each other. 	
	Q Q 1+2	 Original image screen + two independent sub-screens. Ground Mount does not support this display mode. You can zoom or drag the image in all the screens. You can rotate the image on the original image screen to change the start point. 	
Ceiling/Ground mount	Q 1+3	 Original image screen + three independent sub-screens. You can zoom or drag the image in all the screens. You can rotate the image on the original image screen to change the start point. 	
	Q Q 1+4	 Original image screen + four independent sub-screens. You can zoom or drag the image in all the screens. You can rotate the image on the original image screen to change the start point. 	
	1P+6	 360° rectangular panoramic screen + six independent sub-screens. You can zoom or drag the image in all the screens. You can move the start point (left and right) on rectangular panoramic image screen. 	
	Q 1P+8	 Original image screen + eight independent sub-screens. You can zoom or drag the image in all the screens. You can rotate the image on the original image screen to change the start point. 	

Parameter	Description			
	1P	180° rectangular panoramic image screen (from left to right). You can drag the image in all the screens (up and down) to adjust the vertical view.		
	1P+3	 180° rectangular panoramic image screen + three independent sub-screens. You can zoom or drag the image in all the screens. You can drag the image in all the screens (upper and lower) to adjust the vertical view. 		
Wall mount	1P+4	 180° rectangular panoramic image screen + four independent sub-screens. You can zoom or drag the image in all the screens. You can drag the image in all the screens (upper and lower) to adjust the vertical view. 		
	1P+8	 180° rectangular panoramic image screen + eight independent sub-screens. You can zoom or drag the image in all the screens. You can drag the image in all the screens (upper and lower) to adjust the vertical view. 		
	Panorama	Drag or cross the screen 360° to unfold the distortion panorama, and you can drag the image in left/right direction.		
VR mode	Semi-circle	 You can drag the image in upper/lower/left/right direction. Press I to display the panorama, and press O to resume the original size. Press S to rotate the image in anticlockwise direction, and press E to stop the rotation. Scroll the mouse wheel to zoom the image. 		

Parameter	Description			
	Cylinder	 Display the distortion panorama in 360°circularity. You can drag the image in upper/lower/left/right direction. Press I to display the panorama, and press O to return to the original size. Press S to rotate the image in anticlockwise direction, and press E to stop the rotation. Scroll the mouse wheel to zoom the image. 		
	Asteroid	 You can drag the image in upper/lower/left/right direction. Press I to display the panorama, and press O to return to the original size. Press the left mouse-button to slide down to display the image on the plane surface. Scroll the mouse wheel to zoom the image. 		

4.3 PTZ Operation

This section introduces PTZ parameter configuration, PTZ control and PTZ function configuration.

4.3.1 Configuring External PTZ Protocol

You need to configure PTZ protocol when accessing external PTZ camera; otherwise the camera cannot control external PTZ camera.

Prerequisites

- Access external PTZ through RS-485.
- You have configured the parameters of serial port. For details, see "4.8.6.1 Serial Port Settings".

Procedure

<u>Step 1</u> Select Setting > PTZ Setting > Protocol.

	Figure 4-7 PTZ setting		
PTZ Settings			
Protocol	PELCOD Default Refresh Save		
		PTZ Settings Protocol PELCOD	

<u>Step 2</u> Select the PTZ protocol.

Step 3 Click OK.

4.3.2 Configuring PTZ Function

4.3.2.1 Preset

Preset means a certain position that the camera can make quick orientation to. It includes PTZ pan and tilt angles, camera focus, and location.

Step 1	Select Setting > PTZ settings > Function > Preset.

Figure 4-8 Preset					
Function					
	 Preset Tour Scan Pattern Pan PTZ Speed Idle Motion PowerUp PTZ Limit Time Task PTZ Restart Default 	Number	Preset Title	Save	Delete e All
Speed 5 •	► Derauit				

- <u>Step 2</u> Set the speed, and click \bigotimes , \bigcirc and \bigcirc to adjust the parameters of direction, zoom, focus and iris, to move the camera to the position you need.
- <u>Step 3</u> Click **Add** to add the current position to be a preset, and the preset is displayed in preset list.
- <u>Step 4</u> Double-click the preset title to edit it.
- <u>Step 5</u> Click \blacksquare to save the preset.

Related Operations

- Click to delete the preset.
- Click **Remove All** to remove all presets.

4.3.2.2 Tour

Tour means a series of movements that the camera makes along several presets.

Prerequisites

You have set several presets.

<u>Step 1</u> Select Setting > PTZ settings > Function > Tour.

Figure 4-9 Tour				
Function				
<complex-block></complex-block>	on t sk			

<u>Step 2</u> Click **Add** to add tour.

Double-click the tour name to edit the name.

<u>Step 3</u> Click Add 2 to add preset.

Double-click the duration to set the duration.

- <u>Step 4</u> Select the tour mode.
 - Original path: The PTZ camera moves in the order of the selected presets.
 - Shortest path: The PTZ camera ranks presets by distance, and moves in the optimal path.
- Step 5 Click Save.
- <u>Step 6</u> Click **Start** to start touring.


- If you operate PTZ during tour, the camera will stop tour.
- Click Stop to stop touring.

4.3.2.3 Scan

Scan means the camera moves horizontally at a certain speed between the configured left and right limits.

<u>Step 1</u> Select Setting > PTZ settings > Function > Scan.

Figure 4-10 Scan



- <u>Step 2</u> Select the scan number, and set the speed.
- <u>Step 3</u> Click **Setup** to set left limit and right limit.
 - 1) Click Set Left Limit to set the current position to be the left limit.
 - 2) Click Set Right Limit to set the current position to be the right limit.
- <u>Step 4</u> Click **Start** to start scanning. Click **Stop** to stop scanning.

4.3.2.4 Pattern

Pattern means a recording of a series of operations that you make to the camera, and when pattern starts, the camera performs the operations repeatedly. The operations include horizontal and vertical movements, zoom and preset calling. Record and save the operations, and then you can call the pattern path directly.

<u>Step 1</u> Select Setting > PTZ settings > Function > Pattern.

Figure 4-11 Pattern


Function
 Prest Com Com

- <u>Step 2</u> Select the pattern number.
- <u>Step 3</u> Click **Setup**, and then click **Start Rec**. Adjust the parameters of direction, zoom, focus and iris according to the actual situation.
- <u>Step 4</u> Click **Stop Rec** to stop recording.
- <u>Step 5</u> Click **Start** to start patterning.
- <u>Step 6</u> Click **Stop** to start patterning.

4.3.2.5 Pan

Enable Pan, the camera can realize continuous 360° horizontal rotation at a certain speed. <u>Step 1</u> Select **Setting > PTZ settings > Function > Pan**.

Figure 4-12 F	Pan			
Function				
Image: state stat	 Preset Tour Scan Pattern Pan PTZ Speed Idle Motion PowerUp PTZ Limit Time Task PTZ Restart Default 	Pan Speed	□	



Click Stop to stop rotation.

4.3.2.6 PTZ Speed

PTZ speed means the rotation speed of the PTZ camera during touring, pattern, or auto tracking.

<u>Step 1</u> Select Setting > PTZ settings > Function > PTZ Speed.

Function				
Punction	 Preset Tour Scan Pattern Pan PTZ Speed 	PTZ Speed 🔘 Low	Middle	⊙ High
	 Idle Motion PowerUp PTZ Limit Time Task 			
No. 10 August 10	PTZ Restart			
Com (+) Com (+) Com (+) Com (+) Focus (+) Iris (+) Speed (5) (*)	▶ Default			

Figure 4-13 PTZ speed

<u>Step 2</u> Select the PTZ speed: Low, Middle, and High.

 \square

Speed under the direction buttons refers to the rotation angle of the PTZ camera for each press of the direction button.

4.3.2.7 Idle Motion

Idle motion means that the PTZ camera implements the operation which is configured in advance when it does not receive any valid command within the set time.


Prerequisites

You have configured the PTZ motions, including preset, scan, tour, or pattern.

Procedure

<u>Step 1</u> Select Setting > PTZ settings > Function > Idle Motion.

Figure 4-14 Idle motion




- <u>Step 2</u> Select the **Enable** check box to enable the idle motion function.
- Step 3 Select the idle motion and set the idle time.
 You need to select the corresponding number for some selected idle motions, such as Preset001.
- Step 4 Click Save.

4.3.2.8 PowerUp

After setting Powerup motion, the camera will perform the configured motion after it is powered on.

<u>Step 1</u> Select Setting > PTZ settings > Function > PowerUp.





<u>Step 3</u> Select the power up motion.

 \square

When you select **Auto**, the system will perform the last motion that is executed for more than 20 s before power-off.

Step 4 Click OK.

4.3.2.9 PTZ Limit

After setting PTZ limit, the camera can only rotate within the configured area. <u>Step 1</u> Select Setting > PTZ settings > Function > PTZ Limit.



<u>Step 2</u> Adjust the direction buttons, and then click **Setting** to set the up line; click **Setting** ② to set the down line.

Click **Live** to view the configured up line and down line.

<u>Step 3</u> Select the **Enable** check box to enable the PTZ limit function.

4.3.2.10 Time Task

After setting time task, the camera performs the motions during the configured period.


Prerequisites

You have configured the PTZ motions, including preset, scan, tour, and pattern.

Procedure

<u>Step 1</u> Select Setting > PTZ settings > Function > Time Task.

Figure 4-17 Time task



- <u>Step 2</u> Select the **Enable** check box to enable time task function.
- <u>Step 3</u> Select the time task number.
- <u>Step 4</u> Select the time task action.

You need to select the corresponding action number for some selected time task actions.

- Set the auto home time in AutoHome.AutoHome: When you call PTZ, the time task will be interrupted. After settingAutoHome time, the camera will resume the time task automatically.
- <u>Step 6</u> Click **Period setting** to set the time of the task, and then click **Save**. For setting arm time, see "5.1.1.1 Setting Period".
- Step 7 Click Save.

Related Operations

You can copy the configurations of existing task number to other task number.

- 1. Select the existing task number in Time Task num .
- 2. Select the task number to be configured in Copy To Task No.
- 3. Click Copy.
- 4. Click Save.

4.3.2.11 PTZ Restart

<u>Step 1</u> Select Setting > PTZ settings > Function > PTZ Restart.



<u>Step 2</u> Click **PTZ Restart** to restart PTZ.

4.3.2.12 Default

 \wedge

Be careful when doing this operation. It will restore the camera to default configuration, and result in data loss.

<u>Step 1</u> Select Setting > PTZ settings > Function > Default.



<u>Step 2</u> Click **Default** and the PTZ function is restored to default.

4.3.3 Calling PTZ

Click **TZ** on **Live** interface, and the PTZ configuration panel is displayed. You can control PTZ and call PTZ function.

4.3.3.1 PTZ Control

You can rotate device, zoom image, and adjust iris through PTZ control or virtual joystick. See Figure 4-20 and Figure 4-21.

Figure 4-20 PTZ control



Figure 4-21 Joystick



O O O
O O O
C O O
C O O
C O O

left/right/up/down/upper left/upper right/bottom left/bottom right. Click (a), and draw a box in the image, PTZ will rotate, focus and quickly position the defined scene.

• Rotate PTZ direction through joystick. Select and hold 🚱, and drag it to the

direction that you need, then PTZ will move to the defined direction.

- Speed: Measure the rotation speed. The higher the speed value is, the faster the speed becomes.
- Zoom, focus and iris: Click or 🛨 to adjust zoom, focus and iris.

4.3.3.2 PTZ Function

Select the PTZ function from the drop-down list to call the corresponding functions, including Scan, Preset, Tour, Pattern, Pan, Go to, Assistant and Light Wiper. See Figure 4-22. For details, see Table 4-6. Before calling PTZ function, see "4.3.2 Configuring PTZ Function" to configure PTZ function.

 \square

- If an external PTZ is connected to the camera, the configurations are valid only when the corresponding functions are available on the external PTZ.
- The range of PTZ function (such as preset and tour) depends on the PTZ protocol.




Table 4-6 Description of PTZ function

Parameter	Description
Scan	Set the scan number and click Start , the camera moves horizontally at a certain speed between the set left and right limit. Click Stop to stop scanning.
Preset	Set the preset number and click Go to , the camera quickly positions the corresponding preset.
Tour	Set the tour number and click Start , the camera moves in the order of the selected presets. Click Stop to stop touring.
Pattern	Set the pattern number and click Start , the camera moves continuously according to the operation recording. Click Stop to stop patterning. Operation recording includes the information of manual operation, focus and zoom.
Pan	Click Start , and the camera rotates 360°at a certain speed in horizontal direction.
Go to	Set the horizontal angle, vertical angle, and zoom. Click Go to to position a certain point accurately.
Assistant	Set the assistant number and click Aux On to enable the corresponding assistant function, and then you can adjust the camera. Click Aux On to disable the corresponding assistant function.
Light/Wiper	 Set the light or wiper of the camera. Click Enable to enable light/wiper function. Click Disable to disable light/wiper function.

4.4 Playback

This section introduces playback related functions and operations, including video playback

and picture playback.

Ш

- Before playing back video, configure record time range, record storage method, record schedule and record control. For details, see "5.1.1.2.1 Setting Record Plan".
- Before playing back picture, configure snapshot time range, snapshot storage method, snapshot plan. For details, see"5.1.1.3.1 Setting Snapshot Plan".
- When using a smart card, make sure that the card has been authenticated before using.

4.4.1 Playback Interface

Click the **Playback** tab, and the **Playback** interface is displayed.



Figure 4-23 Video playback

Figure 4-24 Picture playback

	File Data		jpg	Card		•	
	Jun				2019 hu Fri		
						1	
	2	3	4	56	5 7	8	-
	9	10	11	12 1	3 14	15	-7
	16	17			0 21	22	
	23		25	26 2	7 28	29	
	30						
					-		
		12			E		
3-							
5-							

Table 4-7 Playback interface description

No.	Function	Description
1 Rules Info	Fisheye	Click , you can select display mode according to the installation mode during playback. This function is only available on fisheye cameras.
	Rules Info	Click , intelligent rules and object detection box are displayed. It is enabled by default. Rules Info is valid only when you enabled the rule during recording.
2	Sound	 Controls the sound during playback. Substant Mute mode. Substant Vocal state. You can adjust the sound.
3	Play control bar	 Controls playback. Click the icon to play back recorded videos. Click the icon to stop playing back recorded videos. Click the icon to play the next frame. Click the icon to slow down the playback. Click the icon to speed up the playback.

No.	Function	Description
4	Progress bar	 Displays the record type and the corresponding period. Click any point in the colored area, and the system will play back the recorded video from the selected moment. Each record type has its own color, and you can see their relations in Record Type bar.
5	Record/Snapshot Type	 Select the record type or snapshot type. Record type includes General, Event, Alarm, Manual Snapshot type includes General, Event, Alarm
6	Assistant	 You can zoom video image of the selected area through two operations. Click the icon to capture one picture of the current video, and it will be saved to the configured storage path.
7	Playback video	You can select the file type, data source, and record date.
8	Video clip	Clip a certain recorded video and save it. For details, see "4.4.3 Clipping Video".
9	Time format of progress bar	Includes 4 time formats: ^① 24hr, ^② 2hr, ^③ 1hr, ^③ 30min. Take ^③ 24hr as an example, the whole progress stands for 24 hours.

4.4.2 Playing back Video or Picture

This section introduces the operation of video playback and picture playback. This section takes video playback as an example.

<u>Step 1</u> Select **dav** from the **Record Type** drop-down list and **SD card** from the **Data Src** drop-down list.

Select **jpg** from **Record Type** drop-down list when playing back pictures, and you do not need to select data source.

File Type dav -Data Src SD Card -> < Sun Mon Tue Wed Thu Fri Sat

Figure 4-25 File type selection

<u>Step 2</u> Select the record type in **Record Type**.

Figure 4-26 Record type selection

Record Type All General Motion Alarm Manual Men selecting Event as the record type, you can select the specific event types from the playback file list, such as Motion Detection, Video Tamper and Scene Changing.

Figure 4-27	Specific event	types
-------------	----------------	-------

00 : 00 : 00 - 23 : 59 : 59	٩	
Event	•	
Event	•	
Motion Detection		
Video Tamper		
Scene Changing		
Intensity Change		
Input Abnormal	Ξ	
People Counting		
Defocus Detection		
Tripwire		
Intrusion		
Abandoned Object		
Missing Object		
Loitering Detection		
Fast-Moving		
Crowd Gathering Estimation	Ŧ	

<u>Step 3</u> Select the month and year of the video that you want to play.

Those dates with blue color indicate there were videos recorded in those days.

Step 4 Play video.

 \square

• Click **()** in the control bar.

The system plays the recorded video of the selected date (in the order of time).

- The system plays the recorded video of the selected date (in the order of time).
- Click any point in the colored area on the progress bar. The playback starts from that moment.

Figure 4-28 Progress bar

08:00 10:00 12:00

• Click []], the video files of the selected date would be listed. Enter the start time and end time, and then click **Q** to search all files between the start time and end time. Double-click the file in the list, and the system plays the video and displays file size, starting time, and ending time.




Figure 4-29 Playback file list

4.4.3 Clipping Video

- Click 📗, the video files of the selected date are listed. Step 1
- Select dav or mp4 in Download Format. Step 2
- Step 3 Click on the progress bar to select the start time of the target video, and then click . See Figure 4-30.

Figure 4-30 Clipping video



The system will prompt that it cannot play back and download at the same time.

Step 6 Click OK.

The playback stops and the clipped file is saved in the configured storage path. For the configuration of storage path, see "4.5.2.5 Path".

4.4.4 Downloading Video or Picture

Download video or picture to a defined path. You can download single video or picture file, or download them in batches. This section takes downloading video as an example.

Ш

- Playback and downloading at the same time is not supported.
- Operations might vary with different browsers, and the actual product shall prevail.
- For details of viewing or setting storage path, see "4.5.2.5 Path".

4.4.4.1 Downloading A Single File

<u>Step 1</u> Select **dav** from the **Record Type** drop-down list and **SD card** from the **Data Src** drop-down list.

Select **jpg** from **Record Type** drop-down list when playing back pictures, and you do not need to select data source.

- <u>Step 2</u> Click **E**, the video files of the selected date are listed. See Figure 4-29.
- Step 3 Select dav or mp4 in Download Format. Click next to the file to de download. The system starts to download the file to the configured path. When downloading pictures, you do not need to select the download format.

4.4.4.2 Downloading Files in Batches

Step 1 Click on the playback interface.

Figure 4-31 Batch download

	nload									
ype	All Videos	•								
tart Time	2019-06-18		00 : 00	: 00 E	nd Time	2019-06-18	2	3 : 59 : 59		Search
	Number	File Size(Kb)		Begin	Time	End	l Time	File	Туре	Download Progres
									M	<1/1 ▶ ▶ 1 (
le Size: 0Kt									M	∢ 1/1 ▶ ⊮ 1 (
le Size: OKt									M	<1/1 ▶ ▶ <u>1</u>
ile Size: OKt	dav								M	<1/1 ▶ ▶ 1 1

<u>Step 2</u> Select the record type, set the start time and end time, and then click **Search**. The searched files are listed. Step 3Select the files to be downloaded, select dav or mp4 from the Format drop-down list,
and then set the storage path. Click Download.
The system starts to download the file to the configured path. When downloading

picture, you do not need to select the download format.

4.5 Camera

This section introduces the camera setting, including conditions, video and audio.

 \square

Camera parameters of different devices might vary, and the actual product shall prevail.

4.5.1 Conditions

Configure camera parameters of the camera to ensure surveillance goes properly.

4.5.1.1 Conditions

Configure camera parameters according to the actual situation, including picture, exposure, backlight and white balance.

4.5.1.1.1 Interface Layout

Configure camera parameters to improve the scene clarity, and ensure that surveillance goes properly. See Figure 4-32.

- You can select normal, day or night mode to view the configuration and the effect of the selected mode, such as picture, exposure, and backlight.






Figure 4-32 Camera conditions





4.5.1.1.2 Picture

You can configure picture parameters as needed.

<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Picture.

	Profile Day		•
▶ Picture	Style Standard	d	•
Exposure	Brightness -	-0-	+ 50
 Backlight 	Contrast -	-0	+ 50
▶ WB	Saturation -	-0-	+ 50
Day & Night	Sharpness -	-0-	+ 50
 Illuminator 	Gamma 🖃	-0-	+ 50
 Image Correction 			
 Splicing Mode 			

Figure 4-34 Picture

<u>Step 2</u> Configure picture parameters.

Table 4-8 Description	of picture parameters
-----------------------	-----------------------

Parameter	Description
Style	 Select the picture style from soft, standard and vivid. Soft: Default image style, displays the actual color of the image. Standard: The hue of the image is weaker than the actual one, and contrast is smaller. Vivid: The image is more vivid than the actual one.
Brightness	Changes the value to adjust the picture brightness. The higher the value is, the brighter the picture will be, and the smaller the darker. The picture might be hazy if the value is configured too big.
Contrast	Changes the contrast of the picture. The higher the value is, the more the contrast will be between bright and dark areas, and the smaller the less. If the value is set too big, the dark area would be too dark and bright area easier to get overexposed. The picture might be hazy if the value is set too small.
Saturation	Makes the color deeper or lighter. The higher the value is, the deeper the color will be, and the lower the lighter. Saturation value does not change image brightness.
Sharpness	Changes the sharpness of picture edges. The higher the value is, the clearer the picture edges will be, and if the value is set too big, picture noises are more likely to appear.
Gamma	Changes the picture brightness and improves the picture dynamic range in a non-linear way. The higher the value is, the brighter the picture will be, and the smaller the darker.
Mirror	Select On , and the picture would display with left and right side reversed.

Parameter	Description
Flip	 Changes the display direction of the picture, see the options below. 0°: Normal display. 90°: The picture rotates 90° clockwise. 180°: The picture rotates 90° counterclockwise. 270°: The picture flips upside down. Image: For some models, please set the resolution to be 1080p or lower when using 90° and 180°. For details, see "4.5.2.1 Video".
EIS	Corrects the device shaking with difference comparison algorithm and improves the image clarity, effectively solves the picture shaking problem.
Picture Freeze	When you call a preset, the image displays the preset location, not the rotation image.

4.5.1.1.3 Exposure

Configure iris and shutter to improve image clarity.

 \square

Cameras with true WDR do not support long exposure when WDR is enabled in **Backlight**. <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Exposure.

Figure 4-35 Exposure

	Profile Day
▶ Picture	Anti-flicker Outdoor
► Exposure	Mode Auto
 Backlight 	3D NR On Off
▶ WB	Grade — + 50
Day & Night	
 Illuminator 	
Image Correction	
 Splicing Mode 	

<u>Step 2</u> Configure exposure parameters.

Parameter	ble 4-9 Description of exposure parameters
Parameter	Description
Anti-flicker	 You can select from 50 Hz, 60 Hz and Outdoor. 50 Hz: When the electric supply is 50 Hz, the system adjusts the exposure according to ambient light automatically to ensure that there is no stripe appears. 60 Hz: When the electric supply is 60 Hz, the system adjusts the exposure according to ambient light automatically to ensure that there is no stripe appears. Outdoor: You can select any exposure mode as needed.
Mode	 Device exposure modes. Auto: Adjusts the image brightness according to the actual condition automatically. Gain Priority: When the exposure range is normal, the system prefers the configured gain range when auto adjusting according to the ambient lighting condition. If the image brightness is not enough and the gain has reached upper or lower limit, the system adjusts shutter value automatically to ensure the image at ideal brightness. You can configure gain range to adjust gain level when using gain priority mode. Shutter priority: When the exposure range is normal, the system prefers the configured shutter range when auto adjusting according to the ambient lighting condition. If the image brightness is not enough and the shutter value has reached upper or lower limit, the system adjusts gain value automatically to ensure the image at ideal brightness. Iris priority: The iris value is set to a fixed value, and the device adjusts shutter value has reached upper or lower limit, the system adjusts gain value automatically to ensure the image at ideal brightness. Iris priority: The iris value is set to a fixed value, and the device adjusts shutter value has reached upper or lower limit, the system adjusts gain value automatically to ensure the image at ideal brightness. Manual: Configure gain and shutter value manually to adjust image brightness. When the Anti-flicker is set to Outdoor, you can select Gain priority or Shutter priority in the Mode list.
Exposure Comp	Sets the value, and it ranges from 0 to 50. The higher the value is, the brighter the image will be.
Shutter	Set the effective exposure time. The smaller the value, the shorter the exposure time will be.
Shutter range	When selecting Shutter Priority or Manual in Mode , and setting Customized Range in Shutter , you can set shutter range, and the unit is ms.
Gain	When selecting Gain Priority or Manual in Mode , you can set shutter range. With minimum illumination, the camera increases Gain automatically to get clearer images.

Parameter	Description
Iris	When selecting Aperture Priority in Mode , you can set iris range.
Auto Iris	 This configuration is available only when the camera is equipped with auto-iris lens. When auto iris is enabled, the iris size changes automatically according to the ambient lighting condition, and the image brightness changes accordingly. When auto iris is disabled, the iris stays at full size and does not change no matter how ambient lighting condition changes.
2D NR	Average single-frame dots and other dots around to reduce noise.
3D NR	Works with multi-frame (no less than 2 frames) images and reduces noise by using the frame information between previous and latter frames.
Grade	This configuration is available only when the 3D DNR is enabled. The higher the DNR level is, the better the result will be.

4.5.1.1.4 Backlight

You can select backlight mode from Auto, BLC, WDR, and HLS.

<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Backlight.

Figure 4-36 Backlight

 Picture Mode Off Exposure Backlight WB Day & Night Illuminator Image Correction Splicing Mode 		Profile Day	•
 Exposure Backlight WB Day & Night Illuminator Image Correction 	▶ Picture	Mode Off	•
 WB Day & Night Illuminator Image Correction 	▶ Exposure		
 Day & Night Illuminator Image Correction 	▶ Backlight		
Illuminator Image Correction	▶ WB		
Image Correction	▶ Day & Night		
	Illuminator		
► Splicing Mode	Image Correction		
	 Splicing Mode 		

<u>Step 2</u> Configure backlight parameters.

Table 4-10 Description of backlight parameters

Backlight mode	Description
Auto	The system adjusts image brightness according to ambient lighting condition automatically to ensure image clarity.

Backlight mode	Description
BLC	 Enable BLC, the camera can get clearer image of the dark areas on the target when shooting against light. You can select Default mode or Customized mode. When in Default mode, the system adjusts exposure according to ambient lighting condition automatically to ensure the clarity of the darkest area. When in Customized mode, the system auto adjusts exposure only to the set area according to ambient lighting condition to ensure the image of the set area at ideal brightness.
WDR	The system dims bright areas and compensates dark areas to ensure the clarity of all the area. The higher the value is, the brighter the dark will be, but the more the noise will be.
HLS	Enable HLS when extreme strong light is in the environment (such as toll station or parking lot), the camera will dim strong light, and reduce the size of Halo zone to lower the brightness of the whole image, so that the camera can capture human face or car plate detail clearly. The higher the value is, the more obvious the HLS effect will be.
Step 3 Click Save	

4.5.1.1.5 WB

WB function makes the image color display precisely as it is. When in WB mode, white objects would always display white color in different environments.

<u>Step 1</u> Select Setting > Camera > Conditions > WB.

Figure 4-37 WB

	Profile Day	•
▶ Picture	Mode Auto	•
▶ Exposure		
 Backlight 		
▶ WB		
▶ Day & Night		
 Illuminator 		
Image Correction		
 Splicing Mode 		



Table 4-11 Description of WB parameters

WB mode	Description
Auto	The system compensates WB according to color temperature to ensure color precision.

WB mode	Description
Natural	The system auto compensates WB to environments without artificial light to ensure color precision.
Street Lamp	The system compensates WB to outdoor night scene to ensure color precision.
Outdoor	The system auto compensates WB to most outdoor environments with natural or artificial light to ensure color precision.
Manual	Configure red and blue gain manually; the system auto compensates WB according to color temperature.
Regional Custom	The system compensates WB only to the set area according to color temperature to ensure color precision.

4.5.1.1.6 Day & Night

Configure the display mode of the image. The system switches between color and black-and-white mode according to the actual condition.

<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Day & Night.

Figure 4-38 Day and night

	Profile Day	
Picture	Mode Auto	
Exposure	Sensitivity Medium	
 Backlight 	Delay 6s	
▶ WB		
► Day & Night		
 Illuminator 		
Image Correction		
 Splicing Mode 		

<u>Step 2</u> Configure day and night parameters.

Table 4-12 Description of day and night parameters

Parameter	Description		
Mode	You can select device display mode from Color , Auto , and B/W . Day & Night configuration is independent from profile management configuration.		
	 Color: The system displays color image. Auto: The system switches between color and black-and-white display according to the actual condition. B/W: The system displays black-and-white image. 		
Sensitivity	This configuration is available only when you set Auto in Mode . You can configure camera sensitivity when switching between color and black-and-white mode.		

Delay You can conf and black-an	
camera switc	ation is available only when you set Auto in Mode . figure the delay when camera switching between color d-white mode. The lower the value is, the faster the shes between color and black-and-white mode.

4.5.1.1.7 Zoom and Focus

Initialize lens to adjust zoom and focus. Only PTZ camera supports lens initialization. <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > ZoomFocus.

Figure 4-39 Zoom and focus

	Profile Day		~
 Picture 	Mode Manual		~
 Exposure 	NearLight	-0-	+ 50
 Backlight 	FarLight		+ 0
▶ WB			
Day & Night			
ZoomFocus			
 Illuminator 			
Defog			

<u>Step 2</u> Configure zoom and focus parameters.

Parameter	Description		
Digital Zoom	Select On to enable digital zoom function. After the optical zoom reached the upper limit, enable digital zoom function, you still can do digital zoom operation.		
Zoom Speed	Adjusts zoom speed. The higher the value is, the higher the speed will be.		
Mode	 Sets focus mode. Auto: When image moves or object changes in the scene, the camera will focus automatically. Semi Auto: Click - or + corresponding to Focus or Zoom, the camera will focus. Calling preset, positioning accurately or rotating PTZ also will trigger focus. Manual: Click - or + corresponding to Focus to adjust the focus. 		
Focus Limit	When the focus length is too short, the camera will focus on the dome cover. Sets the shortest focus distance to avoid focusing on the dome cover. You can also change the focus speed by changing focus length.		

Parameter	Description
Sensitivity	The sensitivity of triggering focus. The higher the value is, the easier the focus will be triggered.
Step 3 Click Save.	

Click Lens Initialization, the lens will adjust the zoom and focus parameters.

4.5.1.1.8 Illuminator

This configuration is available only when the device is equipped with illuminator. <u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Illuminator.

Figure 4-40 Illuminator

	Profile Day
▶ Picture	Mode Auto 💌
Exposure	
 Backlight 	
▶ WB	
Day & Night	
► Illuminator	
Image Correction	
 Splicing Mode 	

<u>Step 2</u> Configure illuminator parameters.

Mode Set Fill Light for sound and siren cameras. IR Mode: Enable the IR illuminator, and the white light is disabled. When an alarm is triggered, the system will link white light. White Light is disabled. When an alarm is triggered, the system will link white light. White Light is disabled. When an alarm is triggered, the system will link white light. Smart illuminator is disabled. When an alarm is triggered, the system will link white light. Fill Light Fill Light Fill Light Smart illuminator is disabled. When an alarm is triggered, the system will switch the illuminator is enabled. The white light is enabled when the target is out of the surveillance area; and the IR illuminator is enabled according to the ambient light. When selecting Smart Illuminator as Fill Light, you need to set the illuminator delay. It is 60 seconds. Manual Adjust the brightness of illuminator nanually, and then the system will supply illuminator to the image according to the ambient light manual. Manual The system adjusts the illuminator intensity according to the change of the ambient light. Mode ZoomPrio When the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights. Mode ZoomPrio When the ambient light turns on the high beam lights until they are off, and then the low beam lights indt in order to avoid over-exposure in short distance. In the meantime, you can configure light in order to avoid over-exposure i	Illuminator		Description
Manual Adjust the brightness of illuminator manually, and then the system will supply illuminator to the image accordingly. Auto The system adjusts the illuminator intensity according to the ambient lighting condition. Smart IR The system adjusts the illuminator intensity according to the change of the ambient light. Mode When the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then. When the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights. When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light intensity.			 IR Mode: Enable the IR illuminator, and the white light is disabled. When an alarm is triggered, the system will link white light. White Light: Enable the white light, and the IR illuminator is disabled. When an alarm is triggered, the system will link white light. Smart illumination: They system will switch the illuminators according to the actual condition. When the ambient light reaches the threshold of IR illuminator, the IR illuminator is enabled. The white light is enabled when the target appears in surveillance area, disabled when the target is out of the surveillance area; and the IR illuminator is enabled according to the ambient light.
Manual then the system will supply illuminator to the image accordingly. Auto The system adjusts the illuminator intensity according to the ambient lighting condition. Smart IR The system adjusts the illuminator intensity according to the ambient lighting condition. Mode The system adjusts the illuminator intensity automatically according to the change of the ambient light. Mode When the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then. Mode ZoomPrio When the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights. When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light intensity.			you need to set the illuminator delay. It is 60 seconds by default, and the range is 30–300
Smart IRThe system adjusts the information intensity according to the ambient lighting condition.ModeThe system adjusts the illuminator intensity automatically according to the change of the ambient light.ModeWhen the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then.ModeZoomPrioWhen the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights.When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light intensity.		Manual	then the system will supply illuminator to the
ModeThe system adjusts the illuminator intensity automatically according to the change of the ambient light.ModeVhen the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then.When the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights.When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light intensity.		Auto	
ModeZoomPrioautomatically according to the change of the ambient light.ModeZoomPrio• When the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then.• When the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights.• When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light intensity.		Smart IR	according to the ambient lighting condition.
Off Illuminator is off.	Mode	ZoomPrio	 automatically according to the change of the ambient light. When the ambient light turns darker, the system turns on the low beam lights first, if the brightness is still not enough, it turns on the high beam lights then. When the ambient light turns brighter, the system dims high beam lights until they are off, and then the low beam lights. When the focus reaches certain wide angle, the system will not turn on high beam light in order to avoid over-exposure in short distance. In the meantime, you can configure light compensation manually to fine-tune IR light
		Off	Illuminator is off.

Table 4-14 Descri	ntion of il	lluminatori	narametere
		numinator	Jarameters

4.5.1.1.9 Defog

The image quality is compromised in foggy or hazy environment, and defog can be used to improve image clarity.

<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Defog.

Figure 4-41 Defog

	Profile Day	•
▶ Picture	Mode Off	
Exposure		
 Backlight 		
▶ WB		
Day & Night		
Illuminator		
▶ Defog		

<u>Step 2</u> Configure defog parameters.

Table 4-15 Description of defog parameters

Defog	Description
Manual	Configure function intensity and atmospheric light mode manually, and then the system adjusts image clarity accordingly. Atmospheric light mode can be adjusted automatically or manually.
Auto	The system adjusts image clarity according to the actual condition.
Off	Defog function is disabled.

Step 3 Click Save.

4.5.1.1.10 Fisheye

Select install mode and record mode according to the actual installation scene. When the camera accesses to the platform with corrective stream, the platform displays the corrective image.

\square

This function is only available on fisheye device.

<u>Step 1</u> Select Setting > Camera > Conditions > Conditions > Fisheye.

Figure 4-42 Fisheye

	Profile	Day	•
▶ Picture	Install Mode	Ceiling	•
▶ Exposure	inotan modo	Coming	
 Backlight 			
▶ WB			
► Day & Night			
► Illuminator			
▶ Fisheye			

<u>Step 2</u> Set install mode and record mode.

Parameter	Description		
Install Mode	You can select Ceiling, Wall, or Ground.		
Record Mode	 10: The original image before correction. 1P: 360° rectangular panoramic image. 2P: When the install mode is Ceiling or Ground, you can set this mode. Two associated 180° rectangular image screens, and at any time, the two screens form a 360° panoramic image. 1R: Original image screen + independent sub-screen. You can zoom or drag the image in all the screens. 2R: Original image screen + two independent sub-screens. You can zoom or drag the image in all the screens. 4R: Original image screen + four independent sub-screens. You can zoom or drag the image in all the screens. 10 + 3R: Original image screen + three independent sub-screens. You can zoom or drag the image in all the screens. 10 + 3R: Original image screen + three independent sub-screens. You can zoom or drag the image in all the screens. 		

Step 3 Click Save.

4.5.1.1.11 Image Correction

Enable the image correction function to correct some bent objects (such as roads) in the image of panoramic splicing cameras, but it will influence the field of view.

Figure 4-43 Image correction

Profile Day				
▶ Picture	Image Correct 🔘 On 💿 Off			
Exposure				
 Backlight 				
▶ WB				
► Day & Night				
Illuminator				
▶ Image Correction				
 Splicing Mode 				

4.5.1.1.12 Splicing Mode

Select the splicing mode to splice several images of different lens to a panoramic image. You can select **Merged Splicing** or **Splicing** for **Mode**.

Figure 4-44 Image correction

	Profile Day	
Picture	Mode Merged Splicing	
Exposure		
 Backlight 		
▶ WB		
Day & Night		
 Illuminator 		
Image Correction		
 Splicing Mode 		

4.5.1.2 Profile Management

The surveillance system works in different ways as profile configured in different time.

- <u>Step 1</u> Select Setting > Camera > Conditions > Profile Management. The Profile Management interface is displayed.
- Step 2 Manage profile.
 - When **Profile Management** is set as **General**, the surveillance system works under **General** configuration.

Figure 4-45 General					
Conditions	Profile Managemen	t Zoom and Foc	us		
Profile Managem	ent 💿 General 🔿 Fu	II Time 🔘 Schedu	le 🔿 Day/Night		
	Default	Refresh	Save		

• When **Profile Management** is set as **Full Time**, you can select **Day** or **Night** in the **Always Enable** list, the surveillance system works under **Always Enable** configuration.



Conditions	rofile Management Zoom and Focus				
Profile Management 🔘 General 💿 Full Time 🔘 Schedule 🔘 Day/Night					
Always Enable	Always Enable Day				
Default Refresh Save					

• When **Profile Management** is set as **Schedule**, you can drag the slide block to set certain time as **Day** or **Night**. For example, set 8:00–18:00 as day, and 0:00–8:00 and 18:00–24:00 as night.

Figure 4-47 Schedule

Conditions Pro	ofile Management Z	oom and Focus						
Profile Management	Profile Management 🔘 General 🔘 Full Time 💿 Schedule 🔘 Day/Night							
Period setting								
	0:00 4:00	8:00	12:00	16:00	20:00	24:00		
	📒 Day 🔳 Night							
	Default	Refresh	Save					

• When **Profile Management** is set as **Day & Night**, the surveillance system works under **Day & Night** configuration.

Figure 4-48 Day/Night					
Conditions F	Profile Managemen	t Zoom and Focus			
Profile Manageme	nt 🔿 General 🔘 Fu	III Time 🔘 Schedule	Day/Night		
	Default	Refresh	Save		

Step 3 Click Save.

4.5.1.3 Zoom and Focus

You can adjust image clarity through auto or manual focus; and adjust the image size through zoom. For details, see "4.2.4.2 Zoom and Focus".

4.5.1.4 Splicing

When the panorama contains multiple images of various lens, enable this function. Before splicing, make sure that the surveillance scene is large and there is no shield on the image, and do not move the camera; otherwise, the splicing might fail.

Ш

For some models, you need to select **Setting** > **System** > **General** > **Splicing** to enable the splicing function. For details, see "4.8.3 Splicing".

<u>Step 1</u> Select Setting > Camera > Conditions > Splicing.

Conditions Profile Management	Splicing
Splicing Distance	· · · · · · · · · · · · · · · · · · ·

Figure 4-49 Splicing

Step 2 Click , \pm or drag to adjust the splicing distance. Then the splicing starts, and after splicing is completed, there is successful note on the interface.

<u>Step 3</u> (Optional) Click **Auto Fine Tuning** when the splicing effect is not good, and the camera automatically adjusts the splicing finely.

4.5.2 Setting Video Parameters

This section introduces video parameters, such as video, snapshot, overlay, ROI (region of interest), and path.

\square

Click **Default**, and the device is restored to default configuration. Click **Refresh** to view the latest configuration.

4.5.2.1 Video

Configure video stream parameters, such as stream type, encode mode, resolution, frame rate, bit rate type, bit rate, I frame interval, SVC, and watermark.

<u>Step 1</u> Select **Setting > Camera > Video > Video**.

Figure 4-50 Video					
Video S	inapshot Over	lay ROI	Path		
Main Stream				Sub Stream	
				Enable	Sub Stream 1
Encode Mode	H.264H	•		Encode Mode	H.264H
Smart Codec	Off	•		Resolution	1280*600(1280x600)
Resolution	8192*3840(8192x3840)	• X		Frame Rate(FPS)	25 🔹
Frame Rate(FPS)	25	•		Bit Rate Type	CBR
Bit Rate Type	CBR	•		Reference Bit Rate	768-4352Kb/S
Reference Bit Rate	13290-65536Kb/S			Bit Rate	2048 (Kb/S)
Bit Rate	22528	 (Kb/S) 		I Frame Interval	50 (25~150)
I Frame Interval	50	(25~150)		SVC	1(off)
SVC	1(off)	•		Stream Smooth	
Watermark Settings					
Watermark Characte	DigitalCCTV				
Stream Smooth	E0E	100			
	Default	Refresh Save			

<u>Step 2</u> Configure video parameters.

Parameter	Description		
Enable	Select the Enable check box to enable sub stream, it is enabled by default.		
Encode Mode	 Select encode mode. H.264: Main profile encode mode. Compared with H.264B, it requires smaller bandwidth. H.264H: High profile encode mode. Compared with H.264, it requires smaller bandwidth. H.264B: Baseline profile encode mode. It requires smaller bandwidth. H.265: Main profile encode mode. Compared with H.264, it requires smaller bandwidth. MJPEG: When under this mode, the image requires high bit rate value to ensure clarity, you are recommended to set the Bit Rate value to the biggest value in the Reference Bit Rate. 		

Table 4-17 Description	of video parameters
------------------------	---------------------

Parameter	Description		
Smart Codec	Enable smart codec to improve video compressibility and save storage space.		
	After smart codec is enabled, the device would stop supporting the third stream, ROI, and smart event detection, and the actual interface shall prevail.		
Resolution	The resolution of the video. The higher the value is, the clearer the image will be, but the bigger the bandwidth will be required.		
	This function is available only for sub stream 2 of some select models.		
	Main stream		
	1. Select the resolution as needed, and click 🔊 next to		
	Resolution.		
	The Area interface is displayed.		
Video Clip	2. Clip the image on the Area interface, and then click Save .		
	View the clipped video on Live interface.		
	Sub stream 2		
	1. Select Video Clip, and click 🐲		
	The Area interface is displayed.		
	2. View the clipped video on Live interface (only the live interface		
	of sub stream 2 displays the clipped area).		
Frame Rate (FPS)	The number of frame in one second of video. The higher the value is, the clearer and smoother the video will be.		
	The bit rate control type during video data transmission. You can select bit rate type from:		
	• CBR (Constant Bit Rate): The bit rate changes a little and keeps		
	close to the defined bit rate value.		
Bit Rate Type	• VBR (Variable Bit Rate): The bit rate changes as monitoring		
Dir Kale Type	scene changes.		
	m		
	The Bit Rate Type can be only be set as CBR when Encode Mode		
	is set as MJPEG.		
Quality	This parameter can be configured only when the Bit Rate Type is set as VBR .		
Quanty	The better the quality is, the larger the bandwidth will be requested.		
Reference Bit Rate	The most suitable bit rate value range recommended to user according to the defined resolution and frame rate.		
Max Bit Rate	This parameter can be configured only when the Bit Rate Type is set as VBR .		
	You can select the value of the Max Bit Rate according to the Reference Bit Rate value. The bit rate then changes as monitoring scene changes, but the max bit rate keeps close to the defined value.		

Parameter	Description			
Bit Rate	This parameter can be configured only when the Bit Rate Type is set as CBR .			
	Select bit rate value in the list according to actual condition.			
I Frame Interval	The number of P frames between two I frames, and the I Frame Interval range changes as FPS changes.			
	It is recommended to set I Frame Interval twice as big as FPS.			
SVC	Scaled video coding, able to encode a high quality video bit stream that contains one or more subset bit streams. When sending stream, to improve fluency, the system will quit some data of related lays according to the network status.			
	 1: The default value, which means that there is no layered coding. 			
	 2, 3 and 4: The lay number that the video stream is packed. 			
Watermark Settings	You can verify the watermark to check if the video has been tampered.			
Watermark Character	 Select the check box to enable watermark function. The default character is DigitalCCTV. 			
Stream Smooth	Click _, + or drag to set the value of Stream Smooth .			
	The higher the value is, the less smooth the stream, but the higher the image definition; the lower the value is, the more smooth the stream, but the lower the image definition.			
Stop 3 Click Savo	The value of Stream Smooth is 100 by default.			

Step 3 Click Save.

4.5.2.2 Snapshot

You can configure snapshot parameters, including snapshot type, image size, quality and interval.

<u>Step 1</u> Select Setting > Camera > Video > Snapshot.

Figure 4-51 Snapshot							
Video	Snapshot	Overlay	ROI	Path	<u></u>		
Snapshot Type	General	•					
Image Size	1080P (1920*1080)						
Quality	5	•					
Interval	1 S	•					
	Default	Refresh Sa	ave				

<u>Step 2</u> Configure snapshot parameters.

Table 4-18 Description of snapshot parameter				
Parameter	Description			
Snapshot Type	 You can select General and Event. General: The system takes snapshot as scheduled. For details, see "4.7.2 Setting Schedule". Event: The system takes snapshot when the video detection, audio detection, event, or alarm is triggered. This function requires the corresponding snapshot being enabled. 			
Image Size	The same resolution with main stream.			
Quality	Configures the snapshot quality. There are six levels of Image quality, and the sixth is the best.			
Interval	Configures the snapshot frequency. Select Customized , and then you can configure snapshot frequency manually.			

Step 3 Click Save.

4.5.2.3 Overlay

Configure overlay information, and it will be displayed on the Live interface.

4.5.2.3.1 Configuring Privacy Masking

You can enable this function when you need to protect privacy of some area on the video image.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Privacy Masking.

Figure 4-52 Privacy masking





Figure 4-53 Privacy masking (PTZ dome)



Step 2 Configure privacy masking.


- PTZ dome
 - 1. Select the SN.
 - 2. Adjust the live image to the proper location through PTZ, select the color, and then click **Draw**. Press the mouse button to draw rectangles. The configuration takes effect immediately.
 - 3. Other operations:
 - \diamond Select the SN, and click Go to, the speed dome rotates to the masked area.
 - Select the SN, and click **Delete** to delete the masking rectangles.
 - \diamond Click **Clear**, and the click **OK** to clear all masking rectangles.
- Other cameras
 - 1. Select the **Enable** check box, and then drag the block to the area that you need to cover.

\square

- You can drag four rectangles at most.
- Click Remove All to delete all the area boxes; select one box, and then click Delete or right-click to delete it.
- 2. Adjust the size of the rectangle to protect the privacy.
- 3. Click Save.

4.5.2.3.2 Configuring Channel Title

You can enable this function when you need to display channel title in the video image. <u>Step 1</u> Select Setting > Camera > Video > Overlay > Channel Title.



<u>Step 2</u> Select the **Enable** check box, enter the channel title, and then select the text align.

Click + to expand the channel title, and you can expand 1 line at most.

- <u>Step 3</u> Move the title box to the position that you want in the image.
- Step 4 Click Save.

4.5.2.3.3 Configuring Time Title

You can enable this function when you need to display time in the video image. <u>Step 1</u> Select **Setting > Camera > Video > Overlay > Time Title**.



- <u>Step 2</u> Select the **Enable** check box.
- <u>Step 3</u> Select the **Week Display** check box.
- <u>Step 4</u> Move the time box to the position that you want in the image.

Step 5 Click Save.

4.5.2.3.4 Configure Text Overlay

You can enable this function if you need to display text in the video image.

Ш

Text overlay and picture overlay cannot work at the same time, and the IPC that connects to mobile NVR with private protocol would display GPS information as priority. <u>Step 1</u> Select Setting > Camera > Video > Overlay > Text Overlay.



<u>Step 2</u> Select the **Enable** check box, enter the text you need, and then select alignment. The text is displayed in the video image.

 \square

Click + to expand the text overlay, and you can expand 9 lines at most.

<u>Step 3</u> Move the text box to the position that you want in the image.

Step 4 Click Save.

4.5.2.3.5 Configure Font Attribute

You can enable this function if you need to adjust the font size in the video image. <u>Step 1</u> Select Setting > Camera > Video > Overlay > Font Attribute.



- <u>Step 2</u> Select the font color and size. Click **More Color** to customize the font color.
- Step 3 Click Save.


4.5.2.3.6 Configure Picture Overlay

You can enable this function if you need to display picture information on the video image.

 \square

Text overlay and picture overlay cannot work at the same time.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Picture Overlay.




<u>Step 2</u> Select the **Enable** check box, click **Upload Picture**, and then select the picture to be overlaid.

The picture is displayed on the video image.

- <u>Step 3</u> Move the overlaid picture to the position that you want in the image.
- Step 4 Click Save.

4.5.2.3.7 Configure Custom Overlay

You can enable this function if you need to display custom information on the video image. <u>Step 1</u> Select **Setting > Camera > Video > Overlay > Custom Overlay**.



<u>Step 2</u> Select the **Enable** check box, and then select the text align.

\square		
Click	+	to expand the custom overlay, and you can expand 1 line at most.

- <u>Step 3</u> Move the custom box to the position that you want in the image.
- Step 4 Click Save.

4.5.2.3.8 Configuring OSD Info

You can enable this function if you want to display the information of preset, PTZ coordinates, zoom, tour and location on the video image.

 \square

Only tracking speed dome supports OSD info function. <u>Step 1</u> Select Setting > Camera > Video > OSD Info.

		Figur	e 4-60 OS	D info				
Video	Snapshot	Overlay	ROI	Path				
P PT2 Dome.				Channel Privacy Mask Channel Title Time Title OSD info Picture Overlay Counting	1 Preset Temperature Coordinates Zoom North RS485 © Enable @ Input Text: Text Align Right	 Enable Enable Enable Enable Enable 	 Disable Disable Disable Disable Disable 	

<u>Step 2</u> Configure OSD information.

Table 4-19 Descri	ption of OSD information

Parameter	Description
Preset	Select Enable , and the preset name is displayed in the image when the camera turns to the preset, and it will disappear 3 s later.
Temperature	Select Enable and the internal temperature of the current device is displayed.
Coordinates	Select Enable and the PTZ coordinates info is displayed in the image.
Zoom	Select Enable and the zoom info is displayed in the image. such as $P:89.4$ T:12/5 Z:12, which means 12x zoom rate.
North	Select Enable and the north direction is displayed in the image.
RS485	Select Enable and it will enable RS-485 communication function.
Text	Select Enable and set text, and the text is displayed in the image.
Input Text	Select Linable and set text, and the text is displayed in the image.
Text Align	Alignment mode of the displayed information in the image.
Stop 2 Move the OS	D box to the position that you want in the image

Step 3Move the OSD box to the position that you want in the image.Step 4Click Save.

4.5.2.3.9 Configuring Counting

The image displays statistics of the enter number and leave number. When the overlay function is enabled during intelligent rules configuration, this function is enabled simultaneously. <u>Step 1</u> Select Setting > Camera > Video > Overlay > Counting.




Figure 4-61 Counting

<u>Step 2</u> Select the **Enable** check box, and then configure counting method and alignment.

- <u>Step 3</u> Move the counting box to the position that you want in the image.
- Step 4 Click Save.

4.5.2.3.10 Configuring Structured Statistics

The image displays structured statistics. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

```
<u>Step 1</u> Select Setting > Camera > Video > Overlay > Structured Statistics.
```




Figure 4-62 Structured statistics

Step 2Select the Enable check box, select the statistics type, and then select text align.Step 3Move the structured statistics box to the position that you want in the image.

Step 4 Click Save.

4.5.2.3.11 Configuring Ranging

Configure camera height and the display time of overlay information. Click any point on the ground that the pole is installed on the image, and the overlay information between camera and the selected point is displayed.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > Ranging.




<u>Step 2</u> Select the **Enable** check box, and then set the installation height and time display. Time display: The display time of the ranging information on live image.

Step 3 Click Save.

4.5.2.3.12 Configuring ANPR

The image displays ANPR statistics information. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

<u>Step 1</u> Select Setting > Camera > Video > Overlay > ANPR.



<u>Step 2</u> Select the **Enable** check box, select the statistics type, and then select text align.

- <u>Step 3</u> Move the ANPR box to the position that you want in the image.
- Step 4 Click Save.

4.5.2.3.13 Configuring Face Statistics

The image displays face statistics information. When the overlay function enabled during intelligent rules configuration, this function is enabled simultaneously.

```
<u>Step 1</u> Select Setting > Camera > Video > Overlay > Face Statistics.
```




Figure 4-65 Face statistics

- <u>Step 2</u> Select the **Enable** check box, and select text align.
- <u>Step 3</u> Move the structured statistics box to the position that you want in the image.
- Step 4 Click Save.

4.5.2.4 ROI

Select ROI (region of interest) on the image and configure the image quality of ROI, and then the selected image is display at defined quality.

<u>Step 1</u> Select Setting > Camera > Video > ROI.

		Figure 4-66	ROI		
Video	Snapshot	Overlay	ROI	Path	-
				O Enable 💿	Disable
	0	_	2019-12-27 17:23:07	Image Quality	6 💌
	Ŷ				
-			2		
T				?	
	and the second second		-		
		-	LON:0100000* LAT:0:00000* Speed: 0.0Km/h		
	A Margan				
Remove All	Delete	(Or Rightclick)			
Default	Refresh	Save			

<u>Step 2</u> Select the **Enable** check box, draw the area on the image, and then configure the image quality of ROI.

 \square

- You can draw four area boxes at most.
- The higher the image quality value is, the better the quality will be.
- Click **Remove All** to delete all the area boxes; select one box, and then click **Delete** or right-click to delete it.

Step 3 Click Save.

4.5.2.5 Path

You can configure the storage path for live snapshot, live record, playback snapshot, playback download, and video clips.

. . . .

<u>Step 1</u> Select Setting > Camera > Video > Path.

Video	Snapshot	Overlay	Path		(?
Live Snapshot	C:\Users\admin\WebE	Download\LiveSnapshot		Browse	
Live Record	C:\Users\admin\WebE	Download\LiveRecord		Browse	
Playback Snapshot	C:\Users\admin\WebE	Download\PlaybackSnapsh	hot	Browse	
Playback Download	C:\Users\admin\WebE	Download\PlaybackRecord	1	Browse	
Video Clips	C:\Users\admin\WebE	Download\VideoClips		Browse	

<u>Step 2</u> Click **Browse** to select the storage path for live snapshot, live record, playback snapshot, playback download, and video clips.

Parameter	Description	
Live Snapshot	The snapshot of live interface. The default path is C:\Users\admin\WebDownload\LiveSnap shot.	
Live Record	The recorded video of live interface. The default path is C:\Users\admin\WebDownload\LiveReco rd.	
Playback Snapshot	The snapshot of playback interface. The default path is C:\Users\admin\WebDownload\Playback Snapshot.	Admin in the path refers to the account being used.
Playback Download	The downloaded video of playback interface. The default path is C:\Users\admin\WebDownload\Playback Record.	<u>useu.</u>
Video Clips	The clipped video of playback interface. The default path is C:\Users\admin\WebDownload\VideoClip s.	

Table 4-20 Description of path

Step 3 Click Save.

4.5.3 Audio

You can configure audio parameters and alarm audio.

4.5.3.1 Configuring Audio Parameter

This section introduces audio parameters, including encode mode, sampling frequency, audio in type, and noise filter.

<u>Step 1</u> Select Setting > Camera > Audio > Audio.

Figure	4-68	Audio
--------	------	-------

Encode			
Main Stream			
Enable			
Encode Mode	G.711A 💌		
Sampling Frequency	16k 💌		
Sub Stream			
Enable	Sub Stream 1		
Encode Mode	G.711A 🔹		
Sampling Frequency	16k 💌		
Attribute			
AudioIn Type	Lineln 💌		
Noise Filter	Enable 🔹		
Microphone Volume	± 50		

- <u>Step 2</u> Select the **Enable** check box in **Main Stream** or **Sub Stream**. For the camera with multiple channels, select the channel number.
- Step 3 Configure audio parameters.

Table 4-21	Description	of audio	parameters
------------	-------------	----------	------------

Parameter	Description
Encode Mode	You can select audio Encode Mode from G.711A, G.711Mu, AAC, G.726.
Encode Mode	The configured audio encode mode applies to both audio and intercom. The default value is recommended.
Sampling Frequency	Sampling number per second. The higher the sampling frequency is, the more the sample in a second will be, and the more accurate the restored signal will be. You can select audio Sampling Frequency from 8K , 16K , 32K , 48K , 64K .
Audioin Type	 You can select audioin type from: Linein: Requires external audio device. Mic: Not require external audio device.
Noise Filter	Enable this function, and the system auto filters ambient noise.
Microphone Volume	Adjusts microphone volume.
Speaker Volume	Adjusts speaker volume.

Step 4 Click Save.

4.5.3.2 Configuring Alarm Audio

You can record or upload alarm audio file. The audio file will be played when the alarm is triggered.

- Click **0** to play the selected audio.
- Click 👱 to download the audio to local storage.

<u>Step 1</u> Select Setting > Camera > Audio > Alarm Audio.

Figure 4-69 Alarm audio

Choose	Name	Play	Download	Modify	Delete
G	alarm1.pcm	0	<u>+</u>		
с	alarm2.pcm	0	±		

Step 2 Click Add Audio File.

Figure 4-70 Add audio file

Add Audio File 🛛 🗙		
Record	C Upload	
Audio File	.pcm	
	Record	

<u>Step 3</u> Configure the audio file.

- Select Record, enter the audio name in the input box, and then click Record.
- Select **Upload**, click is to select the audio file to be uploaded, and then click **Upload**.

\sim	-	
	r	n –
		н.
		н.
-	-	5

The camera supports audio file with .pcm format only, and you can upload audio files with .pcm or .wav2 formats.

<u>Step 4</u> Select the file that you need.

4.6 Network

This section introduces network configuration.

4.6.1 TCP/IP

You can configure IP address and DNS (Domain Name System) server and so on according to network planning.

Prerequisites

The camera has connected to the network.

Procedure

<u>Step 1</u> Select Setting > Network > TCP/IP.

lost Name	IPC			- 1	
TUSCIVAINE	iro				
Ethernet Card	Wire(E	DEFAU	LT)	•	Set as Default
lode	• Sta	atic O	DHCP		
IAC Address				H.	E. =
P Version	IPv4			-	
P Address	100		1	. Billi	
Subnet mask	200	1966	14		
Default Gateway	-	12	12	-	
referred DNS Server	1	1	1	1	
Iternate DNS Server	66		10	-	
Enable ARP/Ping to se	et IP add	dress s	ervice		

<u>Step 2</u> Configure TCP/IP parameters.

Table 4-22 Description of	TCP/IP parameters
---------------------------	-------------------

Parameter	Description	
Host Name	Enter the host name, and the maximum length is 15 characters.	
Ethernet Card	Select the Ethernet card that need to be configured, and the default one is Wire .	
	The mode that the camera gets IP:	
	Static	
Mode	 Configure IP Address, Subnet Mask, and Default Gateway manually, and then click Save, the login interface with the configured IP address is displayed. DHCP When there is DHCP server in the network, select DHCP, and the camera acquires IP address automatically. 	
MAC Address	Displays host MAC address.	
IP Version	Select IPv4 or IPv6.	
IP Address	When you select Static in Mode, enter the IP address and subnet	
Subnet Mask	mask that you need.	

Parameter	Description		
Default Gateway	 IPv6 does not have subnet mask. The default gateway must be in the same network segment with the IP address. 		
Preferred DNS	IP address of the preferred DNS		
Alternate DNS	IP address of the alternate DNS		
Alternate DNS	Select the check box, get the camera MAC address, and then you can modify and configure the device IP address with ARP/ping command. This is enabled by default. During reboot, you will have no more than 2 minutes to configure the device IP address by a ping packet with certain length, the server will be turned off in 2 minutes, or it will be turned off immediately after the IP address is successfully configured. If this is not enabled, the IP address cannot be configured with ping packet. A demonstration of configuring IP address with ARP/Ping. 1. Keep the camera that needs to be configured and the PC within the same local network, and then get a usable IP address. 2. Get the MAC address of the camera from device label. 3. Open command editor on the PC and enter the following command. Windows syntax ^e arg =s <ip address=""> <mac> et ping =I 480 =t <ip address=""> et Windows exampleet arg =s <ip 11-40-8c-18-10-11et<br="" 2.168.0.125="">ping =I 480 <ip 192.168.0.125et<br="">UNIX/Linux/Mac syntaxet arg =s <ip address=""> <mac> et ping =s 480 <ip address=""> et UNIX/Linux/Mac exampleet arg =s 192.168.0.125 11-40-8c-18-10-11et ping =s 480 <ip address=""> et UNIX/Linux/Mac exampleet arg =s 192.168.0.125 11-40-8c-18-10-11et ping =s 480 <ip address=""> et UNIX/Linux/Mac exampleet arg =s 192.168.0.125 11-40-8c-18-10-11et ping =s 480 <ip address=""> et UNIX/Linux/Mac exampleet arg =s 192.168.0.125 11-40-8c-18-10-11et ping =s 480 192.168.0.125et 4. Restart the camera.</ip></ip></ip></ip></mac></ip></ip></ip></ip></mac></ip>		
Step <u>3</u> Click Save .	 Check the PC command line, if information such as Reply from 192.168.0.125 Enter http://(IP address) in the browser address bar to log in. 		

Step 3 Click Save.

4.6.2 Port

Configure the port numbers and the maximum number of users (includes web, platform client, and mobile phone client) that can connect to the device simultaneously. <u>Step 1</u> Select **Setting** > **Network** > **Port**.

	Figure 4-72 Port	
Port		
Max Connection	10	(1~20)
TCP Port	37777	(1025~65534)
UDP Port	37778	(1025~65534)
HTTP Port	80]
RTSP Port	554]
RTMP Port	1935	(1025~65534)
HTTPS Port	443]
	Default Re	fresh Save

<u>Step 2</u> Configure port parameters.

- \square
- 0–1024, 1900, 3800, 5000, 5050, 9999, 37776, 37780–37880, 39999, 42323 are occupied for specific uses.
- Do not use the same value of any other port during port configuration.

Table 4-23 Descripti	on of port parameters
----------------------	-----------------------

Parameter	Description
Max Connection	The max number of users (web client, platform client or mobile phone client) that can connect to the device simultaneously. The value is 10 by default.
TCP Port	Transmission control protocol port. The value is 37777 by default.
UDP Port	User datagram protocol port. The value is 37778 by default.
HTTP Port	Hyper text transfer protocol port. The value is 80 by default.

Real time streaming protocol port, and the value is 554 by default. If you play live view with QuickTime, VLC or Blackberry smart phone, the following URL format is available. When the URL format requiring RTSP, you need to specify channel number and bit stream type in the URL, and also user name and password if needed. When playing live view with Blackberry smart phone, you need to turn off the audio, and then set the codec mode to H.264B and resolution to CIF. URL format example: rtsp://username:password@ip:port/cam/realmonitor?channel=1& subtype=0 Among that: Username: The user name, such as admin. Password: The password@ip:port/cam/realmonitor?channel=1& subtype=0 Among that: Username: The user name, such as admin. Port: Leave it if the value is 554 by default. Channel: The device IP, such as 192.168.1.112. Port: Leave it if the value is 554 by default. Channel: The channel number, which starts from 1. For example, if you are using channel 2, then the channel=2. Subtype=0) and 1 means sub stream (Subtype=1). Example: If you require the sub stream of channel 2 from a certain device, then the URL should be: rtsp://admin:admin@10.12.4.84:554/cam/realmonitor?channel=2 1&=1 If user name and password are not needed, then the URL can be: rtsp://ip:port/cam/realmonitor?channel=11&=0 RTMP Port Real Time Messaging Protocol. The port that	Parameter	Description		
RTMP Port Real Time Messaging Protocol. The port that RTMP provides service. It is 1935 by default.	RTSP Port	 Real time streaming protocol port, and the value is 554 by default. If you play live view with QuickTime, VLC or Blackberry smart phone, the following URL format is available. When the URL format requiring RTSP, you need to specify channel number and bit stream type in the URL, and also user name and password if needed. When playing live view with Blackberry smart phone, you need to turn off the audio, and then set the codec mode to H.264B and resolution to CIF. URL format example: rtsp://username:password@ip:port/cam/realmonitor?channel=1& subtype=0 Among that: Username: The user name, such as admin. Password: The password, such as admin. IP: The device IP, such as 192.168.1.112. Port: Leave it if the value is 554 by default. Channel: The channel number, which starts from 1. For example, if you are using channel 2, then the channel=2. Subtype=0) and 1 means sub stream (Subtype=1). Example: If you require the sub stream of channel 2 from a certain device, then the URL should be: rtsp://admin:admin@10.12.4.84:554/cam/realmonitor?channel=2 		
	RTMP Port			
	HTTPS Port	-		

 \square

The configuration of **Max Connection** takes effect immediately, and others will take effect after reboot.

4.6.3 **PPPoE**

Point-to-Point Protocol over Ethernet, it is one of the protocols that device uses to connect to the internet. Get the PPPoE username and password from the internet service provider, and then set up network connection through PPPoE, the camera will acquire a WAN dynamic IP address.

Prerequisites

- The camera has connected to the network.
- You have gotten the account and password from Internet Service Provider.

Procedure

<u>Step 1</u> Select **Setting > Network > PPPoE**.

	Figure 4-73 PPPol	Ξ	
PPPoE			
Enable			
Username			
Password			
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** check box, and then enter user name and password.

- \square
- Disable UPnP while using PPPoE to avoid possible influence.
- After making PPPoE connection, the device IP address cannot be modified through web interface

Step 3 Click Save.

The success prompt box is displayed, and then the real-time WAN IP address is displayed. You can visit camera through the IP address.

4.6.4 DDNS

Properly configure DDNS, and then the domain name on the DNS server matches your IP address and the matching relation refreshes in real time. You can always visit the camera with the same domain name no matter how the IP address changes.

Prerequisites

Check the type of DNS server supported by the camera.

Procedure

<u>Step 1</u> Select Setting > Network > DDNS.

\square

- Third party server might collect your device information after DDNS is enabled.
- Register and log in to the DDNS website, and then you can view the information of all the connected devices in your account.

Figure 4-74 DDNS (1)				
DDNS				
🔽 Туре	NO-IP DDNS	 After enabling DDNS function, third-party server may collect your device info. 		
Address	dynupdate.no-ip.com			
Domain Nan	none	test		
Username	none			
Password	••••			
Interval	1440	Min.(1440~2880)		
	Default	Refresh Save		

Step 2	Select Type,	and configure the	e parameters as needed.
--------	--------------	-------------------	-------------------------

Parameter	Description			
Туре	The name and web address of the DDNS service provider, see the matching relationship below:			
Web Address • CN99 DDNS web address: www.3322.org • NO-IP DDNS web address: dynupdate.no-ip.com • Dyndns DDNS web address: members.dyndns.org				
Domain Name	The domain name you registered on the DDNS website.			
Test	Only when selecting NO-IP DDNS type, you can click test to check whether the domain name registration is successful.			
Username	Enter the username and password that you got from the DDNS			
Password	server provider. You need to register an account (includes username and password) on the DDNS server provider's website.			
Interval	The update cycle of the connection between the device and the server, and the time is 10 minutes by default.			
Step 3 Click Save.	·			

Result

Open the browser on PC, enter the domain name at the address bar, and then press Enter, the login interface is displayed.

4.6.5 SMTP (Email)

Configure email parameter and enable email linkage. The system sends email to the defined address when the corresponding alarm is triggered.

<u>Step 1</u> Select Setting > Network > SMTP (Email).

		Figure 4-75 SMTP (Email)
SMT	ſP(Email)	
	SMTP Server	none
	Port	25
	Anonymity	
	Username	anonymity
	Password	••••
	Sender	none
	Authentication	
	Autrentication	TLS -
	Title	IPC Message + V Attachment
	Mail Receiver	+
	Health Mail	Update Period 30 Min.(30~1440)
		Test
		1651
		Default Refresh Save

<u>Step 2</u> Configure SMTP (Email) parameters.

Table 4-25 Description of SMTP	(Email) parameters
--------------------------------	--------------------

Parameter	Description				
SMTP Server	SMTP server address				
Port	The port number of the SMTP server.				
Username	The account of SMTP server.	For details, see Table 4-26.			
Password	The password of SMTP server.				
Anonymity	Select the check box, and the sender's information is not displayed in the email.				
Sender	Sender's email address.				
Authentication	Select Authentication from None, SSL and TLS.				
Title	Enter maximum 63 characters in Chinese, English, and Arabic numerals. Click + to select title type, including Name , Device ID , and Event Type , and you can set maximum 2 titles.				
Attachment	Select the check box to support attachment in the email.				
Mail Receiver	Receiver's email address. Supports 3 addresses at most.				

Parameter	meter Description		
Health Mail	The system sends test mail to check if the connection is successfully configured. Select Health Mail and configure the Update Period , and then the system sends test mail as the set interval.		

For the configuration of major mailboxes, see Table 4-26.

Mailbox	SMTP server	Authentic ation	Port	Description
00	smtp.qq.co	SSL	465	 The authentication type cannot be None. You need to enable SMTP service in your mailbox. The authentication code is required, the QQ password or email password is not applicable. Authentication code: The code you receive when enabling SMTP service.
QQ	m	TLS	587	 The authentication type cannot be None. You need to enable SMTP service in your mailbox. The authentication code is required, the QQ password or email password is not applicable. Authentication code: The code you receive when enabling SMTP service.
163	smtp.163.c om	SSL	465/994	 You need to enable SMTP service in your mailbox. The authentication code is required; the email password is not applicable. Authentication code: the code you receive when enabling SMTP service.

Table 4-26 Description of major mailbox configuration

Mailbox	SMTP server	Authentic ation	Port	Description
		TLS	25	 You need to enable SMTP service in your mailbox. The authentication code is required; the email password is not applicable. Authentication code: the code you receive when enabling SMTP service.
		none	25	 You need to enable SMTP service in your mailbox. The authentication code is required; the email password is not applicable. Authentication code: the code you receive when enabling SMTP service.
Sina	smtp.sina.c	SSL	465	Enable SMTP service in your
	om	none	25	mailbox.
126	smtp.126.c om	none	25	Enable SMTP service in your mailbox.

Step 3 Click Save.

<u>Step 4</u> Click **Test** to test whether the emails can be sent and received successfully.

4.6.6 UPnP

UPnP (Universal Plug and Play), a protocol that establishes mapping relation between local area and wide area networks. This function enables you to visit local area device through wide area IP address.

Prerequisites

- Make sure the UPnP service is installed in the system.
- Log in the router, and configure WAN IP address to set up internet connection.
- Enable UPnP in the router.
- Connect your device to the LAN port of the router.
- Select Setting > Network > TCP/IP, in IP Address, enter the local area IP address of the router or select DHCP and acquires IP address automatically.

Procedure

<u>Step 1</u> Select **Setting > Network > UPnP**.

Figure 4-76 UPnP

Start Device Disco Port Mapping List							
	Service Name	Protocol	Internal Port	External Port	Status	Modify	
	HTTP	WebService:TCP	20		Mapping Failed	1	
	TCP	PrivService:TCP	3	Annes.	Mapping Failed	1	
	UDP	PrivService:UDP	a series and	35778	Mapping Failed	/	
V	RTSP	RTSPService:TCP	-		Mapping Failed	2	

- <u>Step 2</u> Select the **Enable** check box, and there are two mapping modes: **Custom** and **Default**.
 - Select **Custom**, click 📝 and then you can modify external port as needed.
 - Select **Default**, and then the system finishes mapping with unoccupied port automatically, and you cannot modify mapping relation.

Step 3 Click Save.

Open web browser on PC, enter http:// wide area IP address: external port number, and then you can visit the local area device with corresponding port.

4.6.7 SNMP

SNMP (Simple Network Management Protocol), which can be used to enable software such as MIB Builder and MG-SOFT MIB Browser to connect to the camera and manage and monitor the camera.

Prerequisites

- Install SNMP monitoring and managing tools such as MIB Builder and MG-SOFT MIB Browser.
- Get the MIB file of the matched version from technical support.

Procedure

<u>Step 1</u> Select Setting > Network > SNMP.

	Figure 4-77 S	NMP (1)		
SNMP				
Version	🗆 v1	🗌 v2		🗆 v3
SNMP Port	161		(1~65535)	
Read Community]	
Write Community]	
Trap Address]	
Trap Port	162]	
	Default	Re	fresh	Save

Figure 4-78 SNMP (2)

NMP			
Version	v1	v2	V3 (Recommen
SNMP Port	161	(1~6	5535)
Read Community			
Write Community			
Trap Address			
Trap Port	162		
Read-only Username	public		
Authentication Type	 MD5 	© SHA	
Authentication Pas		The r	ninimum pass phrase length is 8 characters
Encryption Type	CBC-DES		
Encryption Password		The r	ninimum pass phrase length is 8 characters
Read&write Userna	private		
Authentication Type	MD5	○ SHA	
Authentication Pas		The r	ninimum pass phrase length is 8 characters
Encryption Type	CBC-DES		
Encryption Password		The r	ninimum pass phrase length is 8 characters
	Default	Refresh	Save

<u>Step 2</u> Select SNMP version to enable SNMP.

- Select V1, and the system can only process information of V1 version.
- Select V2, and the system can only process information of V2 version.
- Select V3, and then V1 and V2 become unavailable. You can configure user name, password and authentication type. It requires corresponding user name, password

and authentication type to visit your device from the server.

\square

Using V1 and V2 might cause data leakage, and V3 is recommended.

In **Trap Address**, enter the IP address of the PC that has MIB Builder and MG-SOFT MIB Browser installed, and leave other parameters to the default.

Parameter	Description
SNMP Port	The listening port of the software agent in the device.
Read Community, Write Community	The read and write community string that the software agent supports.
Trap Address	The target address of the Trap information sent by the software agent in the device.
Trap Port	The target port of the Trap information sent by the software agent in the device.
Read-only Username	Set the read-only username accessing device, and it is public by default.
Read/Write Username	Set the read/write username access device, and it is public by default.
Authentication Type	You can select from MD5 and SHA . The default type is MD5 .
Authentication Password	It should be no less than 8 digits.
Encryption Type	The default is CBC-DES.
Encryption Password Step 3 Click Save .	It should be no less than 8 digits.

Table 4-27	Description	of SNMP	parameters
	Dooonplion		paramotoro

Step 3 Click Save.

Result

View device configuration through MIB Builder or MG-SOFT MIB Browser.

- 1. Run MIB Builder and MG-SOFT MIB Browser.
- 2. Compile the two MIB files with MIB Builder.
- 3. Load the generated modules with MG-SOFT MIB Browser.
- 4. Enter the IP address of the device you need to manage in the MG-SOFT MIB Browser, and then select version to search.
- 5. Unfold all the tree lists displayed in the MG-SOFT MIB Browser, and then you can view the configuration information, video channel amount, audio channel amount, and software version.

Ш

Use PC with Windows OS and disable SNMP Trap service. The MG-SOFT MIB Browser will display prompt when alarm is triggered.

4.6.8 Bonjour

Enable this function, and the OS and clients that support Bonjour would find the camera automatically. You can have quick visit to the camera with Safari browser.

 \square

Bonjour is enabled by default.

Procedure

```
<u>Step 1</u> Select Setting > Network > Bonjour.
```

Bonjour	Figure 4-79 Bonjo	our	
Enable			
Server Name	2F03XXXXXXXXXXXX		
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** check box, and then configure server name.

Step 3 Click Save.

Result

In the OS and clients that support Bonjour, follow the steps blow to visit the network camera with Safari browser.

- 1. Click Show All Bookmarks in Safari.
- 2. Enable **Bonjour**. The OS or client automatically detects the network cameras with Bonjour enabled in the LAN.
- 3. Click the camera to visit the corresponding web interface.

4.6.9 Multicast

When multiple users are previewing the device video image simultaneously through network, it might fail due to limited bandwidth. You can solve this problem by setting up a multicast IP (224.0.1.0–238.255.255.255) for the camera and adopt the multicast protocol.

<u>Step 1</u> Select Setting > Network > Multicast.

Figure 4-80 Multicast

Main Stream			Sub Stream		
Enable			Enable	Sub Stream 1	•
Multicast Address	224 . 1 . 2 . 4	(224.0.0.0~239.255.255.255)	Multicast Address	224 1 2 4	(224.0.0.0~239.255.255.255)
Port	40000	(1025~65500)	Port	40016	(1025~65500)

<u>Step 2</u> Select the **Enable** check box, and enter IP address and port number.

Table 4-28 Description of multicast parameters		
Parameter	Description	
Multicast Address	The multicast IP address of Main Stream/Sub Stream is 224.1.2.4 by default, and the range is 224.0.0.0–239.255.255.255.	
Port	The multicast port of corresponding stream: Main Stream : 40000; Sub Stream1 : 40016; Sub Stream2 : 40032, and all the range is 1025–65500.	

Step 3 Click Save.

Result

In the Live interface, select RTSP in Multicast, and then you can view the video image with multicast protocol.

4.6.10 802.1x

Cameras can connect to LAN after passing 802.1x authentication. Step 1 Select Setting rk 2002 1

<u>step 1</u>	Select Setting > Network > 802.1x.	

	Figure 4-81 802.1x	
802.1x		
Enable		
Authentication	PEAP 🔻	
Username	none	
Password	••••	
	Default	Save

<u>Step 2</u> Select the **Enable** check box, and then configure parameters.

Table 4-29 Description of 802.1x parameters

Parameter	Description
Authentication	PEAP (protected EAP protocol).
Username	The user name that was authenticated on the server.
Password	Corresponding password.

Step 3 Click Save.

4.6.11 QoS

You can solve problems such as network delay and congestion with this function. It helps to assure bandwidth, reduce transmission delay, packet loss rate, and delay jitter to improve experience.

0-63 means 64 degrees of priority; 0 for the lowest and 63 the highest.

<u>Step 1</u> Select Setting > Network > QoS.

	Figure 4-82 Q	oS	
QoS			
Realtime Monitor	0	(0~63)	
Command	0	(0~63)	
	Default	Refresh	Save

Step 2 Configure QoS parameters.

Table 4-30 Description of QoS parameters

Parameter	Description
Realtime Monitor	Configure the priority of the data packets that used for network surveillance. 0 for the lowest and 63 the highest.
Command	Configure the priority of the data packets that used for configure or checking.

Step 3 Click Save.

4.6.12 Access Platform

4.6.12.1 P2P

P2P is a private network traversal technology which enables users to manage devices easily without requiring DDNS, port mapping or transit server.

Scan the QR code with your smart phone, and then you can add and manage more devices on the mobile phone client.

<u>Step 1</u> Select Setting > Network > Access Platform > P2P.

P2P	ONVIF	RTMP		
🔽 Enable				
Status	Offline			
S/N	4M02	10.000		
QR Code	Please scan the QR code on the actual interface			
	Default	Refresh	Save	
When P2F	is enabled, remote	e management on de	evice is supported.	

• When P2P is enabled and the device accesses to the network, the status shows online. The information of the IP address, MAC address, device name, and device

SN will be collected. The collected information is for remote access only. You can cancel **Enable** selection to reject the collection.

- <u>Step 2</u> Log in to mobile phone client and tap **Device management**.
- <u>Step 3</u> Tap the + at the upper right corner.
- <u>Step 4</u> Scan the QR code on the **P2P** interface.
- <u>Step 5</u> Follow the instructions to finish the settings.

4.6.12.2 ONVIF

The ONVIF authentication is **On** by default, which allows the network video products (including video recording device and other recording devices) from other manufacturers to connect to your device.

 \square

ONVIF is enabled by default.

<u>Step 1</u> Select **Setting > Network > Port > ONVIF**.

		Figure 4-84	ONVIF	
	P2P	ONVIF	RTMP	
	Authentication	● On ○ O Default	rff Refresh	Save
~				

Step 2 Select On in Authentication.

Step 3 Click Save.

4.6.12.3 RTMP

Through RTMP, you can access the third-party platform (such as Ali and YouTube) to realize video live view.

 \square

- RTMP can be configured by admin only.
- RTMP supports the H.264, H.264 B and H.264H video formats, and the AAC audio format only.

<u>Step 1</u> Select Setting > Network > Port > RTMP.

	Figure 4-8	35 ONVIF	
P2P	ONVIF	RTMP	
Enable			
Stream Type	Main Stream	🔘 Sub Stream 1 🛛 🔘 Sub Stream 2	
Address Type	e 💿 Non-custom	◯ Custom	
IP Address	0.0.0		
Port	1935	(0~65535)	
Custom Addr	ress		
	Default	Refresh Save	

Step 2 Select the Enable check box.

A

Make sure that the IP address is trustable when enabling RTMP. <u>Step 3</u> Configure RTMP parameters. .

Table 4-31	Description	of RTMP	parameters
	Dooonpaon	0	paramotoro

Parameter	Description			
Stream Type	The stream for live view. Make sure that the video format is the H.264, H.264 B and H.264H, and the audio format is AAC.			
	Includes Non-custom and Custom.			
Address Type	• Non-custom: Enter the server IP and domain name.			
	• Custom : Enter the path allocated by the server.			
IP Address	When selecting Non-custom, you need to enter server IP			
	address and port.			
Port	 IP address: Support IPv4 or domain name. 			
	• Port : We recommend that you use the default one.			
Custom Address	When selecting Custom , you need to enter the path allocated by the server.			

Step 4 Click Save.

4.7 Storage

This section introduces how to manage saved resources (such as recorded video) and storage space. The storage management helps to make best use of storage space.

4.7.1 Setting Storage Plan

• Setting record plan and record control to achieve all-time recording, recording in specific period or alarm linked recording. For details, see "5.1.1.2.1 Setting Record Plan" and "5.1.1.2.2 Setting Record Control".

• Set the snapshot schedule as needed. For details, see "5.1.1.3.1 Setting Snapshot Plan".

4.7.2 Setting Schedule

You can configure record schedule, snapshot schedule and holiday schedule. Set certain days as holiday, and when the **Record** or **Snapshot** is selected in the holiday schedule, the system takes snapshot or records video as holiday schedule defined.

Prerequisites

- Set the record mode to be Auto in Record Control. For details, see "5.1.1.2.1 Setting Record Plan".
- Configure holiday record and snapshot schedule. For details, see "5.1.1.2.1 Setting Record Plan" and "5.1.1.3.1 Setting Snapshot Plan".

Procedure

<u>Step 1</u> Select Setting > Storage > Schedule > Holiday Schedule.

			Fig	gure 4-	86 Ho	liday s	chedule
Re	ecord		Sr	apsho	t	Holida	ay Schedu
	Record	SI	napsho	t			
С	alendar					Jul	•
	Sun	Mon	Tue	Wen	Thu	Fri	Sat
		1	2	3	4	5	6
	7	8	9	10	11	12	13
	14	15	16	17	18	19	20
	21	22	23	24	25	26	27
	28	29	30	31			
	Refre	sh		Save			

Step 2 Select **Record** or **Snapshot**.

Step 3 Select the days you need to set as holiday. Those days with yellow color indicates that they were set as holidays.

\square

When holiday schedule setting is not the same as the general setting, holiday schedule setting is prior to the general setting. For example, with **Holiday Schedule** enabled, if the day is holiday, the system snapshots or records as holiday schedule setting; otherwise, the system snapshots or records as general setting.

```
Step 4 Click Save.
```

4.7.3 Setting Destination

This section introduces the configuration of the storage method for the recorded videos and snapshots.

4.7.3.1 Path

You can select different storage paths for the recorded videos and snapshots according to event type. You can select from SD card, FTP and NAS.

 \square

Local is displayed only on models that support SD card.

```
<u>Step 1</u> Select Setting > Storage > Destination > Path.
```

Figure	e 4-87	Path

		Snapshot			
duled Motion De	ection Alarm	Event Type	Scheduled	Motion Detection	Alarm
		Local			
V V		FTP			\checkmark
		NAS			
			Local Local Local Local NAS	Local C	Local C

<u>Step 2</u> Select the storage method that you need for the recorded videos and snapshots of different types.

Table 4-32 Description	of path	parameters
------------------------	---------	------------

Select from Scheduled, Motion Detection and Alarm.		
Save in the internal SD card.		
Save in the FTP server.		
Save in the NAS (network attached storage).		

Step 3 Click Save.

<u>Step 4</u> Configure other path parameters on **Destination**, **FTP** or **NAS** interface. For details, see "4.7.3 Setting Destination", "4.7.3.3 FTP" or "4.7.3.4 NAS".

4.7.3.2 Local

Display the information of the local SD card. You can set it as read only or read & write; you can also hot swap and format SD card, and reset password for it. When inserting a smart card onto a device available for it, there are 3 modes according to the SD card status:

- Normal mode: The new SD cards and the cards whose password are cleared successfully show normal mode. The SD cards of this status do not support authorization operation.
- Unauthorized mode: The SD card authorized by other devices shows unauthorized mode. The SD cards of this status do not support operations of setting read only, read & write, formatting and encryption.
- Encrypted mode: The SD cards encrypted and authorized on this camera show encrypted mode. The camera can record max. 10 pieces of encrypted SD information. When the recorded videos exceed 10 pieces, the earliest ones will be overwritten.

 \square

- Functions might vary with different models, and the actual product shall prevail.
- If you enter the wrong password for five times when authorizing, modifying, and clearing password, the camera will be locked for five minutes.
- Make sure that the SD card has been authorized before recording and playback.
- The health status of SD card:
 - ◊ Green: The health status is excellent.
 - ◊ Blue: The health status is good.
 - Orange: The health status is moderate.
 - Red: The health status is poor, and you need to replace the SD card.

Select **Setting** > **Storage** > **Destination** > **Local**, and then the **Local** interface is displayed. See Figure 4-88.

- Click Read Only, and then the SD card is set to read only.
- Click Read & Write, and then the SD card is set to read & write.
- Click Hot Swap, and then you can pull out the SD card.
- Click **Refresh**, and then you can format the SD card.
- Click **Format**, and you can format the SD card.

 \square

When reading SD card on PC, if the SD card capacity is much less than the nominal capacity, you need to format the SD card. Then the data in SD card will be cleared, and the SD card is formatted to be private file system. The private file system can greatly improve SD card multimedia file read/write performance. Download Diskmanager from Toolbox to read the SD card. For details, contact aftersales technicians.

Figure	4-88	Local
iguio	- 00	Looui

Path	L	ocal	FTP	NAS	
Name	Status	Attribute	Used Ci	apacity/Total Capacity	
Read Only	Read & W	rite Hot	Swap Refre	esh	

4.7.3.3 FTP

FTP function can be enabled only when it was selected as a destination path. When the network does not work, you can save all the files to the internal SD card for emergency.

<u>Step 1</u> Select Setting > Storage > Destination > FTP.

Figure 4-89 FTP											
Path	Local	FTP		NAS							
Enable Server Address	FTP	•									
Port	21	(0~65535)									
Username	ipc										
Password	•••										
Remote Directory	share										
Emergency (Local)											
	test			1							
	Default	Refresh	Save								

- <u>Step 2</u> Select the **Enable** check box to enable FTP function, and select the FTP type.

You select **FTP** or **SFPT** from the drop-down list. **SFTP** is recommended to enhance network security.

<u>Step 3</u> Configure FTP parameters.

Table 4-33 Description of FTP parameters

Parameter	Description
Server Address	The IP address of the FTP server.
Port	The port number of the FTP server.
Username	The user name to log in to the FTP server.
Password	The password to log in to the FTP server.
Remote Directory	The destination path in the FTP server.
Emergency (Local)	Select Emergency (Local) , and when the FTP server does not work, all the files are saved to the internal SD card.

Step 4 Click Save.

<u>Step 5</u> Click **test** to test whether FTP function works normally.

4.7.3.4 NAS

This function can be enabled only when NAS was selected as a destination path. Enable this function, and you can save all the files in the NAS.

<u>Step 1</u> Select Setting > Storage > Destination > NAS.

Figure 4-90 NAS				
Path	Local	FTP	NAS	
Enable Server Address Remote Directory	NFS 0.0.00 Default	Refresh S	tave	

- Step 2 Select the **Enable** check box to enable NAS function, and select NAS protocol type.
 - **NFS** (Network File System): A file system which enables computers in the same network share files through TCP/IP.
 - SMB (Server Message Block): Provides shared access for clients and the server.

<u>Step 3</u> Configure NAS parameters.

Parameter	Description		
Server Address	The IP address of the NAS server.		
Username	When selecting SMB protocol, you are required to enter use		
Password	name and password. Enter them as needed.		
Remote Directory	The destination path in the NAS server.		
Step 4 Click Save			

Table 4-34 Description of NAS parameters

Click Save. Step 4

4.8 System

This section introduces system configurations, including general, date & time, account, safety, PTZ settings, default, import/export, remote, auto maintain and upgrade.

4.8.1 General

You can configure device name, language and video standard.

<u>Step 1</u> Select Setting > System > General > General.

Figure 4-91 General			
General D	ate&Time		
Name	4M0292DYAG2B100		
Language	English	•	
Video Standard	PAL	•	
TVOut	TV	•	
	Default	Refresh	Save

<u>Step 2</u> Configure general parameters.

Table 4-35 Description of general parameters

Parameter	Description
Name	The name of the device.
Language	Select system language.
Video Standard	Select video standard from PAL and NTSC.

Parameter	Description
TVOut	 Select On or Off. This function is available on models with analog output. If the TV out is On, smart plans will be disabled; if the smart plans are enabled, the TV out will be set as Off. SDI and HDCVI are available on select models.

Step 3 Click Save.

4.8.2 Date & Time

You can configure date and time format, time zone, current time, DST (Daylight Saving Time) or NTP server.

```
<u>Step 1</u> Select Setting > System > General > Date & Time.
```

Figure	4-92	Date	and	time

General	Date&Time	
Date Format	YYYY-MM-DD	
Time Format	24-Hour	
Time Zone	(UTC) Coordinated Universal Time	
Current Time	2019-07-12 🗰 09 : 45 : 51 Sync PC	
DST		
DST Type	Date O Week	
Start Time	Jan 💌 1 💌 00 : 00 : 00	
End Time	Jan 💌 2 💌 00 : 00 : 00	
NTP		
Server	clock.isc.org	
Port	123	
Interval	10 Min. (0~30)	
	Default Refresh Save	

Parameter	Description	
Date Format	Configure the date format.	
Time Format	Configure the time format. You can select from 12-Hour or 24-Hour .	
Time Zone	Configure the time zone that the camera is at.	
Current Time	Configure system time. Click Sync PC , and the system time changes to the PC time.	
DST	Enable DST as needed. Select the check box, and configure start time and end time of DST with Date or Week .	
NTP	Select the check box, and then NTP (network time protocol) is	
NTP Server.	enabled, the system then syncs time with the internet server in real time.	
Time Zone	You can also enter the IP address, time zone, port, and interval of a	
Port	PC which installed NTP server to use NTP.	

Parameter	Description
Interval	
Stop 3 Click Savo	

Step 3 Click Save.

4.8.3 Splicing

When the panorama contains multiple images of various lens, enable this function. Before splicing, make sure that the surveillance scene is large and there is no shield on the image, and do not move the camera; otherwise, the splicing might fail.


 \square

For some models, you need to select **Setting > Camera > Condition > Splicing** to enable the splicing function. For details, see "4.5.1.4 Splicing".

```
Step 1 Select Setting > System > General > Splicing
```

	Figure 4-93 Splic	cing (1)	
General	Date&Time	Splicing	
Camera1	Camera2		
Start			

Figure 4-94 Splicing (2)



<u>Step 2</u> Select the camera which needs to be spliced.

When splicing the image through selecting lenses, you need to select the continuous splicing screens. The screen with the icon 🧭 (deeper color) means the first screen of the splicing. You can select any screen as the first one, and select the following screens continuously. The system supports the splicing of 4, 5, 6, 7 and 8 sensors.

 \square

his function is available on some select models. And it is all sensors splicing by default.

Step 3 Click Start.

The system starts to splice image.

- Some camera restarts automatically after splicing is completed, and you can view the splicing effect on the **Live** interface.
- Some camera displays splicing live view interface after splicing is completed. Click **OK**, and then the system prompts default box. And then click **OK**. The splicing takes effect.

4.8.4 Account

Manage all the users. You can add, delete, or modify users. Users include admin, added users and ONVIF users.

Managing users and groups are only available for administrator users.

- The max length of the user or group name is 31 characters which consisted of number, letters, underline, dash, dot and @.
- The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' "; : &).
- You can have 18 users and 8 groups at most.
- You can manage users through single user or group, and duplicate user names or group names are not allowed. A user can be in only one group at a time, and the group users can own authorities within group authority range.
- Online users cannot modify their own authority.
- There is one admin by default which has highest authority.
- Select **Anonymous Login**, and then log in with only IP address instead of user name and password. Anonymous users only have preview authorities. During anonymous login, click **Logout**, and then you can log in with other username.


4.8.4.1 Adding a User

You are admin user by default. You can add users, and configure different authorities. <u>Step 1</u> Select Setting > System > Account > Account > Username.

Figure 4-95 Username

Username	Group Name					
No.	Username	Group Name	Memo	Restricted Login	Modify	Delete
1	admin	admin	admin 's account	I	2	•
2	admin1	admin		Q	1	-
Authority						
Authority User	Live	Playback	System	System Info		
-	Live File Backup	Playback Storage	System Event	System Info Network		

Step 2 Click Add User.



Add	d User			×
	Username Password		Must	
		The minimum pass phra	se length is 8	
		characters		
		Weak Middle Stro	ng	
	Confirm Password			
	Group Name	admin		
	Memo			
	Operation Permiss	ion Restricte	d Login	
	All			
	Vser			
	Live			
	Playback			
	System			
	System InfoManual Control			
	File Backup		E	
	Storage			
	Event			
	Vetwork			
	Peripheral			
	AV Parameter			
	PTZ			
	Security			
	Maintenance			
				-
		[Save Cancel	
		L		

	Must	
Password		
	The minimum pass phrase length is 8	
	characters	
Confirm Password	Weak Middle Strong	
Group Name	admin	
Memo		
Operation Permis	sion Restricted Login	
IP Addr	255	
IPv4	▼ IP Address ▼ 1 . 0 . 0 . 1	
Validity		
Begin Ti		
End Tim	e 2019-07-19 💽 08 : 00 : 00	
Time R		
0	0 2 4 6 8 10 12 14 16 18 20 22 24	
Sun		Setting
Mon 		Setting
Tue		Setting
Wed		Setting
Thu		Setting
		Setting
Fri		Setting
Fri Sat		Setting

Figure 4-97 Add user (restricted login)

<u>Step 3</u> Configure user parameters.

Table 4-37 Description of user parameters (1)

Parameter	Description	
Username	User's unique identification. You cannot use existed user name.	
Password	Enter password and confirm it again.	
Confirm Password	The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' "; : &).	
Group Name	The group that users belong to. Each group has different authorities.	
Memo	Describe the user.	
Operation Permission	Select authorities as needed. You are recommended giving fewer authorities to normal users than premium users.	

Parameter	Description
Restricted Login	 Set the PC address that allows the defined user to log in to the camera and the validity period and time range. You can log in to web with the defined IP in the defined time range of validity period. IP address: You can log in to web through the PC with the set IP. Validity period: You can log in to web in the set validity period. Time Range: You can log in to web in the set time range. Set as following: Select IP Address: Select IP type and set IP address. IP Address: Enter the IP address of the host to be added. IP segment: Enter the start address and end address of the host to be added. Select Validity Period: Set the begin time and end time. Select Time Range: Set the time range that allow user to log in. For details, see "5.1.1.1 Setting Period".

Step 4 Click Save.

The newly added user is displayed in the user name list.

- \square
- After adding user, click to modify password, group, memo or authorities; click
 to delete the added users. Admin user cannot be deleted.
- Click 🛃 in the **admin** row to modify its username and email address.

4.8.4.2 Adding User Group

You have two groups named admin and user by default, and you can add new group, delete added group or modify group authority and memo.

<u>Step 1</u> Select Setting > System > Account > Account > Group Name.

Figure 4-98 Group name

Username	Group Name					
No.	Group Name		Memo		Modify	Delete
1	admin		administrator group		2	•
2	user		user group		2	•
Authority						
Authority User	Live	Playback	System	System Info		
	Live File Backup	Playback Storage	System Event	System Info Network		

Step 2 Click Add Group.

Figure 4-99 Add group

Add Group			X
Group Name Memo Authority	All Live	Must	
	 Playback System System Info Save Cancel 	-	

<u>Step 3</u> Enter the group name and memo, and then select group authorities.

<u>Step 4</u> Click **Save** to finish configuration.

The newly added group displays in the group name list.

- \square
- After adding group, click ... to modify group memo or authorities; click \bigcirc to delete the added group, admin group and user group cannot be deleted.
- Click 🛃 in the row of admin group or user group to modify group memo.

4.8.4.3 ONVIF User

You can add, delete ONVIF user, and modify their passwords.

<u>Step 1</u> Select Setting > System > Account > ONVIF User.

		Figure	4-100 ON	VIF user			
Account	Onvif User						
No.		Username		Group Name	Modify	Delete	
1		admin		admin	2	•	
Add User	7						

Step 2 Click Add User.

F	Figure 4-101 Add user	
Add User		×
Username	Must	
Password		
	The minimum pass phrase length is 8	
	characters	
	Weak Middle Strong	
Confirm Password		
Group Name	admin 💌	
	Save Cancel	

<u>Step 3</u> Configure user parameters.

Table 4-38 Description of u	user parameters (2)
-----------------------------	---------------------

Parameter	Description
	Description
Username	User's unique identification. You cannot use existed user name.
Password	Enter password and confirm it again.
Confirm Password	The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' "; : &).
Group Name	The group that users belong to. Each group has different authorities.

Step 4 Click Save.

The newly added user displays in the user name list.

 \square

- After adding user, click to modify password, group, memo or authorities; click
 to delete the added user. Admin user cannot be deleted.
- Click 🥂 in the **admin** row to modify its username and email address.

4.8.5 Safety

You can configure system service, HTTPS, and Firewall.

4.8.5.1 System Service

Configure the IP hosts (devices with IP address) that are allowed to visit the device. Only the hosts in the trusted sites list can log in to the web interface. This is to enhance network and data security.

<u>Step 1</u> Select Setting > System > Safety > System Service.

Figure 4-102 System service				
System Service	HTTPS	Firewall		
SSH	Enable			
Multicast/Broadcast.	🗸 Enable			
Password Reset	Enable			
CGI Service	Enable			
Onvif Service	Enable			
Genetec Service	Enable			
Audio and Video Tr	. 🔲 Enable	*Please make sure matched device or software supports video decryption function.		
Mobile Push	Enable			
Default	Defeat	0		
Default	Refresh	Save		

Figure 4-102 System service

<u>Step 2</u> Enable the system service according to the actual needs.

Table 4-39 Description of system service parameters

Function	Description	
SSH	You can enable SSH authentication to perform safety management.	
Multicast/Broadcast Search	Enable this function, and then when multiple users are previewing the device video image simultaneously through network, they can find your device with multicast/broadcast protocol.	
Password Reset	Manage system security with this function.	
CGI Service	Enable this function, and then other devices can access through this service.	

Function	Description	
Onvif Service	Enable this function, and then other devices can access through this service.	
Genetec Service	Enable this function, and then other devices can access through this service.	
Audio and Video	Enable to encrypt audio/video transmission.	
Transmission Encryption	Make sure that the other devices and software that working together with the camera support video decryption.	
Mobile Push	Enable this function, and then the system would send the snapshot that was taken when alarm is triggered to your phone, this is enabled by default.	

Step 3 Click Save.

4.8.5.2 HTTPS

Create a certificate or upload an authenticated certificate, and then you can log in through HTTPS with your PC. The HTTPS can protect page authenticity on all types of websites, secure accounts, and keep user communications, identity, and web browsing private.

Procedure

<u>Step 1</u> Select **Setting > Network > HTTPS**.

Figure 4-103 HTTPS (1)							
System Service	HTTPS	Firewall					
Enable HTTPS							
Protocol Version							
Enable TLSv1.0							
Create Certificate							
Create							
Request Created							
Request Created				Delete	Install	Download	
Install Signed Certific	ate						
Certificate Path				Browse			
Certificate Key Path				Browse	Upload		
Certificate Installed							
Certificate Installed				Delete			
Attribute							
	Refresh	Save					

<u>Step 2</u> Create a certificate or upload an authenticated certificate.

• For creating a certificate, click **Create**.

Figure 4-104 HTTPS dialog box			
HTTPS		×	
Country		*e.g. CN	
IP or Domain name		*	
Validity Period	365	Day*Range :1-5000	
Province	none]	
Location	none]	
Organization	none		
Organization Unit	none		
Email]	
	Create Ca	ncel	

- For uploading the authenticated certificate, click **Browse** to select the certificate and certificate key, click **Upload** to upload them, and then skip to <u>Step5</u>.
- <u>Step 3</u> Enter the required information and then click **Create**.

The entered **IP or Domain name** must be the same as the IP or domain name of the device.

Step 4 Click Install.

Figure 4-105 Certificate installation

HTTPS			
Enable HTTPS			
Create Certificate			
Create			
Request Created			
Request Created	H/IP=http://172.12.80.250/;C=CN;ST=none;L=none;	Delete	Install Download
Install Signed Certifica	te		
Certificate Path		Browse]
Certificate Key Path		Browse	Upload
		Browse	opieza
Certificate Installed			
Certificate Installed		Delete	
Attribute			-
	Refresh Save		

<u>Step 5</u> Click **Download** to download root certificate.

Step 6 Click Download Root Certificate.

Figure 4-106 File download

File Dov	vnload - Security Warning 🛛 🔀
Do you	u want to open or save this file?
	Name: ca.crt Type: Security Certificate From: 10.10.6.238
	Open Save Cancel
۲	While files from the Internet can be useful, this file type can potentially harm your computer. If you do not trust the source, do not open or save this software. <u>What's the risk?</u>

Step 7 Click **Open**.

Figure 4-107 Certificate information

Certificate ? 🔀			
General Details Certification Path			
Certificate Information			
This CA Root certificate is not trusted. To enable trust, install this certificate in the Trusted Root Certification Authorities store.			
Issued to: Product Root CA			
Issued by: Product Root CA			
Valid from 2013-6-18 to 2023-6-16			
Install Certificate Issuer Statement			
ОК			

Step 8 Click Install Certificate.



Figure 4-108 Certificate import wizard (1)

Step 9 Click Next.

Figure 4-109 Certificate Store

Certificate Import Wizard	X
Certificate Store Certificate stores are system areas where certificates are kept.	
Windows can automatically select a certificate store, or you can specify a location for	
Automatically select the certificate store based on the type of certificate	
OPlace all certificates in the following store	
Certificate store:	
Browse	
< <u>B</u> ack <u>N</u> ext > Cance	

<u>Step 10</u> Select the storage location and click **Next**.

Certificate Import Wizard		X
	Completing the Certificate Import Wizard	
	You have successfully completed the Certificate Import wizard.	
	You have specified the following settings:	
	Certificate Store Selected Automatically determined by t Content Certificate	
	<	
		1
	< <u>B</u> ack Finish Cancel	

Figure 4-110 Certificate import wizard (2)




Figure 4-111 Import succeeds

Certific	ate Import Wizard 🛛 🔀
(į)	The import was successful.
	ОК

4.8.5.3 Firewall

Configure **Network Access**, **PING prohibited** and **Prevent Semijoin** to enhance network and data security.

- Network Access: Set trusted list and restricted list to limit access.
 - Trust list: Only when the IP/MAC of your PC in the trusted list, can you access the camera. Ports are the same.
 - ◊ Banned list: When the IP/MAC of your PC is in the banned list, you cannot access the camera. Ports are the same.
- **PING prohibited**: Enable **PING prohibited** function, and the camera will not respond to the ping request.
- **Prevent Semijoin**: Enable **Prevent Semijoin** function, and the camera can provide service normally under Semijoin attack.

\square

- You cannot set trust or banned list for camera IP or MAC addresses.
- You cannot set trust or banned list for port MAC addresses.
- When the IP addresses of the camera and your PC are in the same LAN, MAC verification takes effect.
- When you access the camera through internet, the camera verifies the MAC address according to the router MAC.

This section takes **Network Access** as an example.

<u>Step 1</u> Select Setting > System > Safety > Firewall.

System Service	HTTPS Firewall			
Rule Type	Network Access			
Enable	V			
Mode	● TrustList 〇 BannedList			
Only the listed If	addresses/MAC are allowed to visit corresponding ports	of the device.		
	IP address /MAC address	Port	Modify	Delete
\checkmark	Reput that	Device All Ports	1	•
	NO. 10 1.00	Device All Ports	1	•
V	45263.86	Device All Ports	1	•
	1000000	Device All Ports	1	•
Add IP/MAC				
//dd ii /iii//O				
Default	Refresh Save			

- <u>Step 2</u> Select **Network Access** from **Rule Type** list, and then select the **Enable** check box.
 - Enable **PING prohibited** and **Prevent Semijoin**, and click **Save**. You do not need to configure parameters.
 - Enable Network Access, and configure trust list and banned list.
 - Select the mode: **TrustList** and **BannedList**.
 - Click Add IP/MAC.

Figure 4-113 A	dd IP/MAC
Add IP/MAC	×
Rule Type	IP Address
IP Version	IPv4
IP Address	1
Device All Ports	
Device Start Server	1
Device End Server	1
ОК	Cancel

<u>Step 3</u> Configure parameters.

Table 4-40 Description of adding IP/MAC parameters

Parameter	Description	
Rule Type	 Select IP address, IP segment, MAC address or all IP addresses. IP address: Select IP version and enter the IP address of the host to be added. IP segment: Select IP version and enter the start address and end address of the segment to be added. MAC address: Enter MAC address of the host to be added. All IP addresses: Set all IP addresses in trusted list or restricted list. 	
Device All Ports	Set access ports. You can select all ports or the ports in defined	
Device Start Server Port	 areas. Device all ports: Set all IP port in trust list or Banned list. Wh 	
Device End Server Port	 selecting BannedList in Mode, and All IP Address in Rule Type, you cannot select the Device All Ports check box. Device start server port and Device end server port: Set Device start server port and device end server port, and the range is 1– 65535. 	

Step 4 Click **OK**, and the **Firewall** interface is displayed.

Step 5 Click Save.

4.8.6 Peripheral

4.8.6.1 Serial Port Settings

Set the serial port of the external device.

<u>Step 1</u> Select Setting > System > Peripheral > Serial Port Setting.

Fi	gure 4-114 Serial p	port settings	
Serial Port Settings	External Light	Wiper	
Address	1		
Baud Rate	9600	-	
Data Bit	8	•	
Stop Bit	1	•	
Parity	NONE	-	
	Default	Refresh	Save

<u>Step 2</u> Configure serial port settings parameters.

Table 4-41 Description of serial port settings parameters

Parameter	Description
Address	The corresponding device address. It is 1 by default. Make sure that the address is the device address; otherwise you cannot control the device.
Baud Rate	Select the baud rate for the camera. It is 9600 by default.
Date Bit	It is 8 by default.
Stop Bit	It is 1 by default.
Parity	It is None by default.

Step 3 Click Save.

4.8.6.2 External Light

You need to configure external light mode when the external light is used.

Prerequisites

- Connect external light with RS-485 port.
- You have configured serial port parameters. For details, see "4.8.6.1 Serial Port Settings".

Procedure

<u>Step 1</u> Select Setting > System > Peripheral > External Light.

	Figure 4-11	5 External Lig	ht		
Serial Port Settings	xternal Light Wiper				
		2000-01-01 03.45.55	Work Mode Auto Mode Light Brightness Period setting	Auto Time O	▼ ▼ + 128
IPC					
Default	Refresh Save]			

<u>Step 2</u> Configure external light work mode.

Description
Off: Turn off the external light.
 Manual: Set the light brightness manually.
 Auto: The camera turns on or turns off the light according to the light time and photoresister automatically.
 Time: When selecting Time in Auto Mode, click Setting to set the arming period. During the arming period, the external light is on. For details of arming period setting, see "5.1.1.1 Setting Period". Photoresister: When you select Photoresister in Auto Mode,
the system turns on the external light according to the brightness automatically.
Set the brightness of the external light.

Step 3 Click Save.

4.8.6.3 Wiper

<u>Step 1</u> Select Setting > System > Peripheral > Peripheral > Wiper.

		Figure 4-116 Wip	er
Serial Port Settings	External Light	Wiper	
		2000-01-01 03.59.58	Wiper Interval Time 10 s (0~255) Start Stop Once
IPC			Wash Time Wash Everyday O4 : 00 Once
Default	Refresh	Save	

<u>Step 2</u> Configure wiper work mode.

Table 4-43 Description of wiper parameters
--

Parameter	Description
Interval Time	The interval time between stop mode and start mode. For example, set the time to10 s, and the wiper will work every 10 s.
Start	Set the work status of the wiper.
Stop	• Start: Click Start , and the wiper works as the set interval time.
Once	 Stop: Click Stop, and the wiper stops working. Once: Click Once, and the wiper works once.
Time Wash	Select the Time Wash check box and set the time, and then the wiper will work as the set time. Click Once , and the wiper works once. It can be used to check whether the wiper can work normally.

Step 3 Click Save.

5 Event

This chapter introduces intelligent event settings, including smart track, panoramic calibration, video detection, audio detection, smart plan, IVS, face detection, face recognition, people counting, heat map, video Metadata, alarm, and abnormality.

5.1 Setting Alarm Linkage

5.1.1 Alarm Linkage

When configuring alarm events, select alarm linkages (such as record, snapshot). See Figure 5-1. When the corresponding alarm is triggered in the configured arming period, the system will alarm.

	r igaro o r / iarri initago
Period	Setting
Anti-Dither	0 s (0~100) Sensor Type NO 💌
Record	
Record Delay	10 s (10~300)
Relay-out	
Alarm Delay	10 s (10~300)
📄 Send Email	
PTZ	
Snapshot	
	Default Refresh Save

Figure 5-1 Alarm linkage

5.1.1.1 Setting Period

Set arming periods. The system only performs corresponding linkage action in the configured period.

<u>Step 1</u> Click **Setting** next to **Period**.




Figure 5-2 Period

- <u>Step 2</u> Set arming periods. Alarms will be triggered in the time period in green on the timeline.
 - Method one: Directly press and drag the left mouse button on the timeline.
 - Method two: Enter an actual time period.
 - 1. Click Setting next to a day.
 - 2. Select a time period to be enabled.
 - 3. Enter start time and end time of a time period.

\square

- Select All or check boxes of some days to set the time period of multiple days at one time.
- You can set 6 time periods per day.

Step 3 Click Save.

5.1.1.2 Record Linkage


The system can link record channel when an alarm event occurs. After alarm, the system stops recording after an extended time period according to the **Record Delay** setting.


To use the record linkage function, set record plan for motion detection alarm and enable auto recording in record control.

5.1.1.2.1 Setting Record Plan

After the corresponding alarm type (**Normal**, **Motion**, and **Alarm**) is enabled, the record channel links recording.

<u>Step 1</u> Select Setting > Storage > Schedule > Record.





<u>Step 2</u> Set record plan.

Green represents normal record plan (such as timing recording); yellow represents motion record plan (such as recording triggered by intelligent events); red represents alarm record plan (such as recording triggered by alarm-in).

- Method one: Select a record type, such as **Normal**, and directly press and drag the left mouse button to set the time period for normal record on the timeline.
- Method two: Enter an actual time period.
 - 1. Click **Setting** next to a day.

🔲 All	Sun Mon Tue Wed Thu Fri Sat Holiday	
Period1	00 : 00 : 00 - 23 : 59 : 59 Mormal 🗸 Motion 🗸 Alarm	
Period2	00 : 00 : 00 - 23 : 59 : 59 Mormal Motion Alarm	
Period3	00 : 00 : 00 - 23 : 59 : 59 Mormal Motion Alarm	
Period4	00 : 00 : 00 - 23 : 59 : 59 Mormal Motion Alarm	
Period5	00 : 00 : 00 - 23 : 59 : 59 Mormal Motion Alarm	
Period6	00 : 00 : 00 - 23 : 59 : 59 🔲 Normal 🦳 Motion 🖳 Alarm	

2. Select a day, and the alarm type next to a period, and then set the period.

 \square

- Select All or check boxes of some days to set the time period of multiple days at one time.
- You can set 6 time periods per day.

Step 3 Click Save.

5.1.1.2.2 Setting Record Control

Set parameters such as pack duration, pre-event record, disk full, record mode, and record stream.

\square

Make sure that the SD card is authenticated before recording if you use a smart card. For details, see "4.5.2.5 Path".

<u>Step 1</u> Select Setting > Storage > Record Control.

Figure 5-5 Record control

Record Control	
Pack Duration	8 Min. (1~120)
Pre-event Record	5 s (0~5)
Disk Full	Overwrite
Record Mode	● Auto 🔿 Manual 🔿 Off
Record Stream	Main Stream
	Default Refresh Save

<u>Step 2</u> Set parameters.

TILLEAD		1	
Table 5-1 Descri	ption of record	d control	parameters

Parameter	Description
Pack Duration	The time for packing each video file.
Pre-event Record	The time to record the video in advance of a triggered alarm event. For example, if the pre-event record is set to be 5 s, the system saves the recorded video of 5 s before the alarm is triggered.
	When an alarm or motion detection links recording, and the recording is not enabled, the system saves the video data within the pre-event record time to the video file.
	Recording strategy when the disk is full.
Disk Full	 Stop: Stop recording when the disk is full. Overwrite: Cyclically overwrite the earliest video when the disk is full.
Record Mode	When you select Manual , the system starts recording; when you select Auto , the system starts recording in the configured time period of record plan.
Record Stream	Select record stream, including Main Stream and Sub Stream.

Step 3 Click Save.

5.1.1.2.3 Setting Record Linkage

On the alarm event setting interface (such as the motion detection interface), select **Record** and set **Record Delay** to set alarm linkage and record delay.

After **Record Delay** is configured, alarm recording continues for an extended period after the alarm ends.

Figure 5-6 Re	cord linkage	
Record		
Record Delay	10	s (10~300)

5.1.1.3 Snapshot Linkage


After snapshot linkage is configured, the system can automatically alarm and take snapshots when an alarm is triggered.

After **Motion** is enabled in **Snapshot**, the system takes snapshots when an alarm is triggered. For querying and setting snapshot storage location, see "4.5.2.5 Path".

5.1.1.3.1 Setting Snapshot Plan

According to the configured snapshot plan, the system enables or disables snapshot at corresponding time.

<u>Step 1</u> Select Setting > Storage > Schedule > Snapshot.



<u>Step 2</u> Select snapshot type and set time period.

Green represents normal snapshot plan (such as timing snapshot); yellow represents motion snapshot plan (such as snapshot triggered by intelligent events); red represents alarm snapshot plan (such as snapshot triggered by alarm-in).

- Method one: Select snapshot type, such as **Normal**, and directly press and drag the left mouse button to set time period for normal snapshot on the timeline.
- Method two: Enter an actual time period.
 - 1. Click **Setting** next to a day.

Figure 5-8 Setting (snapshot time period)

🗖 All	🗸 Sun	Mon 📃	🗖 Tue 📄 Wed 📄 Thu 📄 Fri 📄 Sat 📄 Holiday	
Period1	00 : 00	: 00 -	- 23 : 59 : 59 🕅 Normal 🗸 Motion 🗸 Alarm	
Period2	00 : 00	: 00 -	- 23 : 59 : 59 Normal Motion Alarm	
Period3	00 : 00	: 00 -	- 23 : 59 : 59 Normal Motion Alarm	
Period4	00 : 00	: 00 -	- 23 : 59 : 59 Normal Motion Alarm	
Period5	00 : 00	: 00 -	- 23 : 59 : 59 Normal Motion Alarm	
Period6	00 : 00	: 00 -	- 23 : 59 : 59 Normal Motion Alarm	

- 2. Select a day, and the alarm type next to a period. Then set the period.
 - Ш
 - Select All or check boxes of some days to set the time period of multiple days at one time.
 - ◊ You can set 6 time periods per day.
- 3. You can set 6 time periods per day.
 - The **Snapshot** interface is displayed.

Step 3 Click Save.

5.1.1.3.2 Setting Snapshot Linkage

On the alarm event setting interface (such as the motion detection interface), select **Snapshot** and set alarm linkage snapshot.

Figure 5-9 Snapshot linkage

Snapshot

5.1.1.4 Relay-out Linkage

When an alarm is triggered, the system can automatically link with relay-out device.

On the alarm event setting interface (such as the motion detection interface), select **Alarm** and set **Alarm Delay**.

When alarm delay is configured, alarm continues for an extended period after the alarm ends.

Figure 5-10 Relay-out linkage

Relay-out		
Alarm Delay	10	s (10~300)

5.1.1.5 Email Linkage

When an alarm is triggered, the system will automatically send an email to users. Email linkage takes effect only when SMTP is configured. For details, see "4.6.5 SMTP (Email)".

C Oracl Errell	Figure 5-11 Email linkage
Send Email	Send Email

5.1.1.6 PTZ Linkage

When an alarm is triggered, the system links PTZ to do some operations. For example, the system links PTZ to rotate to the preset X.

	Figure 5-12 PTZ	linkage		
V PTZ	Activation Preset	▼ No.	1	(1~255)

5.1.1.7 White Light Linkage


When an alarm is triggered, the system can automatically enable the white light. Set **Mode**, **Flicker Frequency**, **Duration**, and **Period**.

- **Mode**: The display mode of the white light when an alarm is triggered. It includes **Normally on** and **Flicker**. When set flicker as the mode, you need to set the flicker frequency.
- **Duration**: After setting white light duration, the white light is turned off after an extended time of period after an alarm. It is 5 seconds–30 seconds.
- **Period**: The period for using white light. When an alarm triggered during the configured period, the system links white light. For the configuration, see "5.1.1.1 Setting Period".

i igai e e	ie inne igni innege
Vhite Light	
Mode	Flicker 💌
Flicker Frequ	Medium 💌
Duration	10 s (5~30)
Period	Setting

5.1.1.8 Audio Linkage

The system broadcasts alarm audio file when an alarm event occurs. Select **Setting > Camera > Audio > Alarm Audio** to set alarm audio file.



5.1.2 Subscribing Alarm

5.1.2.1 About Alarm Types

For alarm types and preparations of alarm events, see Table 5-2.

Figure 5-13 White light linkage

Alarm Type	Description	Preparation	
Motion Detection	The alarm is triggered when moving object is detected.	Motion detection is enabled. For details, see "5.4.1 Setting Motion Detection".	
Disk Full	The alarm is triggered when the free space of SD card is less than the configured value.	The SD card no space function is enabled. For details, see "5.19.1 Setting SD Card".	
Disk Error	The alarm is triggered when there is failure or malfunction in the SD card.	SD card failure detection is enabled. For details, see "5.19.1 Setting SD Card".	
Video Tampering	The alarm is triggered when the camera lens is covered or there is defocus in video images.	Video tampering is enabled. For details, see "5.4.2 Setting Video Tamper".	
External Alarm	The alarm is triggered when there is external alarm input.	The device has alarm input port and external alarm function is enabled. For details, see "5.18 Setting Relay-in".	
Illegal Access	The alarm is triggered when the number of consecutive login password error is up to the allowable number.	Illegal access detection is enabled. For details, see "5.19.3 Setting Illegal Access".	
Audio Detection	The alarm is triggered when there is audio connection problem.	Abnormal audio detection is enabled. For details, see "5.6 Setting Audio Detection".	
IVS	The alarm is triggered when intelligent rule is triggered.	Enable IVS, crowd map, face detection or people counting, and other intelligent functions.	
Scene Changing	The alarm is triggered when the device monitoring scene changes.	Scene changing detection is enabled. For details, see "5.4.3 Setting Scene Changing".	
Voltage Detection	The alarm is triggered when the device detects abnormal voltage input.	Voltage detection is enabled. For details, see "5.19.4 Setting Voltage Detection".	
Security Exception	The alarm is triggered when the device detects malicious attack.	Voltage detection is enabled. For details, see "5.19.5 Setting Security Exception".	

Table 5-2 Description of alarm types

5.1.2.2 Subscribing Alarm Information

You can subscribe alarm event. When a subscribed alarm event is triggered, the system records detailed alarm information at the right side of the interface.

 \square

Functions of different devices might vary, and the actual product shall prevail. <u>Step 1</u> Click the **Alarm** tab.

Figure 5-15 Alarm (subscription)

Alarm Type		No.	Time	Alarm Type	Source IP	Alarm Channel
Motion Detection	Disk Full					
Disk Error	Video Tampering					
External Alarm	Illegal Access					
Audio Detection	IVS					
Scene Changing	Security Exception					
Operation						
Prompt						
Alarm Tone						
Play Alarm Tone						
Tone Path	Browse					

<u>Step 2</u> Select **Alarm Type** according to the actual need.

- Select **Prompt**. The system prompts and records alarm information according to actual conditions.
 - When the subscribed alarm event is triggered and the Alarm interface is not displayed, the <a>is displayed on the Alarm tab and the alarm information is recorded automatically. Click the Alarm tab, and this icon disappears.
 - When the subscribed alarm event is triggered and the Alarm interface is displayed, the corresponding alarm information is displayed in the alarm list at the right side of the Alarm interface.
- Select Play Alarm Tone, and select the tone path.
 The system would play the selected audio file when the selected alarm is triggered.

5.2 Setting Smart Track

After setting calibration and parameters for smart track, the tracking speed dome can automatically link to a corresponding position and tracks an object till it is out of the object is beyond the monitoring range or the set tracking time is reached when the intelligent rules for panoramic camera triggers an alarm.

5.2.1 Setting Calibration Parameters for Smart Track

The camera has calibration parameters by default, and you can modify the parameters manually when the effect is not good with default setting.

<u>Step 1</u> Select Setting > Event > Smart Track > Smart Track.

Figure 5-16 Smart track

Smart Track	Alam Trad						10 11 42 42		
1 Number F	2 3	A (Zoom (+) Focus (+) Iris (+) 5 (*)	Delete	P'49	8739522		
1	1683,3059	4863, 1693	1374,311,7	6	•				
2	1849,4062	5299,3879	1374,311,7	la l	•				
3	1429,2558	4039,473	1374,311,7		•				
4	1453,3159	4071,1851	1374,311,7	lei	•				
Default	Refresh	Save							

<u>Step 2</u> Select scene number under the video images in turns (See Figure 5-17) to add calibration points on the video images of the corresponding scene. Scene numbers 1 to 4 are four splitting scenes of spliced image, and at least add four calibration points on each scene.



1	2	3	4
---	---	---	---

Add calibration points according to the following procedure.

- 1) Adjust the video image of the speed dome to a position aligned with the panoramic image, and then click 🔂.
- 2) Calibration box is displayed in the images of speed dome and panoramic camera.
- 3) Drag the calibration box to a proper position, and click 🖬 to save one pair of calibration boxes.
- 4) After the calibration record is saved, the calibration box is displayed in yellow.

```
Step 3 Click Save.
```

5.2.2 Enabling Alarm Track

Alarm Track is disabled by default. Smart Track is enabled only after Alarm Track is enabled and intelligent rules of the panoramic camera. **Smart Track** is supported only when rules of crowd map, intrusion and tripwire are triggered. See "5.8 Setting IVS" and "5.9 Setting Crowd Map".

<u>Step 1</u> Select Setting > Event > Smart Track > Alarm Track.

Figure 5-18 Alarm track					
Smart Track	Alarm Track				
Enable					
Auto Track	● On ○ Off				
Track Time	Continue till object disa				
Idle Time	5 s	(1~1800)			
Idle Position	Preset1 -				
Default	Refresh Save				

- <u>Step 2</u> Select the **Enable** check box to enable track linkage. After enabling the function, manual positioning, manual tacking and auto tracking takes effect.
- Step 3 Set parameters.

Table 5-3 Description	of alarm track parameters
rubio o o booonpiion	or alarm traok paramotoro

Parameter	Description
Auto Track	Select On , the speed dome would automatically links to a corresponding position and tracks an object when the intelligent rules of the panoramic camera trigger alarms.
Track Time	 Set the alarm track time. Before an object disappears: The speed dome would automatically links to a corresponding position and tracks an object until the object moves out of the monitoring range when the intelligent rules of the panoramic camera trigger alarms. Custom: Set the auto alarm track time of the speed dome.
Idle Time	It is an interval from the end of alarm track of the speed dome to the start of idle mode.
Idle Position	Set Idle Time and Idle Position . If no event needs to be tracked after the configured idle time, the device automatically rotates to the set idle position. For example, the Idle Time is set to be five seconds and the Idle Position is set to be preset point 1. When the speed dome does not start tracking after five seconds, it automatically rotates to preset point 1. To set Idle Position , first set a preset point. For preset point, see
Stop 4 Click Save	"4.3.2.1 Preset".

Step 4 Click Save.

5.3 Setting Panoramic Calibration

The device has calibration parameters by default, and you can modify the parameters manually when the effect is not good with default setting. Before manually calibrating a channel, clear all

default calibration parameters.

Channel 1 is a PTZ camera. You should calibrate the scene coordinates of **Channel 1** and other channels. Take **Channel 2** as an example.

<u>Step 1</u> Select **Setting > Event > Panoramic Calibration**.

Panoramic Calibration 1154.17 Please adjust the PTZ angle of channel PTZ control interface make the center point of channel 1 basically concide with the green point of calibration 1 or calib 2 screen, then it is to make calibration — Zoom (+) Calibrate1 Calibrate2 Speed 5 V 2 Channel * 1085.2895 2446.3931 1328.311.0 H 2 1108.6328 3676.7643 1328.311.0 H 2775 931 3 2020 1219 1328 311 0 Ы 4 2459,7205 5574,7301 1328.311.0 H 0 Default Refresh

Figure 5-19 Panoramic calibration

<u>Step 2</u> Select channel 2, and then select a calibration number under the video images in turns (See Figure 5-20) to add calibration points to the corresponding video images. Take **Calibrate 1** as an example.

Figure 5-20 Selecting a calibration number



1) Adjust the PTZ angle of channel 1 through the PTZ control interface to rotate the center of channel 1 to a position aligned with the green point in **Calibrate 1** image, and then click .

Calibration box is displayed in images of Channel 1 and Calibrate 1

 Respectively drag calibration boxes on images of Channel 1 and Calibrate 1 to the corresponding positions. Click limet to save this pair of calibration boxes.

You are recommended to drag calibration box to a static position with clear edges in the image. This can ensure the edges can be accurately distinguished by the camera. After the calibration record is saved, the calibration box is displayed in yellow.

Repeat <u>1</u>) to <u>2</u>) to add at least 4 pairs of calibration points to each calibration picture. <u>Step 3</u> Click **Save**.

5.4 Setting Video Detection

Check whether there are considerable changes on the video by analyzing video images. In case of any considerable change on the video (such as moving object, fuzzy image), the system performs an alarm linkage.

5.4.1 Setting Motion Detection

The system performs an alarm linkage when the moving object appears on the image and its moving speed reaches the preset sensitivity.

 \square

- If you enable motion detection and smart motion detection simultaneously, and configure the linked activities, the linked activities take effect as following:
 - When Motion Detection is triggered, the camera will record and take snapshots, but other configured linkages such as sending emails, PTZ operation will not take effect.
 - ◇ When Smart Motion Detection is triggered, all the configured linkages take effect.
- If you only enable motion detection, all the configured linkages take effect when motion detection is triggered.

<u>Step 1</u> Select Setting > Event > Video Detection > Motion Detection.


Figure 5-21 Motion detection					
Motion Detection	on Video	Tampering	Scene Changing		
🗌 Enable	-				
Working P	eriod	Setup			
Anti-Dither		5	Second (0~100)		
Area	[Setup			
Record					
Record De	lay	10	Second (10~300)		
Relay-out					
Alarm Dela	ay	10	Second (10~300)		
📃 Send Ema	il				
🔲 Snapshot					
Default		Refresh	Save		

<u>Step 2</u> Select the **Enable** check box to enable motion detection function.

<u>Step 3</u> Set the area for motion detection.

1) Click Setup next to Area.

Figure 5-22 Area



- 2) Select a color and set the region name. Select an effective area for Motion Detection in the image and set **Sensitivity** and **Threshold**.
 - Select a color on
 Select a color
 Select a color on
 Select a color on

parameters for each region.

- Sensitivity: Sensitive degree of outside changes. It is easier to trigger the alarm with higher sensitivity.
- Threshold: Effective area threshold for Motion Detection. The smaller the threshold is, the easier the alarm is triggered.
- The whole video image is the effective area for Motion Detection by default.
- The red line in the waveform indicates that the Motion Detection is triggered, and the green one indicates that there is no motion detection. Adjust sensitivity and threshold according to the waveform.
- 3) Click Save.
- <u>Step 4</u> Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage". Anti-dither: After the **Anti-dither** time is set, the system only records one motion detection event in the period.
- Step 5 Click Save.

5.4.2 Setting Video Tamper

The system performs alarm linkage when the lens is covered or video output is mono-color screen caused by light and other reasons.

<u>Step 1</u> Select Setting > Event > Video Detection > Video Tamper.

Figu	re 5-23 Video tar	mpering
Motion Detection Vide	eo Tampering	g Scene Changing
🔲 Enable Video Tam	pering 🔲	Enable Defocus Detection
Working Period	Setup]
Record		
Record Delay	10	Second (10~300)
Relay-out		
Alarm Delay	10	Second (10~300)
🔲 Send Email		
🔲 Snapshot		
Default	Refresh	Save

- Step 2Select the Enable Video Tampering check box, and set arming periods and alarm
linkage action. For details, see "5.1.1 Alarm Linkage".
Select the Enable Defocus Detection check box: The alarm is triggered when the
image is fuzzy. This function is available on some select models.
- Step 3 Click Save.

5.4.3 Setting Scene Changing

The system performs alarm linkage when the image switches from the current scene to another one.

<u>Step 1</u> Select Setting > Event > Video Detection > Scene Changing.

	-		
Enabl	e		
Workin	ng Period	Setup	
Recor	d		
Recor	d Delay	10	Second (10~300)
Relay-	out		
Alarm	Delay	10	Second (10~300)
Send I	Email		
Snaps	hot		
Def	ault	Refresh	Save

5.5 Setting Smart Motion Detection

Step 3 Click Save.

The system performs alarm linkage when human, non-motorized vehicle, or motor vehicle appear on the image and its moving speed reaches the preset sensitivity. Enabling smart motion detection can avoid the alarms triggered by the environment changes, and the function is enabled by default.

Prerequisites

- Select Setting > Event > Video Detection > Motion Detection to enable the motion detection function.
- You have set **Period** and **Area** in **Motion Detection**, and make sure that the sensitivity value is larger than 0, and the threshold value is smaller than 100.

Procedure

<u>Step 1</u> Select Setting > Event > Smart Motion Detection.

Figure 5-25 Smart motion detection

Smar	t Motion Detection		
[Enable		
	Effective object	Human Motor Ver	icle
	Sensitivity	Middle	
		Default Refresh	Save

<u>Step 2</u> Select the **Enable** check box to enable the smart motion detection function.

- Step 3 Set effective object and sensitivity.
 - Effective object: Includes **Human** and **Motor vehicle**. When you select **Human**, the camera will detect human and non-motorized vehicle.
 - Sensitivity: Includes Low, Middle, and High. The higher the sensitivity is, the easier the alarm will be triggered.
- Step 4 Click OK.

5.6 Setting Audio Detection

The system performs alarm linkage when vague voice, tone change, or sound intensity rapid change is detected.

<u>Step 1</u> Select Setting > Event > Audio Detection.

Figu	re 5-26 Audio	detection		
dio Detection				
Enable Input Abno	rmal			
Enable Intensity C	hange			
Sensitivity	Ξ	-0	 50	
Threshold	Ξ	-0	+ 50	
han a share a same become				
Working Period	Setup			
Anti-Dither	5	Sec	cond (0~100)	
Record				
Record Delay	10	Sec	cond (10~300)	
🔽 Relay-out				
Alarm Delay	10	Sec	cond (10~300)	
🔲 Send Email				
🔲 Snapshot				
Default	Refresh		Save	

Step 2 Set parameters.

- Input abnormal: Select the **Enable Input Abnormal** check box, and the alarm is triggered when the system detects abnormal sound input.
- Intensity change: Select the **Enable Intensity Change** check box and then set **Sensitivity** and **Threshold**. The alarm is triggered when the system detects that the sound intensity exceeds the set threshold.
 - It is easier to trigger the alarm with higher sensitivity or smaller threshold. Set a

high threshold for noisy environment.

The red line in the waveform indicates audio detection is triggered, and the green one indicates no audio detection. Adjust sensitivity and threshold according to the waveform.

<u>Step 3</u> Set arming periods and alarm linkage action.

Step 4 Click Save.

5.7 Setting Smart Plan

Smart plan includes face detection, heat map, IVS, people counting, face detection, video metadata, and stereo analysis. The intelligent function can be enabled only after the corresponding smart plan is enabled.

<u>Step 1</u> Select **Setting > Event > Smart Plan**.

The Smart Plan interface is displayed. For smart plan icon, see Table 5-4.

lcon	Description	lcon	Description	lcon	Description
	Face detection	0	Stereo vision		Heat map
Ŕ	Stereo analysis		IVS		Face recognition
ŤŤ	People counting		Video metadata		Crowd map
Step 2 Enable	ANPR	 9 9	Vehicle density	_	

Table 5-4 Description of smart plan icon

<u>Step 2</u> Enable smart functions as need.

Different cameras support different ways to enable smart functions. Select corresponding ways to enable these functions according to the actual interface.

• Select an icon to enable the corresponding smart plan.

Click an icon to enable it, and the selected smart function is highlighted. Click it again to cancel the selection.

If the icon **more** on the interface, click it to enable the smart function switch.

- Enable smart plan through Add Plan.
 - Select a preset point from the Add Plan the interface. The smart plan for the point is displayed.
 - Click the corresponding icon to enable a smart function.
 The selected smart function is highlighted. Click it again to cancel the selection.
- Step 3 Click Save.

5.8 Setting IVS

This section introduces scene selection requirements, rule configuration, and global configuration for IVS (intelligent video surveillance).

Basic requirements on scene selection are as follows.

- The target should occupy no more than 10% of the whole image.
- The target size in the image should be no more than 10 × 10 pixels. The size of abandoned object in the image should be no less than 15 × 15 pixels (CIF image). The target height and width should no more less than a third of the image height and width. The recommended target height is 10% of the image height.
- The brightness difference of the target and the background should be no less than 10 gray levels.
- The target should be continuously present in the image for no less than two seconds, and the moving distance of the target should be larger than its width and no less than 15 pixels (CIF image) at the same time.
- Reduce the complexity of surveillance scene as much as you can. Intelligent analysis functions are not recommended to be used in scene with dense targets and frequent illumination change.
- Avoid areas such as glass, reflective ground, water surface, and areas interfered by branch, shadow and mosquito. Avoid backlight scene and direct light.

5.8.1 Global Configuration

Set global rules for IVS, including anti-disturb, depth of field calibration, and valid motion parameter for targets.

Calibration Purpose

Determine corresponding relationship between 2D image captured by the camera and 3D actual object according to one horizontal ruler and three vertical rulers calibrated by the user and the corresponding actual distance.

Applicable Scene

- Medium or distant view with installation height of more than three meters. Scenes with parallel view or ceiling-mounted are not supported.
- Calibrate horizontal plane, not vertical walls or sloping surfaces.
- This function is not applicable to scenes with distorted view, such as the distorted views captured by super wide-angle or fisheye camera.

Notes

- Calibration Drawing
 - Calibration area: The calibration area drawn should be on one horizontal plane.
 - Vertical ruler: The bottom of three vertical rulers should be on the same horizontal plane. Select three reference objects with fixed height in triangular distribution as vertical rulers, such as vehicle parked at roadside or road lamp poles. Arrange three persons to draw at each of the three positions in the monitoring scene.
 - Horizontal ruler: Select reference object with known length on the ground, such as sign

on the road, or use a tape to measure the actual length.

Calibration Verification

After setting the ruler, draw a straight line on the image, check the estimated value of the straight line, and then compare this value with the value measured in the actual scene to verify calibration accuracy. In case of major difference between the estimated value and the actual one, fine-tune or reset parameters until the error requirement is met.

Procedure

1. Select Setting > Event > IVS > Global Setup

Figure 5-27 Global setup of IVS

Rule Config Global Setup	Parameter Anti-Disturb Enable On Off Sensitivity
LITTERATE S	Calibrate Region Area Horizontal Vertical Vertical Vertical Remove Calibrat Ruler Vertical Horizontal Actual Length Add Calibration Remove Calibrat
	Advanced Parameter × Default Refresh Save

2. Set parameters.

Table 5-5 Description of global setup (IVS) parameters

Parameter	Description
Anti-Disturb Enable	A reserved function.
Sensitivity	Adjust the filter sensitivity. With higher value, it is easier to trigger an alarm when low-contrast object and small object are captured, and the false detection rate is higher.
Tracking Overlap Rate	
Valid Tracking Distance	A reserved function.
Valid Tracking Time	

- 3. Set calibration area and ruler.
 - a. Click Add Calibration Area and draw a calibration area in the image.
 - b. Select a calibration type and enter the actual length, and then click Add Rulers.
 - c. Draw one horizontal ruler and three vertical rulers in the calibration area.
- 4. Click Save.

Result

Select the verification type, and then click Calibration Valid.
 To verify vertical ruler and horizontal ruler, respectively select Height Verification and

Width Verification.

Draw a straight line in the image to verify whether the rulers are correctly set.
 In case of big difference between the estimated value and the actual one, fine-tune or reset parameters until the error requirement is met.

5.8.2 Rule Configuration

Set rules for IVS, including cross fence detection, tripwire, intrusion, abandoned object, moving object, fast moving, parking detection, crowd gathering, and loitering detection.

- Select Setting > Event > Smart Plan, and enable IVS.
- Select Setting > Event > IVS > Global Setup to finish global configuration, and then configure Fast Moving rule.

For the functions and applications of the rules, see Table 5-6.

Rule	Description	Applicable Scene	
Tripwire	When the target crosses tripwire from the defined motion direction, the system performs alarm linkages.	Scenes with sparse targets and no occlusion among targets, such as the perimeter protection of unattended area. Scenes with sparse targets and without obvious and frequent light change. Simple scene in the detection area is recommended. • Missed alarm might increase in the scenes with dense targets, frequent occlusion, and people staying. • In scenes with complex foreground and background, false alarm might be triggered for abandoned or missing object.	
Intrusion	When the target enters, leaves, or appears in the detection area, the system performs alarm linkages.		
Abandoned object	When an object is abandoned in the detection area over the set time, the system performs alarm linkages.		

Table 5-6 Description of IVS functions

Rule	Description	Applicable Scene
Missing object	When an object is taken out of the detection area over the defined time, the system performs alarm linkages.	 Scenes with sparse targets and without obvious and frequent light change. Simple scene in the detection area is recommended. Missed alarm might increase in the scenes with dense targets, frequent occlusion, and people staying. In scenes with complex foreground and background, false alarm might be triggered for abandoned or missing object.
Fast moving	When the motion speed is higher than the configured speed, the system performs alarm linkages.	Scene with sparse targets and less occlusion. The camera should be installed right above the monitoring area. The light direction should be vertical to the motion direction.
Parking detection	When the target stays over the configured time, the system performs alarm linkages.	Road monitoring and traffic management.
Crowd gathering	When the crowd gathers or the crowd density is large, the system performs alarm linkages.	Scenes with medium or long distance, such as outdoor plaza, government entrance, station entrance and exit. It is not suitable for short-distance view analysis.
Loitering detection	When the target loiters over the shortest alarm time, the system performs alarm linkages. After alarm is triggered, if the target stays in the area within the time interval of alarm, then alarm will be triggered again.	Scenes such as park and hall.

Configure IVS rules. This section takes tripwire as an example.

 \square

Go to the **Rule Config** interface of the speed dome, and the PTZ lock function is automatically enabled. The locking time is 180 seconds. You can only manually control the PTZ during the locking time. Click **Unlock** at lower left corner of the **Rule Config** interface to manually unlock the PTZ, and click **Lock** again to relock the PTZ.

<u>Step 1</u> Select Setting > Event > IVS > Rule Config.

Step 2 Click 🖶 on the **Rule Config** interface, double-click the name to modify the rule name, and then select **Tripwire** from the **Rule Type** drop-down list.

Figure 5-28 T	ripwire
Rule Config Global Setup	
-authors if	☑ No. Name Rule Type ਜੋਂ⊅ ☑ 1 Rule1 Tripwire ▼ ● ^
	Parameter Setup Period Setting Direction A<->B
Draw Rule Clear	Cobject filter Record Record Delay 10 s (10~300)
Target filter Max Size 8191 Draw Target O Min Size 0 * 0 Clear Pixel Counter 0 * 0 Draw Target	Relay-out Alarm Delay 10 s (10~300) Send Email PTZ
Diaw larger	Image: Snapshot Default Refresh

<u>Step 3</u> Click **Draw Rule** to draw rule line in the image. Right-click to finish drawing. For requirements of drawing rules, see Table 5-6. After drawing rules, drag corners of the detection area to adjust the area range.

Rule	Description
Tripwire	Draw a detection line.
Intrusion	Draw a detection area.
Abandoned object	During the detection of abandoned object, the alarm is also
Missing object	triggered if pedestrian or vehicle stays for a long time. If the abandoned object is smaller than pedestrian and vehicle,
Fast moving	set the target size to filter pedestrian and vehicle or properly
Parking detection	extend the duration to avoid false alarm triggered by
Crowd gathering	transient staying of pedestrian.
Loitering detection	 During the detection of crowd gathering, false alarm might be triggered by low installation height, large percentage of single person in an image or obvious target occlusion, continuous shaking of the camera, shaking of leaves and tree shade, frequent opening or closing of retractable door, or dense traffic or people flow.

<u>Step 4</u> (Optional) Click **Draw Target** at the right side of **Target Filter**, and then draw the target in the image.

- When the rule of crowd gathering is configured, you do not need to set target filter, but draw the minimum gathering area. Click **Draw Target** to draw the minimum gathering area in the scene. The alarm is triggered when the number of people in the detection area exceeds the minimum area and the duration.
- Click **Clear** to delete all drawn detection lines.

• Click **Draw Target** at the right side of **Pixel Counter**, and then press and hold the left mouse button to draw a rectangle, the **Pixel Counter** then displays its pixel.

<u>Step 5</u> Set rule parameters for IVS.

Parameter	Description
Direction	 Set the direction of rule detection. When setting cross fence detection and tripwire, select A->B, B->A, or A<->B. When setting intrusion, select Enters, Exits, or Enter&Exit.
Action	When setting intrusion action, select Appears or Cross .
Object tracking	Select Object Tracking to enable this function. When alarm is triggered by a moving object, select 1P+3 or 1P+5 as the object tracking display mode in the Live interface. Then the tracking scene follows the moving object until the object is out of the camera range. For details, see "4.2.4 Window Adjustment Bar".
Track linkage	Select AlarmTrack and set the tracking time. When alarm is
Track Time	 triggered, the camera automatically tracks the person or object that triggers the alarm. Tracking time is the duration that the camera automatically tracks the object. Before enabling this function, you need to enable or disable the Alarm Track function under Smart Track as needed. When the Channel is set as 1, disable Alarm Track under Smart Track. When the Channel is set as 2 or 3, enable Alarm Track under Smart Track.
AI Recognition	 Select Al Recognition to enable this function. When you select Person as the alarm target, an alarm will be triggered when the system detects that persons trigger the rule. When you select Vehicle as the alarm target, alarm will be triggered when the system detects that vehicle trigger the rule.
Duration	 For abandoned object, the duration is the shortest time for triggering an alarm after an object is abandoned. For missing object, the duration is the shortest time for triggering an alarm after an object is missing. For parking detection, crowd gathering, or loitering detection, the duration is the shortest time for triggering an alarm after an object appears in the area.

Parameter	Description
Sensitivity	 For fast moving, sensitivity is related to the triggering speed. Lower sensitivity requires faster moving speed to trigger the alarm. For crowd gathering, sensitivity is related to the alarm triggering time. It is easier to trigger the alarm with higher sensitivity.

<u>Step 6</u> Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage". Step 7 Click **Save**.

To view alarm information on the **Alarm** tab, you need to subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

5.9 Setting Crowd Map

You can view crowd distribution on the map in real time for timely arming, to prevent stampede and other accidents.

5.9.1 Global Configuration

Set the calibration parameters of panoramic cameras.

Calibration Purpose

Determine corresponding relationship between 2D image captured by the camera and 3D actual object according to one horizontal ruler and three vertical rulers calibrated by the user and the corresponding actual distance.

Notes

When drawing calibration ruler, keep the ruler length consistent with the actual length of the object.

Procedure

1. Select Setting > Event > Crowd Map > Global Setup



Figure 5-29 Global setup of crowd map

Crowd Map Global Setup			
	Parameter	6.2	
	Ruler Settings	6.2	m
	Ruler Lis	t	
	 Vertical Actual Length 	O Horizontal	
	Add Rulers	Remove Rulers	
	Default	Refresh	Save

- 2. Set calibration area and ruler.
 - a. Click Add Calibration Area and draw a calibration area in the image.
 - b. Select a calibration type and enter the actual length, and then click Add Rulers.
 - c. Draw one horizontal ruler and three vertical rulers in the calibration area.
- 3. Click Save.

5.9.2 Rule Configuration

When the number of people or the crowd density in the detection area exceeds the configured threshold, the system performs alarm linkages.

Prerequisites

- Select Setting > Event > Smart Plan, and enable Crowd Map.
- Select Setting > Event > Crowd Map > Global Setup to configure the crowd map.

Procedure

<u>Step 1</u> Select Setting > Event > Crowd Map > Crowd Map.

		Figure 5-	30 Crowd i	map				
Crowd Map	Global Setup							
14847Kbps			5120x1800	Enable				
				Period	Setting			
ANGU RE	Detect Region		X 9 07 21 X9 15	No. Re	noin	Trigger alarm Imber of people	Delete	÷
		See y		1 Re	gion1	20	0	
Draw Detect			Clear	Global Crowd Density	4	Human /m²	(2~10)	
Draw Area			Clear	Smart Track				
Pixel Counter	0 * 0		Draw Target	Record Record Delay	1 2 10	s (10~300)		
				Relay-out	123			
				Alarm Delay	10	s (10~300)		
				Send Email				
				V Snapshot	1 2			
				Default	Refresh	Save		

<u>Step 2</u> Select the **Enable** check box, and then the crowd map function is enabled.

<u>Step 3</u> Click **Draw Detection Area** to draw global area for detecting crowd distribution in the image.

After drawing a global area, you can draw multiple local statistical areas in the global area as needed.

1) Click 🛟, and then click **Draw Area** to draw local statistical area in global detection area.

You can draw up to eight local statistical areas.

 Double-click the area name and the alarm people amount to set the area name of local statistical area and the threshold of the alarm people amount.
 When the number of people in the statistical area exceeds the alarm people amount, the system performs alarm linkages. The default alarm people amount is 20.

<u>Step 4</u> Set parameters.

Table 5-9 Description of crowd map parameters

Parameter	Description
Global	Select the Global check box and set the crowd density
Crowd Density	threshold. The system detects crowd distribution in the global area. When the crowd density exceeds the configured threshold, the system performs alarm linkages.

Parameter	Description
Smart track	 Select the Smart Track check box, and when alarm is triggered by the panoramic camera, the speed dome automatically turns to the position where alarm is triggered. The tracking time is "idle time + five seconds." For the details of idle time configuration, see "5.2.2 Enabling Alarm Track" Linkage rules: Detect global alarm only: Turns to crowd with highest density. Detect local alarm only: Turns to local area that triggers alarm first. Detect global alarm + one local alarm: First turns to local area, and then the crowd with highest density when there is no alarm in local area. Detect global alarm + multiple local alarms: First turns to local area that triggers alarm first, and then the crowd with highest density when there is no alarm in local area. Detect global alarm + multiple local alarms: First turns to local area that triggers alarm first, and then the crowd with highest density when there is no alarm in local area.
Pixel Counter	Click Draw Target next to Pixel Counter , and then press and hold the left mouse button to draw a rectangle, the Pixel Counter then displays its pixel.
Step 5 Set arming periods	and alarm linkage actions. For details, see "5.1.1 Alarm Linkage"
Step 6 Click Save.	

Result

Click on the Live interface to view the crowd map.

Figure 5-31 Crowd map (1)



Double-click the rendering area at the lower-right corner in the image to view crowd distribution in the area.




Figure 5-32 Crowd map (2)

5.10 Setting Face Recognition

When a face is detected or recognized in the detection area, the system performs alarm linkage and supports searching face detection and recognition results.

- Face Detection: When a face is detected in the area, the system performs alarm linkage, such as recording and sending emails.
- Face Recognition: When a face is detected in the area, the system compares the captured face image with the information in the face database, and links alarm according to the comparison result.

For the process of setting face recognition, see Figure 5-33.



5.10.1 Setting Face Detection

When a face is recognized in the detection area, the system performs alarm linkage.

Prerequisites

Select Setting > Event > Smart Plan, and then enable Face Recognition.

Procedure

<u>Step 1</u> Select Setting > Face Recognition > Face Detection.

rigare e et rae	
Face Detection Face Database Config Alarm Sea	rch
	 Enable OSD Clear Period Setting Face Enhancement Record Record Delay 10 s (10~300) Send Email Y Snapshot Non-living Filtering
Detect Region Draw Clear Exclude Re Draw Modify Clear Target filter Max Size 8191 8191 Draw Target Min Size 0 0 Clear Pixel Counter 0 * 0 Draw Target 	Snap Face Image One-inch photo Snap Mode Optimized Snap Advanced Advanced Enable Face Exposure Face Target Brightn

Figure 5-34 Face detection

- <u>Step 2</u> Select the **Enable** check box to enable the face detection function.
- <u>Step 3</u> (Optional) Click **Draw** next to **Detect Region** to draw a face detection area in the image.
- <u>Step 4</u> (Optional) Click **Draw** next to **Exclude Region** to draw a non-face detection area in the **Detect Region**.
- <u>Step 5</u> (Optional) Select **Max Size** or **Min Size**, click **Draw Target** at the right side of **Target filter**, and then draw the target in the image.
- <u>Step 6</u> Set parameters.

Table 5-10 Description of face detection parameters

Parameter	Description
OSD	Select the OSD check box, and the number of people with face detected and recognized is displayed on the Live interface.
	Click Reset to recount.
Face Enhancement	Select the Face Enhancement check box to preferably guarantee clear face with low stream.
Non-living Filtering	Filter non-living faces in the image, such as a face picture.
Snap Face Image	Set a range for snapping face image, including face picture and one-inch picture.
Snap Mode	 Optimized Snapshot: Capture the clearest picture within the configured time after the camera detects face. Recognition Priority: Repeatedly compare the captured face to the faces in the armed face database, and capture the most similar face image and send the alarm. It is recommended to use this mode in access control scene. Click Advanced to set the optimized time.

Parameter	Description
Attribute	Select the Attribute check box, and click is to set the display of face attribute during the face detection.
Advanced	 Snapshot Angle Filter: Set snapshot angle to be filtered during the face detection. Snapshot Sensitivity: Set snapshot sensitivity during the face detection. It is easier to detect face with higher sensitivity. Optimized Time: Set a time period to capture the clearest picture after the camera detects face.
Enable Face Exposure	Select the Enable Face Exposure check box. When a face is detected, the camera can enhance brightness of the face to make the face image clear.
Face Target Brightness	Set the face target brightness. It is 50 by default.
Face Exposure Detection Interval	Set the face exposure detection interval to prevent image flickering caused by constant adjustment of face exposure. It is five seconds by default.
Pixel Counter	Click Draw Target next to Pixel Counter , and then press and hold the left mouse button to draw a rectangle, the Pixel Counter then displays its pixel.

<u>Step 7</u> Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage" <u>Step 8</u> Click **Save**.

5.10.2 Setting Face Database

By setting face database, the face database information can be used to compare with the face detected.

Face database configuration includes creating face database, adding face picture, and face modeling.

5.10.2.1 Creating Face Database

Face database includes face picture, face data and other information. It also provides comparison data for the captured face pictures.

<u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config. Capacity Limit: Shows the usage of the memory.

Figure 5-35 Face database configuration

nan Recogr	nition Face Database Config	Alarm	Search				
dd Face Data	b Capacity Limit:	92%					
No.	Face Database	Register No	Deploy 🔽	Similarity Threshold	MoreInfo	Arm/Disarm	Delete
1	11	10228		10		@	•
Refresh	Save						

Step 2 Click Add Face Database.

Figure 5-36 Add face database

Add Face Da	tabase	X
Name		
	OK Cancel	

<u>Step 3</u> Set the name of the face database.

Step 4 Click OK

Figure 5-37 Face database successfully added

No.	Face Database	Register No	Deploy 🥅	Similarity Threshold	MoreInfo	Arm/Disarm	Delet
1	1	8037	V	82		0	•
2	test11	4144		82		٢	•
3	test2	4143		82		0	•
4	test_new	4568		82			0
5	Test_1	0		82		۲	•

<u>Step 5</u> Set parameters.

Table 5-11 Description of face database parameters

Parameter	Description
Deploy	Select the Deploy check box, and the face database deployment is enabled. The captured face picture is compared to the armed face database.

Parameter	Description
Similarity Threshold	The detected face matches the face database only when the similarity between the detected face and the face feature in face database reaches the configured similarity threshold. After successful match, the comparison result is displayed on the Live interface.
MoreInfo	Click MoreInfo to manage face database. You can search face images by setting search conditions, register personnel, and modify personnel information.
Arm/Disarm	Set the alarm time period. Alarm event will be triggered only within the defined time. See "5.1.1.1 Setting Period".
Delete	Delete the selected face database.

5.10.2.2 Adding Face Picture

Add face picture to the created face database. Single adding and batch importing are supported.

Requirements on face pictures.

- A single face picture size is 50K–150K in JPEG format. The resolution is less than 1080p.
- Face size is 30%–60% of the whole picture. Pixel should be no less than 100 pixels between the ears.
- Taken in full-face view directly facing the camera without makeup, beautification, glasses, and fringe. Eyebrow, mouth and other face features must be visible.

5.10.2.2.1 Single Adding

Add face pictures one by one. Select this way when you need to add a small number of face pictures.

<u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config.

<u>Step 2</u> Click entry next to the face database to be set.

Figure 5-38 Face database configuration

Face Detection Fac	e Database Config	Alarm	Search				
Back Face Databa	se: Test_1						Task List
Name	Gender	Unlimited	Date of Birth			Modeling Status Unlimited	-
Credentials T Unlimit	ted 💌 ID No.		Region	Unlimited	✓ Search		
Registration Batc	h Registration Modelin	g All Mode	eling				

Step 3 Click Registration.

Figu	re 5-39 Registration (1)	
Registration		×
Upload Picture * Name* Gender Male City Custom	Upload Picture	
Credentials IC ID No. Address Memo		
	Add to task list Cancel	

<u>Step 4</u> Click **Upload Picture**, select a face picture to be uploaded, and then click **Open**.

You can manually select the area for a face. After uploading picture, box select a face and click **OK**. When there are multiple faces in a photo, select the target face and click **OK** to save face picture.

Figure 5-40 Registration (2)

Registration	n		Σ
Upload Pictur	G		OK Cancel
Name*			
Gender	Male	•	
Date of Birth			the second and
Region	Unlimited	•	
City	Custom	•	-10
Credentials	IC	•	
ID No.			
Address	1		
Memo			
			Add to task list Cancel

<u>Step 5</u> Enter the information about face picture according to the actual situation. <u>Step 6</u> Click **Add to task list**.

Step 7 Click Task List1 , and then click **OK**.

The **Task List** interface is displayed. See Figure 5-41. Click **Remove All** to remove all tasks by one click.

Add	Status	
Modify	Status	
Delete	Status	

Figure 5-41 Task list (manually add)

If adding user fails, the error code is displayed on the interface. For details, see Table 5-12. For face modeling operation, see "5.10.2.4 Face Modeling".

Parameter	Error	Description
0x1134000C		The picture is too large, and the upper limit is 150K.
0x1134000E	Picture importing error	The quality of the added pictures is to the upper limit.
0x11340019		The space of the face database exceeds the upper limit.
1	Picture modeling error	The picture format is not correct. Import the picture in JPG format.
2		No face in the picture or the face is not clear. Change the picture.
3		Multiple faces in the picture. Change the picture.
4		Fails to decode the picture. Change the picture.
5		The picture is not suitable to be imported to the face database. Change the picture.
6		The database error. Restart the camera and model faces again.
7		Fails to get the picture. Import the picture again.
8		System error. Restart the camera and model faces again.

5.10.2.2.2 Batch Importing

Import face pictures in batches. Select this way when you need to add a large number of face pictures.

Before importing pictures in batches, name face pictures in a format of

"Name#SGender#BDate of Birth#NRegion#TCredentials Type#MID No.jpg" (for example, "John#S1#B1990-01-01#T1#M0000). For naming rules, see Table 5-13.

\square

- The max. size of a single face picture is 150K, and the resolution is less than 1080p.
- When naming pictures, Name is required, and others are optional.

Table 5-13 Description of naming rules for batch import parameters

Description
Enter a name.
Enter a figure. "1" is male and "2" female.
Enter a figure. Format: yyyy-mm-dd, such as 2017-11-23.
Enter a figure. "1" is ID card and "2" passport.
Enter ID No.

<u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config.

<u>Step 2</u> Click [] next to the face database that you want to set.

Step 3 Click Batch Registration.

Figure 5-42 Batch add

	+ Supported Picture Format(.jpg)	
Naming Format: Name#SGer	nder#BDate of Birth#NRegion#TCreder	ntials Type#MID No.
Example: John#S1#B1990-01	-01#NCN#T1#M330501199001016222	

Step 4 Click +

to select file path.

Figure 5-43 Batch import

		Land .
Human Face		
i D		

Step 5 Click Browse.

The interface shows import process. After finishing the import, the interface shown as Figure 5-44 is displayed.

Figure 5-44 Importing successfully

Task List		×
	Picture import completed!	
🕗 Succee	1:0	
G Fail:1	Check Details	

5.10.2.3 Managing Face Picture

Add face pictures to face database, and then manage and maintain face pictures to ensure correct information.

5.10.2.3.1 Modifying Face Information

Step 1 Go to the Face Database Config interface, set filtering condition as needed, and click Search.

The search result is displayed.

Step 2 Select the row where the face picture or the personnel information is located, and then click or .

Registratio	n	×
Upload Pictur		
Name*	021819	Upload Picture
Gender	•	
Date of Birth		
Region	Unlimited 💌	
City	Custom	
Credentials	Other 💌	
ID No.		
Address		
Memo		
		Add to task list Cancel

Figure 5-45 Face information modification

Step 3Modify face information according to the actual need. Click Add to task list.Step 4Click Task List1 , and then click OK.

5.10.2.3.2 Deleting Face Picture

Go to the Face Database Config Interface, and delete the created face picture.

- Single delete: Select the row where the face picture or the personnel information is located, and click in or is to delete the face picture.
- Batch delete: Select at the upper right corner of the face picture or of the row where the personnel information is located. Select the information, click Add to Deletion List, TaskListi, and then click OK to delete the selected face picture.
- Delete all: When viewing face pictures in a list, click of the row where the serial number is located; when viewing by thumbnail, select All to select all face pictures. Click Add to Deletion List, Task List, and then click OK to delete all face pictures.

5.10.2.4 Face Modeling

Face modeling extracts face picture information and imports the information to a database to establish relevant face feature models. Through this function, the face recognition and other intelligent detections can be realized.

 \square

- The more the selected face pictures are, the longer time the face modeling takes. Please wait patiently.
- During modeling, some intelligent detection functions (such as face recognition) are not available temporarily, and will be available after modeling.
- <u>Step 1</u> Select Setting > Event > Face Recognition > Face Database Config. The Face Database Config interface is displayed.
- Step 2 Click 🔲 next to the face database to be set.

Figure 5-46 Face database configuration

Face Detection Face Database Config	Alarm	Search	
Back Face Database: Test_1			🗐 Task List
Name Gender	Unlimited	 Date of Birth 	Modeling Status Unlimited 💌
Credentials T Unlimited 💌 ID No.		Region	Unlimited Search
Registration Batch Registration Modelin	g All Mod	deling	

Step 3 Start modeling.

• Selective modeling.

If there are many face pictures in the face database, you can set search criteria to select the pictures that need to be modeled.

- 1. Set the search criteria, and click Search.
- 2. Select the face pictures to be modeled.
- 3. Click Modeling.
- All modeling.

Click **Modeling All** to complete modeling of all face pictures in the face database.

- <u>Step 4</u> View the modeling result.
 - Successful modeling.

Figure 5-47 Successful modeling

Task List		×
	Modeling completed.	
🤣 Succeed:8		
	Previous	

• Failed modeling

Figure 5-48 Failed modeling

Click **Search**, and the face details are displayed. Click to view the face picture in list format. See Figure 5-49. Click to view the face picture in thumbnail format. See Figure 5-50.

- When the modeling status is Valid in the list or is displayed on the left corner of the thumbnail, it means the modeling succeeded.
- When the modeling status is **Invalid** in the list or is not displayed on the left corner of the thumbnail, it means the modeling failed. Point to the modeling status in the list or the pictures without to view the details of the failure. Change the pictures according to the details.

me edentials	Ty Unlimited	Gender	Unlimited	Date of Birth Region	yyyy-mm-dd 📰 yyyy- Unlimited 🔹 Provi						
tegistrati	on Batch Regis	tration Model	ing All	Modeling					🖬 Add b	o the delete lis	st 崖
	No.	Name	Gender	Date of Birth	Region	City	Credentials Type	ID No.	Modeling Status	Modify	Del
	1	501	Male				IC		Valid	1	
3	2	502	Male				IC		Valid	1	
	3	503	Male				IC		Valid	1	1
3	4	504	Female				IC		Valid	1	1
	5	505	Female				IC		Invalid	1	1
									No face dete	ected.	

Figure 5-50 Modeling status (thumbnail)



5.10.3 Setting Face Recognition Alarm Linkage

When face recognition succeeded or failed, the device links alarm out. <u>Step 1</u> Select Setting > Event > Face Recognition > Alarm.

Figure 5-51 Alarm (face recognition)								
Face Detection	Face Database Config	Alarm	Search					
Face Database	Please add face databa	•						
Relay-out	Alarm Channel1	•						
Alarm Rule	Face Recognition Su	cceeded 🗌 Fa	ce Recognition Failed					
Alarm Delay	1 s (1~300))						
	Refresh	Save						

<u>Step 2</u> Select a face database and an alarm rule.

- Face recognition succeeded: When the detected face matches that in the face database, the device links alarm out.
- Face recognition failed: When the detected face fails to match that in the face database, the device links alarm out.
- Step 3 Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage"
- Step 4 Click Save.

5.10.4 Viewing Face Recognition Result

View face recognition result on the Live interface or by the search function.

5.10.4.1 Viewing Result in the Live Interface

View face recognition result on the Live interface. See Figure 5-52.

- Face recognition result is displayed at the left side and the captured face pictures and attribute information at the right side.
- Click a face picture in the display area, and the information is displayed.



Figure 5-52 Face recognition result

5.10.4.2 Viewing Result by Search Function

View face recognition or face snapshot result. Take face recognition search as an example.

Prerequisites

You have installed a SD card in the camera.

Procedure

```
<u>Step 1</u> Select Setting > Event > Face Recognition > Search.
```

Figure 5-53 Face recognition search

Face Detection	Face Database	e Config	Alarm	Search				
Туре	Face Snapsh 💌							
Start Time	2019-07-03 📑	14 : 20 : 4	55 End Time	2019-07-04	14 : 2	20 : 55 ≈ Adva	inced Par Sea	irch
Age	Unlimited 💌	Gender	Unlimited 💌	Expression	Unlimited	 Glasses 	Unlimited -]
Mouth Mask	Unlimited 💌	Beard	Unlimited 💌					

<u>Step 2</u> Select **Face Recognition** for **Type**, enter the start time and the end time, and then click **Search**.

The result is displayed. See Figure 5-54.

- Click Advanced Parameters to set more search conditions.
- Click the search result to view details. See Figure 5-55.

 Totally 1 tem: Each page displays 20 * Jem

Figure 5-54 Search result (face recognition)

Figure 5-55 MoreInfo (face recognition)

MoreInfo			×
Alarm Info	Face Database: Similarity: 99% Time: 2019-07-12 15:56:54		
Attribute	Age: Young Expression: Confused Mouth Mask: No	Gender: Male Glasses: General Beard: No	
MoreInfo	Name: Jhon Date of Birth: 1991-05-20 Region: Brazil Credentials Type: Passport Address: Unknown Memo: Unknown	Gender: Male City: Brasilia ID No.: PE1234478	

5.11 Setting Face Detection

When a face is detected in the detection area, the system performs an alarm linkage.

Prerequisites

Select Setting > Event > Smart Plan, and then enable Face Detection.

Procedure




Figure 5-56 Face detection

		🔲 Enable		
	A Cast of Land	OSD	Clear	
	THE WAY T	Period	Setting	
	· 音	E Face Enhancement	t	
		Record		
		Record Delay	10 s (10~300)	
		Relay-out	1 2	
The second se		Alarm Delay	10 s (10~300)	
		🔲 Send Email		
		🔽 Snapshot		
Detect Region Draw	Clear	Non-living Filter	ing	
	Ciear	Snap Face Image	One-inch photo 💌	
Exclude Re Draw Modify	Clear	Snap Mode	Optimized Snap 💌	
Target filter Max Size 8191 * 8191	Draw Target		Attribute	
O Min Size 0 * 0	Clear		Advanced	
Pixel Counter 0 * 0	Draw Target	Enable Face Expos	ure	
		Face Target Brightn		(0~1
		Face Exposure Det	= 0 + 5	(0~1
		Default	Refresh Save	

- <u>Step 2</u> Select the **Enable** check box to enable the face detection function.
- <u>Step 3</u> (Optional) Click **Draw** next to **Detect Region** to draw a face detection area in the image.
- <u>Step 4</u> (Optional) Click **Draw** next to **Exclude Region**, and then draw an area excluding face detection in the image.
- <u>Step 5</u> (Optional) Select **Max Size** or **Min Size**, click **Draw Target** at the right side of **Target filter**, and then draw the target in the image.
- Step 6 Set parameters.

Parameter	Description
OSD	Select the OSD check box, and the number people with face detected and recognized is displayed on the Live interface. Click Clear to recount.
Face Enhancement	Select the Face Enhancement check box to preferably guarantee clear face with low stream.
Target Box Overlay	Select the Non-living Filtering check box to add a target box to the face in the captured picture to highlight the face. The captured face picture is saved in SD card. Click the Snap Face Image tab to view the captured picture.
Non-living Filtering	Filter non-living faces in the image, such as a face picture.
Snap Face Image	Set a range for snapping face image, including face picture and one-inch picture.

Table 5-14 Description of face detection parameters

Parameter	Description
Snap Mode	 Optimized Snapshot: Capture the clearest picture within the configured time after the camera detects face. Recognition Priority: Repeatedly compare the captured face to the faces in the armed face database, and capture the most similar face image and send the event. It is recommended to use this mode in access control scene. Click Advanced to set the optimized time.
Attribute	Select the Attribute check box, and click to set the display of face attribute during the face detection.
Advanced	 Snapshot Angle Filter: Set snapshot angle to be filtered during the face detection. Snapshot Sensitivity: Set snapshot sensitivity during the face detection. It is easier to detect face with higher sensitivity. Optimized Time: Set a time period to capture the clearest picture after the camera detects face.
Enable Face Exposure	Select the Enable Face Exposure check box. When a face is detected, the camera can enhance brightness of the face to make the face image clear.
Face Target Brightness	Set the face target brightness. It is 50 by default.
Face Exposure Detection Interval	Set the face exposure detection interval to prevent image flickering caused by constant adjustment of face exposure. It is five seconds by default.
Pixel Counter	Click Draw Target next to Pixel Counter , and then press and hold the left mouse button to draw a rectangle, the Pixel Counter then displays its pixel.
Step 7 Set arming po	eriods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 8 Click Save.

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

Result

The face detection result is displayed on the live interface.

- The face pictures snapped in real time and their attribute information is displayed.
- Click a face picture in the display area, and the details are displayed.




Figure 5-57 Face detection result

5.12 Setting People Counting

People counting (including enter number, leave number and strand number in area), calibration configuration, queuing number, and view the people counting data in report form.

5.12.1 People Counting

The system counts the people entering and leaving the detection area. When the number of counted people exceeds the configured value, the system performs an alarm linkage.

Prerequisites

Select Setting > Event > Smart Plan, and then enable People Counting.

Procedure

<u>Step 1</u> Select Setting > Event > People Counting.

People Counting Calibration Config	Queuing	Report							
	2020-05-27 10:08:	hewee		ło.	Name	Ri	ule Type		÷
				1	1	People C	Counting	•	0
				2	PC-1	In Area N	lo.	•	•
	6	e e	Para	ameter Se	etup				
			C	DSD		Clear			
		01	F	Period		Setting			
			F	lowrate /	Alarm				
	R	1	E	Enter No.		2			
		51	L	eave No		2			
Draw Rule		Clear	s	Stranded	No.	0			
Draw Line		Clear	V F	Record					
			F	Record D	elay	10	s (10~3	00)	
			F	Relay-out		1 2			
				Alarm Del		10	s (10~3	00)	
				Send Ema					
			V 5	Snapshot					
			Glot	al Setup					
			s	3 <mark>ensitiv</mark> ity	r.	— —	-0	+ 7	
				Aax Heigl		220	cm (0~3		
			N	Ain Heigh	t	50	cm (0~2	00)	
				Default	Re	fresh	Save		

Figure 5-58 People counting



	gane e ee						
People Counting Calibration Config	Queuing	Report					
	3020-05-27 10:05	03Wed	👿 No.	Name	Rule Typ	9	÷
		A STA	✓ 1	1	People Countin	g 🔻	•
			✓ 2	PC-1	In Area No.		•
Traw Rule		Clear	Parameter Period	PC-1 Setup al Number Stat Jumber ng Alarm ng Time Delay ut belay mail	In Area No. Setting tistics Alarm 2 (0-8 ≥Threshold ▼ 30 s (1- 10 s (1 1 2	D)	
			- Global Setu	up	11		
			Sensitiv	rity	D 0	-+7	
			Max He	ight		0~300)	
			Min Hei	ght	50 cm (0~200)	
			Default	Ref	resh Save		

Figure 5-59 In area No.

<u>Step 2</u> Click 🔂 to add the people counting function.

- <u>Step 3</u> Double-click the name to modify the rule name. Select **People Counting** or **In Area No**.
 - **People Counting**: The system counts the people entering and leaving the detection area. When the number of counted number of people who enter, leave, or stay in the area exceeds the configured value, the system performs an alarm linkage.
 - In Area No.: The system counts the people in the detection area and the duration that people stay in the area. When the number of counted number of people in the detection area or the stay duration exceeds the configured value, the system performs an alarm linkage. This function is available on some select models.
- <u>Step 4</u> Click **Draw Area** to draw a detection area in the image.
 - When setting **People Counting**, you need to draw direction lines. When targets enter or leave along the direction line, they will be counted.
 - For the models that support multiple counting rules, different detection areas can be overlapped.

Step 5 Set parameters.

Parameter	Description
OSD	Select the OSD check box or select the Enter No. or Leave No. check box under OSD to display the people counting data in the image. Click Clear to clear the count.
Flip	Set the viewing angle of the image as Inclined or Vertical .
Flowrate Alarm	Set Enter No. , Leave No. , and Stranded No. The alarm is triggered when the configured value is reached.
Regional People Number Statistics Alarm	Set the number of people in the people counting region. When the people count reaches the threshold or the stay duration exceeds the configured value, the alarm is triggered.
Inside Number	When you set inside number to be 0, and select the type to
Туре	be≥ Threshold , the system will not perform the alarm linkage.
Stranding Alarm	Select the Stranding Alarm check box, and then set the stranding
Stranding Time	time, when the stay duration exceeds the configured value, the alarm will be triggered.
Sensitivity	Set the alarm-triggered sensitivity. The higher the sensitivity is, the easier the alarm will be triggered.
Max Height	Set the maximum height of the people in detection area. The unit is cm, and the range is 0–300.
Min Height	Set the minimum height of the people in detection area. The unit is cm, and the range is 0–200.

TILL FAF DIST		
Table 5-15 Descri	ption of people	e counting parameters

<u>Step 6</u> Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage". <u>Step 7</u> Click **Save**.

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

Result

You can view the counting result on the **Live** interface.

- For **People Counting** rule, the entry and exit numbers are displayed.
- For In Area No. rule, the inside number is displayed.



Figure 5-60 Counting result

5.12.2 Calibration Configuration

After configuring the rule for people counting, set the installation height and angle of the camera through calibration configuration.

Prerequisites

You have set at least one rule in **Setting > Event > People counting > People Counting**.

Procedure

<u>Step 1</u> Select Setting > Event > People Counting > Calibration Config.

People Counting Calibration Config	Queuing	Report			
	2020-05-27 10:00	0:55Wed	Installation Height	377	cm (0~1000)
			Installation Angle	86.6	° (0~90)
	1 61	1	Refresh	Save]
		€ €			
	- 0 -				
1 20		P			
	2	1			
KIN America		2/			
Ground		Clear			

Figure 5-61 Calibration configuration (stereo analysis)

- <u>Step 2</u> Click **Clear** to clear the default calibration box.
- <u>Step 3</u> Click **Ground** to draw a rectangular box in the image.

Ground should be on the same plane and as big as possible for calibration.

<u>Step 4</u> Click **Save**, and then the camera calculates its height above the ground and the angle it forms with the ground.
 If the height and angle are quite different from the actual situation, repeat <u>Step2</u>–Step3.

5.12.3 Queuing

The system counts the queue people in the detection area. When the queue people number exceeds the configured number or the queue time exceeds the configured time, the alarm is triggered, and the system performs an alarm linkage.

Prerequisites

Select Setting > Event > Smart Plan, and then enable People Counting.

Procedure

<u>Step 1</u> Select Setting > Event > Queuing.

	Figure 5-64		g				
People Counting Calibration Config	Queuing	Report					
	2020-05-27 10/08	:25%/Ved	No.	100 M 100 000 000	Rule Ty	-	÷
			✓ 1✓ 2	QUE-1	Queuing		0
					Queuing		9
				eter Setup	Setting		
	1	A 1	Qu	eue People No. /	Alarm		
			Qu	eue People No.	30 (0~	-80)	
120 0	A		Тур		≥Threshold	•	
		2		eue Time Alarm			
Draw Rule	L	Clear	Qu	eue Time	30 s (1~1800)	
			Re	cord			
				cord Delay		(10~300)	
			Rel		1 2		
				rm Delay	10 s ((10~300)	
			Ser	nd Email			
			0110	aponor			
			Global	Setup			
			Ser	nsitivity	Ξ0		
				x Height		(0~300)	
			Min	i Height	50 cm	(0~200)	
			Def	ault R	lefresh Sav	e	
				1993			

Figure 5-62 Queuing

<u>Step 2</u> Click 🔂 to add the queuing function.

You can add 4 rules at most.

- <u>Step 3</u> Double-click the name to modify the rule name. Click **Draw Rule** to draw a detection area in the image, and right-click to complete the drawing.
- <u>Step 4</u> Set parameters.

Parameter	Description				
Queue People No. Alarm	Set the queue people number for triggering the alarm and				
Queue People No.	counting type. When the queue people number reaches the				
Туре	configured value, the alarm is triggered.				
Queue Time Alarm	Set the queue time. When the queue time reaches the				
Queue Time	configured value, the alarm is triggered.				
Sensitivity	Set the alarm-triggered sensitivity. The higher the sensitivit is, the easier the alarm will be triggered.				
Max Height	Set the maximum height of the people in detection area. The unit is cm, and the range is 0–300.				

Table 5-16 Description of people queuing

Parameter		Description		
Min Height		Set the minimum height of the people in detection area. The unit is cm, and the range is 0–200.		
Step 5	Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".			
<u>Step 6</u>	Click Save.			
	To view alarm information on the Alarm tab, subscribe relevant alarm event. For			

Result

You can view the queuing result on the Live interface.

details, see "5.1.2 Subscribing Alarm".

The queuing number and the stranding time of each target are displayed on the interface.



Figure 5-63 Queuing result

5.12.4 Viewing People Counting Diagram

You can search and export the heat map and tracking map according to the set searching criteria. This function is available on some Fisheye camera. <u>Step 1</u> Select Setting > Event > People Counting > Diagram.

Figure 5-64 Diagram


ople Counting Qu	euing Diagram	Report
Enable		
Report Type Heat Map •Report max range is 1		2019-04-16 T 17 : 00 : 00 End Time 2019-04-16 T 18 : 00 : 00
Number of people	me Threshold 3	Minute Search Export
		r fa
		Report

- <u>Step 2</u> Select the **Enable** check box to enable diagram function. And then you can search the diagram during the set period.
- <u>Step 3</u> Set the searching criteria.

Parameter	Description		
Report Type	 Select the report type from the following two types: Heat Map: Density statistics of moving object, the color range is from blue to red, blue means the minimum heat value and red means the maximum heat value. Track Map: Tendency statistics of moving object. 		
Start Time	The start time of the report.		
End Time	The end time of the report.		
Number of People	When selecting heat map as the report type, you can select		
Threshold	Number of People , and set the threshold. The system searches the diagram according to the number of people in the area, and shows the heat map.		
Time	When selecting heat map as the report type, you can select Time ,		
Threshold	and set the threshold. The system searches the diagram according to the queuing time in the area and shows the heat map.		

<u>Step 4</u> Click **Search** to complete the diagram.

Click **Export** to export the report.



With the ruler on the right, you can read the diagram clearly.

5.12.5 Viewing People Counting Report

Generate people counting data in report form.

<u>Step 1</u> Select Setting > Event > People Counting > People Counting Report.

Figure 5-66 People counting report

People Counting	Queuing	Diagram	Report				
Rule In Area No.		istics Type Number of	of people 💌 Ti	ime Range Daily		•	
Start Time 2019-04-1	6 🗰 00 :	00 : 00 End1	Time 2019-04-16	18 : 00	: 00 •D	Daily report max range is 24 hours.	
Stranding Time 💿 5s	s 💿 30s 💿 60s	Chart Type 💿 Bar (Chart 💿 Line Chart				
V Rule1 V Rule3	Search	Export					
				I I r. I II			
				Report			

<u>Step 2</u> Set search conditions.

Table 5-18 Description of people counting report parameters

Parameter	Description
Rule	Select the rule of the report from In Area No and Queuing.

Parameter	Description				
Statistics Type	 The statistical type of people counting report. When you select Number of people, the system generates the report of the number of people that exceeds the configured number of people. When you select Average stranding time, the system generates the report of the average stranding time that exceeds the average stranding time. 				
Time Range	 Select the period for the report. When selecting People Counting, you can view daily report, monthly report and annual report. When selecting In Area No., you can view daily report and monthly report. 				
Begin Time	The bagin time and the and time of people counting				
End Time	The begin time and the end time of people counting.				
People Counting Direction	In and out directions of people counting report. You can select Entrance or Leave . Select Display Data , and the statistical quantity is displayed on the report.				
Stranding Time	Count the stay time, select 5 s, 30 s, or 60 s.				
Queue Time	Count the queuing tine, select 1 minute, 5 minutes, or 10 minutes.				
Report Type (Bar Chart/Line Chart)	Includes bar chart and line chart.				
Rule 1, Rule 2	Select the check box to search the report of the corresponding rule.				
Step 3 Click Search to	complete the report.				

<u>Step 3</u> Click **Search** to complete the report.

Click Export to export the report in .bmp or .csv format.

5.13 Setting Heat Map

Make statistics on the cumulative density of object movement and view heat map in report.

5.13.1 Heat Map

Detect the distribution of dynamically moving objects in the target area within a certain period and displays the distribution on a heat map. Color varies from blue to red. The lowest heating value is in blue, and the highest heating value is in red. When mirroring occurs on the camera or the viewing angle changes, original data on the heat map will be cleared

Prerequisites

Select Setting > Setting > Event > Smart Plan, and then enable Heat Map.

Procedure

<u>Step 1</u> Select Setting > Event > Heat Map > Heat Map.

Figure 5-67	Heat map
-------------	----------

Heat Map	Report			
			Enable	
		-av Dr. sdur	Period	Setting
		0.21% 82.5 <u>m</u> 2h	Tu 224	
			Default	Refresh Save


<u>Step 2</u> Select the **Enable** check box to enable the heat map function.

- Step 3 Set the arming period. For details, see "5.1.1.1 Setting Period".
- Step 4 Click Save.

5.13.2 Viewing Heat Map Report

The system can export heat map data as a report.

<u>Step 1</u> Select Setting > Event > Heat Map > Report.



<u>Step 2</u> Set the start time and end time.

Only some devices support heat map sequence numbers.

<u>Step 3</u> Click **Search** to complete the report. Click **Export** to export the statistical report.

5.14 Setting Vehicle Density

Configure the rules for traffic congestion and parking upper limit, and view the counting data on the **Live** interface.

Prerequisites

Select Setting > Event > Smart Plan, and then enable Vehicle Density.

Procedure

<u>Step 1</u> Select **Setting > Event > Vehicle Density**.

Figure 5-69 Vehicle density (traffic congestion)

		No.	Region	Scene	Delete 🚽
		1	VD-1	Traffic Conge	0
		2	VD-2	Parking Upp 👻	•
	P	meter Setuj ieriod iepeat Alarn	Setu n Time 0	ıps (0~300)	
		hreshold	50	vehicles (10-	
0 * 0	Draw Target	ontinuous (Cong 10	Min. (1~100)	
		ecord			
	R	ecord Dela	y 10	s (10~300)	
	🗆 R	elay-out	1 2		
	A	larm Delay	10	s (10~300)	
	🗔 s	end Email			
	🔽 S	napshot			
	▼ S	napshot			
		Default	Refresh	Save	_

	No.	Region	Scene	Delete 🕂
	1	VD-1	Traffic Conger	•
20.5 TA - 2 195	2	VD-2	Parking Upp	•
	Period Repeat Alai Upper Limit	m Time 0 Vehici	s (0~300)	1000)
	Record			
Draw Target	Record Dela	ay 10	s (10~300)	
	Relay-out	1 2		
	Alarm Delay		s (10~300)	
	Send Email			
hand (
	Clear Draw Target	 ✓ 1 ✓ 2 ✓ 2 ✓ 2 ✓ 4 ✓ 4 ✓ 1 ✓ 2 ✓ 4 ✓ 2 ✓ 4 ✓ 4	V 1 VD-1 V 2 VD-2 V 1 2 V 1 2 V 1 2 V 1 2 V 1 2 V 1 2 V 1 2 Alarm Delay 10 10	I VD-1 Traffic Congl I 2 VD-2 Parking Uppl I Parameter Setup Period Setup Period Setup s (0~300) I Upper Limit Vehicl Threshold 20 Image: Ima

Figure 5-70 Vehicle density (parking upper limit)

<u>Step 2</u> Click 🔂 to add the vehicle density function.

- <u>Step 3</u> Double-click the name to modify the rule name. Select **Traffic Congestion** or **Parking Upper Limit**.
 - **Traffic Congestion**: The system counts the vehicles in the detection area. When the counted vehicle number and the continuous congestion time exceed the configured values, an alarm is triggered and the system performs an alarm linkage.
 - **Parking Upper Limit**: The system counts the vehicles in the detection area. When the counted vehicle number exceeds the configured value, an alarm triggered and the system performs an alarm linkage.
- <u>Step 4</u> Click **Draw Area** to draw a detection area in the image.
- <u>Step 5</u> Set parameters.

Parameter	Description
Repeat Alarm Time	After the alarm is triggered, if the status lasts for the configured time in Repeat Alarm Time , the alarm will be triggered again.
Vehicle Congestion Alarm	Select the check box, and set the Threshold and Continuous Congestion Time . When the counted vehicle and the continuous congestion time exceed the configured values, an alarm is triggered.
Upper Limit Vehicle Quantity Alarm	Select the check box, and set the Threshold . When the counted vehicle exceeds the configured values, an alarm is triggered.

Table 5-19	Description	n of people	counting	parameters
	Description	i oi peopie	oouning	pulumeters

Parameter	Description				
Pixel Counter	Click Draw Target next to Pixel Counter , and then press and hold the left mouse button to draw a rectangle, the Pixel Counter then displays its pixel.				
Step 6 Set arming periods	and alarm linkage actions. For details, see "5.1.1 Alarm Linkage"				

<u>Step 6</u> Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 7 Click Save.

To view alarm information on the **Alarm** tab, subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

Result


You can view the counting result on the Live interface.

- For **Traffic Congestion** rule, the entry and exit numbers are displayed.
- For **Parking Upper Limit** rule, the inside number is displayed.

Figure 5-71 Traffic congestion



Figure 5-72 Parking upper limit



5.15 Setting Stereo Analysis

Stereo analysis includes rule configuration and calibration configuration.

5.15.1 Setting Rules for Stereo Analysis

The rules for stereo analysis include Fall Detection, Violence Detection, People No. Error, People Approaching Detection, and Strand Detection.

Prerequisites

Select **Setting** > **Event** > **Smart Plan**, and then enable **Stereo Analysis** For the functions and applications of the rules, see Table 5-20.

Rule	Function	Applicable Scene	
Fall Detection	When walking or standing people in the detection area suddenly fall down on the ground, the alarm is triggered.	Park and hall	
Violence Detection	When people walking or standing inside or outside the self-service hall or ATM protection cabin have violent movement (such as smashing ATM machine) or fighting, the alarm is triggered.	Bank halls and ATM protection cabins	
People No. Error (Functions of People No. Error vary from devices.)	The camera can recognize the real-time number of people in the monitoring area. When the number of people exceeds the configured value, the alarm is triggered.	Scenic spots and banks	

Table 5-20 Description of stereo analysis function

Rule	Function	Applicable Scene
	When a recording device is used, the device that monitors the front of a classroom needs to be configured with this function. With this function, the teacher's actions can be traced and enlarged. When the number of people in the image is not 1, the whole image is displayed.	Classrooms
People Approaching Detection	When the distance between walking or standing people reaches the configured value, the alarm is triggered.	Banks and educational institutions
Strand Detection	When people in the monitoring area stay longer than the configured stranding time, the alarm is triggered.	Banks and parks

This section takes Fall Detection as an example to introduce the configuration of stereo analysis rule.

Procedure

- <u>Step 1</u> Select Setting > Event > Stereo Analysis > Stereo Analysis. The Stereo Analysis interface is displayed.
- Step 2 Click , double-click the name to modify the rule name, and then select **People Approaching Detection** as **Rule Typ**.

	No.	Name	Rule Type	÷
The state of the s	✓ 1	Rule1	People Approz 🗸	(
	2	Rule2	Fall Detection V	•
	√ 3	Rule3	Violence Deter V	6
	☑ 4	Rule4	People No. Eri 🗸	6
	☑ 5	Rule5	Strand Detecti 🗸	•
	Parameter Setu	p		
	Period	Setting]	
	Sensitivity		-)÷5	
	Duration	2	s (1~60)	
The set of the	Repeat Alan	n 0	s (0~300)	
	Mode	Less than	~	
Clear	Spacing Thr	es 100	cm (10~600)	
	Record			
	Record Dela	y 10	s (10~300)	
	Relay-out	1 2		
	Alarm Delay		s (10~300)	
	Send Email			
	PTZ			
	Snapshot			

Figure 5-73 People approaching detection

- <u>Step 3</u> (Optional) Click **Clear** to delete the default rule box, and then click **Draw Rule** to draw a detection area in the image.
 - When selecting **People No. Error** for a recording device, draw the front of a classroom as the detection area.
 - When selecting **Stand Detection** for a recording device, draw the area where the students stay as the detection area.
 - For other devices without special requirements, use the default box of the system (draw the full screen as the detection area).

<u>Step 4</u> Set parameters.

Parameters for recording device and common device are different. The actual interface shall prevail.

Parameter	Description				
Sensitivity	Set the alarm-triggered sensitivity. The higher the sensitivity is, the easier the alarm will be triggered.				
Alarm People Amount	When configuring People No. Error , set the alarm people amount and alarm type. Alarm type includes Greater than , Equal to , Less than , and Unequal to .				
Alarm Type	When the real-time number of people in the detection area is greater than, equal to, less than, or unequal to Alarm People Amount , the alarm is triggered.				

Table 5-21 Description of stereo analysis parameters

Parameter	Description
Duration	 For People Approaching Detection, when the time for people approaching reaches the configured value, the alarm is triggered. For Fall Detection, when the time of people falling down on the ground reaches the configured value, the alarm is triggered. For People No. Error, when the number of people in the area reaches the configured value of alarm people amount and alarm type, and the time reaches the configured value, the alarm is triggered.
Close-up Mode	 For people No. error function for a recording device, select Tracking Mode as Close-up Mode. Then the camera traces the teacher's walking trajectory. You can view the tracking effect through sub stream 1 of the live interface. When the number of people on the image is not 1, the full screen is displayed. When setting the stand detection function for a recording device, select Fixed Mode as Close-up Mode. Then sub stream 1 enlarges and displays the image of standing people. When the number of standing people is not 1, the full screen is displayed. Men the number of standing people is not 1, the full screen is displayed. Before viewing the tracking or enlargement effect through sub stream 1, ensure that sub stream 1 is enabled and the resolution of the main stream and sub streams, see "4.5.2.1 Video".
Repeat Alarm Time	After the alarm is triggered, if the status lasts for the configured time in Repeat Alarm Time , the alarm will be triggered again.
Strand Time Threshold	When configuring Strand Detection, you need to set the strand time threshold. When people in the area stay longer than the configured strand time threshold, the alarm is triggered.

Step 5Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage".Step 6Click Save.

- Select Setting > Event > Stereo Analysis > Calibration Config to finish calibration configuration for other devices, and then the detection rule becomes valid. For details, see "5.15.2 Calibration Configuration".
- To view alarm information on the **Alarm** tab, you should subscribe relevant alarm event. For details, see "5.1.2 Subscribing Alarm".

5.15.2 Calibration Configuration

After configuring the rule for stereo analysis, set the installation height and angle of the camera

through calibration configuration. There are two calibration modes: Calibration mode 1: Directly enter the installation height and angle according to the actual conditions; calibration mode 2: Draw an area in the image to automatically calculate the installation height and the angle. This section takes calibration mode 2 as an example.

Prerequisites

You have set at least one rule in Setting > Event > Stereo Analysis > Stereo Analysis.

Procedure

<u>Step 1</u> Select Setting > Event > Stereo Analysis > Calibration Config.

Figure 5-74 Calibration configuration (stereo analysis)

Stereo Analysis Calibration Config			
	Installation Height Installation Angle	106 77.0	cm (0~1000) ° (0~90)
	Refresh	Save	
Ground Clear			

- <u>Step 2</u> Click **Clear** to clear the default calibration box.
- <u>Step 3</u> Click **Ground** to draw a rectangular box in the image.

Ground should be on the same plane and as big as possible for calibration.

<u>Step 4</u> Click **Save**, and then the camera calculates its height above the ground and the angle it forms with the ground.
 If the height and angle are quite different from the actual situation, repeat <u>Step2</u>–Step4.

5.16 Setting ANPR

Extract information of motor vehicles and display related attributes on the live interface.

5.16.1 Scene Configuration

Configure non-motor vehicle detection.

Prerequisites

Select Setting > Event > Smart Plan, and then enable ANPR.

Procedure

<u>Step 1</u> Select Setting > Event > ANPR > Scene Set.

Figure 5-75 Scene set (ANPR) Scene Set Picture Rule Type Image: Colspan="2">Image: Colspan="2" Image: Colspan="2" Image							
Scene Set	Picture Report	te					
		t Main Utball.				Contraction and	and the second second
			Trafi OSE Peri	fic Flow St) od	Clear]	
			🗌 Cap	iture Comp	olete Vehicle	: ; (10~300)	
Target filter Max Min Pixel Counter	Size 8191 * 8191 Size 0 * 0 0 * 0	Draw Target Clear Draw Target	Defa	ault	Refresh	Save	

Step 2 Click **Draw** to draw a detect region and an exclude region in the image.

- Detect region: The region that needs to be detected.
- Exclude region: The region that does not need to be detected. Click **Modify** to modify the drawn region.

Click **Clear** at the right side to draw the detection area again.

- <u>Step 3</u> Click **Draw Target** next to **Target Filter** to draw the maximum size and minimum size for the detection target in the image.
- <u>Step 4</u> Configure parameters.

Table 5-22 Description of scene set parameters (ANPR)

Parameter	Description
Traffic Flow Statistics	Select Traffic Flow Stat , and the device detects the number of motor vehicles and non-motor vehicles in the detection area and generates the statistical report. If Traffic Flow Stat is disabled, the report has no statistical data.
030	Select OSD to display the statistical result on the preview interface. To clear the statistical result, click Clear .
Snap Mode	Select the snap mode: Optimized Snap and Tripwire.
Relay-out	Select the Relay-out check box, and when alarm is triggered, the system interacts with the linked alarm devices.
Alarm Delay	The Alarm linkage keeps running for the configured time after alarm is ended.

<u>Step 5</u> Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage". Step 6 Click **Save**.

Result

The ANPR result is displayed on the live interface.

- The plate no. and attribute information of vehicle are displayed at the right side.
- Click the picture in the display area, and the detailed information is displayed.

<complex-block>

5.16.2 Setting Picture Overlay

Set overlay of motor vehicle. <u>Step 1</u> Select Setting > Event > ANPR > Picture.

ype Car Color PI	late No. Car Log	0	Picture Overlay	
			Туре	Motor Vehicle
			V Plate No.	Car Color
		a Sun Ray	Car Type	Car Logo
	Star in	iras. semita	Sunshield	Seatbelt
	12 10 10 10	A AND A AND A	Smoking Status	Calling Status
1172		Server and the se	Ornament	Inspection Sticker
			Time	
	1		Location	
			Upload Picture	
THE REAL PROPERTY IN		a hard a state of the state of	Vehicle Body Pic.	


- <u>Step 2</u> Select **Motor Vehicle** from the **Type** drop-down list.
- <u>Step 3</u> Set overlay information and box position, such as plate no., time, car color, car type, and car logo.
- Step 4 Click Save.

5.16.3 Viewing ANPR Report

Generate data of ANPR in report form.

<u>Step 1</u> Select Setting > Event > ANPR > Report.

Figure 5-78 Report




<u>Step 2</u> Select the report type, start time, end time, and other parameters.

Step 3 Click Search.

The statistical results are displayed. Then click **Export** to export the statistical report.

Figure 5-79 Statistical results



5.17 Setting Video Metadata

Classify people, non-motor vehicles and motor vehicles in the captured video, and display the relevant attributes on the live interface.

5.17.1 Scene Configuration

Set the detection scenes and rules, including rules for people, non-motor vehicles and motor vehicles.

Select Setting > Event > Smart Plan, and then enable Video Metadata.

Take setting of the People Detection rules as an example.

<u>Step 1</u> Select Setting > Event > Video Metadata > Scene Set.

	Figure 5-80 Sc	ene set (vide	eo me	tadata	a)		
Scene Set Pic	ture Report						
58405	2.14		V	No.	Name	Rule Type	÷
			V	1	Rule1	People 💌	0
				2	Rule2	Non-motor \	0
	Add to the second			3	Rule3	Motor Vehic 💌	0
		ALC: NOTICE OF					
7 130			- Parame	ter Setup -			
				c Flow Sta			
	I MARINE MAR				Clear		
		the second					
			Perio	bd	Setting		
Fo	R. B.						
				Mode	Optimize	ec 💌	
			Capt	ure Compl	ete Vehicle		
Detect Region Draw		Clear	V Rela	y-out	1 2		
Exclude Re Draw	Modify	Clear	Alarr	n Delay	10	s (10~300)	
Target filter Max Size	8191 * 8191	Draw Target					
-			- Global S	Setup ——			
Min Size	0 * 0	Clear	Priva	cy Protecti	on Face		
Pixel Counter	0 * 0	Draw Target	Eace	Enhancer	nent		
			-				
			Snap	Face Ima	ge One-inch	photo 💌	
			Enat	ole Face Ex	posure		
			Face	Target Bri	ghtn 🖃 ———		
				· · · · · · · · · · · · · · · · · · ·	Det 🖃 🌔 —		
			Scen	ie	Distant \	/iew 💌	
			Defa	ut	Refresh	Save	
			Dela		Reliesti	Jave	

- Step 2 Click 🔂, and double-click the name to modify the rule name, and select **People** in **Rule Type** list.
- <u>Step 3</u> Click **Draw** to draw a detect region and an exclude region in the image.
- <u>Step 4</u> Click **Draw Target** next to **Target Filter** to draw the maximum size and minimum size for the detection target in the image.
- <u>Step 5</u> Set parameters.

Table 5-23	Description	of scene	set parameters	(video	metadata)
				(

Parameter	Description		
People Flow Statistics	Select the People Flow Statistics check box to count the number of people in the detection area.		
Traffic Flow Stat	Select the Traffic Flow Statistics check box to count the number of motor vehicles in the detection area.		
Capture whole vehicle	Select the Capture Whole Vehicle check box to capture whole vehicle. The snapshot is saved in the preset path for monitoring snapshots. For details, see "4.5.2.5 Path".		
Non-motor Vehicle Flow Statistics	Select the Non-motor Vehicle Flow Statistics check box to count the number of non-motor vehicles in the detection area.		

Parameter	Description
OSD	Select the OSD check box, and the numbers of motor vehicles, non-motor vehicles and people in the detection area are displayed.
Pixel Counter	Click Draw Target next to Pixel Counter , and then press and hold the left mouse button to draw a rectangle, the Pixel Counter then displays its pixel.
Privacy Protection	Select the Privacy Protection check box and then select Face or Human body from the drop-down list to blur faces or human bodies in the image.
Face Enhancement	Select the Face Enhancement check box to preferably guarantee clear face with low stream.
Snap Face Image	Set a range for snapping face image, including face picture and one-inch picture.
Enable Face Exposure	Select the Enable Face Exposure check box to make face clearer by adjusting lens aperture and shutter.
Face Target Brightness	Set the face target brightness, and it is 50 by default.
Face Exposure Detection Interval	Set the face exposure detection interval to prevent image flickering caused by constant adjustment of face exposure. It is 5 seconds by default.
Scene	Set scene as Distant View or Close View .

<u>Step 6</u> Set arming periods and alarm linkage actions. For details, see "5.1.1 Alarm Linkage". <u>Step 7</u> Click **Save**.

Result

Click is on the live interface to view the detection results of video metadata.


- The plate no. and attributes of motor vehicle are displayed at the right side, and pictures of people and non-motor vehicles and their attributes at the bottom.
- Click the picture in the display area, and the detailed information is displayed.



Figure 5-81 Video matedata result

5.17.2 Setting Picture Information

Set overlay of motor vehicle, non-motor vehicle and people and the box position. This section takes the configuration of motor vehicle overlay as an example. <u>Step 1</u> Select Setting > Event > Video Metadata > Picture.



	Туре	Motor Vehicle
	Plate No.	Car Color
The second secon	🔽 Car Type	🔽 Car Logo
	Sunshield	🔄 Seatbelt
THE REAL PROPERTY AND A DESCRIPTION OF	Smoke	Calling
	Ornament	Inspection Sticker
	Time	
	Location	
	Upload Picture —	
	Vehicle Body Pi	c
	Default	Refresh Save

<u>Step 2</u> Select **Motor Vehicle** from the **Type** drop-down list.

Select Non-motor Vehicle or People, and set non-motor vehicle and people overlay.

- <u>Step 3</u> Set overlay information and box position, such as plate no., time, car color, car type, and car logo.
- Step 4 Click Save.


5.17.3 Viewing Video Metadata Report

Generate data of video metadata recognition in report form.

- <u>Step 1</u> Select Setting > Event > Video Metadata > Report.
 - The **Report** interface is displayed.
- <u>Step 2</u> Select the report type, start time, end time, and other parameters.
- <u>Step 3</u> Click **Search** to complete the report.

The statistical results are displayed. Click **Export** to export the statistical report.

Figure 5-83 Video metadata report



5.18 Setting Relay-in

When an alarm is triggered at the alarm-in port, the system performs alarm linkage. <u>Step 1</u> Select Setting > Event > Alarm Settings > Alarm.

Figure 5-84 Alarm linkage				
Alarm				
Enable				
Relay-in	Alarm1			
Period	Setting			
Anti-Dither	0 s (0~100) Sensor Type NO 💌			
Record				
Record Delay	10 s (10~300)			
Relay-out	1 2			
Alarm Delay	10 s (10~300)			
📄 Send Email				
Snapshot				
	Default Refresh Save			

<u>Step 2</u> Select the **Enable** check box to enable the alarm linkage function.

<u>Step 3</u> Select a relay-in port and a sensor type.

- Sensor Type: NO or NC.
- Anti-Dither: Only record one alarm event during the anti-dither period.

Step 4 Set arming periods and alarm linkage action. For details, see "5.1.1 Alarm Linkage".

Step 5 Click Save.

5.19 Setting Abnormality

Abnormality includes SD card, network, illegal access, voltage detection, and security exception.

 \square

Only the device with SD card has the abnormality functions, including **No SD Card**, **SD Card Error**, and **Capacity Warning**.

5.19.1 Setting SD Card

In case of SD card abnormality, the system performs alarm linkage. The event types include **No SD Card**, **Capacity Warning**, and **SD Card Error**. Functions might vary with different models, and the actual interface shall prevail.

<u>Step 1</u> Select Setting > Event > Exception Handling > SD Card.

Figure 5-85 SD card						
SD Card	SD Card Network		Security Exception			
Event Type	No SD Card	•				
Relay-out Alarm Delay	1 2 10	s (10~300)				
📄 Send Email						
	Default	Refresh	Save			

- <u>Step 2</u> Select the event type from the **Event Type** drop-down list, and then select the **Enable** check box to enable the SD card detection function. When setting **Capacity Warning** as **Event Type**, set **Capacity Limit**. When the
 - remaining space of SD card is less than this value, the alarm is triggered.
- <u>Step 3</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
- Step 4 Click Save.

5.19.2 Setting Network

In case of network abnormality, the system performs alarm linkage. The event types include **Disconnection** and **IP Conflict**.

<u>Step 1</u> Select Setting > Event > Abnormality > Network.

	Figure 5-86 Network			
Card	Network	Illegal Acces		

SD Card	Network	Illegal Access	Security Exception
Event Type	Disconnectio	n 🔻	
Enable			
Record			
Record Delay	10	s (10~300)	
Relay-out	1 2		
Alarm Delay	10	s (10~300)	
	Default	Refresh	Save
	·		

- <u>Step 2</u> Select the event type from the **Event Type** drop-down list, and then select the **Enable** check box to enable the network detection function.
- <u>Step 3</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 4 Click Save.

5.19.3 Setting Illegal Access

When you enter a wrong login password more than the set times, the system performs alarm linkage.

```
<u>Step 1</u> Select Setting > Event > Abnormality > Illegal Access.
```

Figure 5-87 Illegal access					
SD Card	Network	lllegal Access	Security Exception		
_					
Enable					
Login Error	5	time (3~10)			
Relay-out	1 2	_			
Alarm Delay	10	s (10~300)			
📄 Send Email					
	Default	Refresh	Save		

<u>Step 2</u> Select the **Enable** check box to enable the illegal access detection function.

Step 3 Set Login Error.

If you consecutively enter a wrong password more than the set value, the account will be locked.

- <u>Step 4</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
- Step 5 Click Save.

5.19.4 Setting Voltage Detection

When the input voltage is higher than or lower than the rated value of the device, the system performs alarm linkage.

<u>Step 1</u> Select Setting > Event > Abnormality > Voltage Detection.

SD Card	Network	Illegal Access	Voltage Detection Security Exception
Enable			
V Overlay			
Send Email			
	Default	Refresh	Save

<u>Step 2</u> Select the **Enable** check box to enable the voltage detection function.

Select **Overlay**, and the alarm icon is displayed by overlapping when the alarm is triggered. Implicates undervoltage and indicates overvoltage.

<u>Step 3</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".

Step 4 Click Save.

5.19.5 Setting Security Exception

When a hostile attack is detected, the system performs alarm linkage.

<u>Step 1</u> Select Setting > Event > Abnormality > Security Exception.

Figure 5-89 Security exception					
SD Card	Network	Illegal Access	Security Exception		
 Enable Relay-out Alarm Delay Send Email 	<mark>1</mark> 2 10	s (10~300)			
	Default	Refresh	Save		

<u>Step 2</u> Select the **Enable** check box to enable the security exception detection function.

- <u>Step 3</u> Set alarm linkage actions. For details, see "5.1.1 Alarm Linkage".
- Step 4 Click Save.

5.19.6 Setting Disarming

You can disable the linkage actions through the app on your smart phone, and then the system will not perform any linkage action, but alarm records will still be generated. <u>Step 1</u> Select **Setting > Event > Disarming**.

Figure 5-90 Disarming

Disarming	
Disarming	Enable
Disarm by Period Disarm Period	Enable (Disarm by Period will be valid after one-click disarm is disabled.)
Disarm Alarm Linka.	
	Select All
	Relay-out
	Send Email
	Audio Linkage
	✓ Warning Light
	Default Refresh Save

- <u>Step 2</u> Select the **Enable** check box to disarm.
- <u>Step 3</u> (Optional) Select the **Enable** check box next to **Disarm by Period** to enable the Disarm by Period function, and then you can disarm by period. For setting disarm period, see "5.1.1.1 Setting Period".

This function is only valid when **Disarming** is disabled.

- <u>Step 4</u> Select alarm linkage actions as needed.
- Step 5 Click Save.

6 Maintenance

6.1 Requirements

To make sure the system runs normally, maintain it as the following requirements:

- Check surveillance images regularly.
- Clear regularly user and user group information that are not frequently used.
- Modify the password every three months. For details, see "4.8.4 Account".
- View system logs and analyze them, and process the abnormity in time.
- Back up the system configuration regularly.
- Restart the device and delete the old files regularly.
- Upgrade firmware in time.

6.2 Auto Maintain

You can restart the system manually, and set the time of auto reboot and auto deleting old files. This function is disabled by default.

<u>Step 1</u> Select Setting > System > Auto Maintain.

Figure 6-1 Auto maintain

Auto Maintain			
Auto Reboot			
Auto Delete Old Files			
Manual Reboot			
Refresh Save	9		

<u>Step 2</u> Configure auto maintain parameters.

- Select the **Auto Reboot** check box, and set the reboot time, the system automatically restarts as the set time every week.
- Select the **Auto Delete Old Files** check box, and set the time, the system automatically deletes old files as the set time. The time range is 1 to 31 days.

\wedge

When you enable and confirm the **Auto Delete Old Files** function, The **The deleted files cannot be restored, are you sure?** notice is displayed. Operate it carefully.

• Click **Manual Reboot**, and then click **OK** on the displayed interface, the camera will restart.

Step 3 Click OK.

6.3 Resetting Password

When you need to reset the password for the admin account, there will be a security code sent


to the entered email address which can be used to reset the password.


Prerequisites

You have enabled password reset service. For details, see "4.8.5.1 System Service".

Procedure

<u>Step 1</u> Open IE browser, enter the IP address of the device in the address bar and press Enter.





Step 2 Click Forgot password?


Figure 6-3 Prompt


Prompt 🛛
In order to provide a secure password reset environment, we need to collect your e-mail address, device NAC address, device SN, etc. All collected into is used only for the purposes of verifying device validity and sending a security code to you. Do you agree and want to continue the operation?
OK Cancel

Step 3 Click OK.

\square

Clicking **OK** means that you are informed that some of your personal data might be collected to help reset the password, such as phone number, MAC address, and device serial number. Read the prompt carefully to decide whether to authorize the collection activity.





Step 4 Reset the password.

<u>Step 5</u> Scan the QR code, and there will be a security code sent to the email address you entered. Enter the security code as instructed.



- Please use the security code within 24 hours after you receive it. Otherwise, it will become invalid.
- If you fail to use the security code for two times continuously, there will be fail notice when you try to get a security code for the third time. You have to reset the device to get a security code or wait 24 hours to get it again.

Step 6 Click Next.

Figure 6-5	Reset the	password	(2)
------------	-----------	----------	-----

admin			
Use a password that has 8 to 32 characters, it can be a combination of letter(s), number(s) and symbol(s) with at least two kinds of them.			
0 0	can be a combination of letter(s), number(s) and	Use a password that has 8 to 32 characters, it can be a combination of letter(s), number(s) and symbol(s) with at least two kinds of them.	Use a password that has 8 to 32 characters, it can be a combination of letter(s), number(s) and symbol(s) with at least two kinds of them.

- Step 7 Reset and confirm the password. The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among upper case, lower case, number, and special character (excluding ' ";: &).
- Click Save. Step 8 The login interface is displayed.

6.4 Backup and Default

6.4.1 Import/Export

- Export the system configuration file to back up the system configuration.
- Import system configuration file to make quick configuration or recover system ٠ configuration.

<u>Step 1</u> Select Setting > System > Import/Export.

		Figure 6-6 Impo	rt/Export	
In	nport/Export			
	Backup Path			
	Import	Export]	
			-	
ep 2	Click Import or I	Export		

Step 2

- Import: Select local configuration file, and click Open to import the local system configuration file to the system.
- Export: Select the storage path, and click Save to export the system configuration file to local storage.

<u>Step 3</u> Click **Save** to finish configuration.

6.4.2 Default

Restore the device to default configuration or factory settings.

 \wedge

This function will restore the device to default configuration or factory setting. Select **Setting > System > Default**.

- Click Default, and then all the configurations except IP address and account are reset to default.
- Click Factory Default, and all the configurations are reset to factory settings.

Figure 6-7 Default

Default	
Default	Other configurations will be recovered to default except network IP address, user management and so on.
Factory Default	Completely recover device parameters to factory default.

6.5 Upgrade

Upgrading to the latest system can perfect camera functions and improve stability.

_	_	

If wrong upgrade file has been used, restart the device; otherwise some functions might not work properly.

<u>Step 1</u> Select Setting > System > Upgrade.

Figure 6-8 Upgrade

e Upgrade		
Select Firmware File		Browse Upgrade
nline Upgrade		
	Save	
Auto-check for updates		

<u>Step 2</u> Select upgrading method according to the actual needs.

- File Upgrade
 - 1. Click **Browse**, and then upload upgrade file.
 - 2. The upgrade file should be a .bin file.
 - 3. Click Upgrade.

The upgrade starts.

- Online Upgrade
 - 1. Select the Auto-check for updates check box.

The system checks for upgrade once a day automatically, and there will be system notice if any upgrade is available.

\square

We need to collect the data such as device name, firmware version, and device serial number to proceed auto-check. The collected information is only used for verifying the legality of cameras and upgrade notice.

2. If there is any upgrade available, click **Upgrade**, and then the system starts upgrading.

 \square

Click Manual Check to check for upgrade manually.

6.6 Information

You can view the information, including version, log and online user, and back up or clear log.

6.6.1 Version

You can view device information such as hardware, system version, and web version. Select **Setting** > **Information** > **Version** to view the version information.

Figure 6-9 Log

6.6.2 Log

You can view and back up logs.

<u>Step 1</u> Select **Setting > Information > Log**.

		- 3-		- 9		
Log	Remote Log					
Start Time	2019-07-17	19 : 25 : 40	End Time	2019-07-18	19 : 25 : 40	1
Туре	All	- Search				
No.		g Time		Username		Log Type
Detailed Informat	tion					
Time:						
Username:						
Type:						
Content:						
Realize						
Backup						

<u>Step 2</u> Configure **Start Time** and **End Time**, and then select the log type.

The start time should be later than January 1st, 2000, and the end time should be earlier than December 31, 2037.

The log type includes All, System, Setting, Data, Event, Record, Account, and Safety.

- **System**: Includes program start, abnormal close, close, program reboot, device closedown, device reboot, system reboot, and system upgrade.
- **Setting**: Includes saving configuration and deleting configuration file.
- **Data**: Includes configuring disk type, clearing data, hot swap, FTP state, and record mode.
- Event (records events such as video detection, smart plan, alarm and abnormality): includes event start and event end.
- **Record**: Includes file access, file access error, and file search.
- Account: Includes login, logout, adding user, deleting user, modifying user, adding group, deleting group, and modifying group.
- Safety: Includes password resetting and IP filter.

Step 3 Click Search.

- Click a certain log, and then you can view the detailed information in **Detailed Information** area.
- Click **Backup**, and then you can back up all found logs to local PC.

Log	Remote Log						
Start Time	2019-07-17	19 : 25 : 40	End Time	2019-07-18	19 : 25 :	40	
Туре	All	 Search 	Find 72 log Time 20	019-07-17 19:55:03	2019-07-18 19:01:11		
No.	Log Time		Use	ername		Log Type	
1	2019-07-18 19:	01:11	a	dmin		Set Time	×
2	2019-07-18 19:	01:11	a	dmin		Set Time	E
3	2019-07-18 18:	58:51	a	dmin		Set Time	
4	2019-07-18 18:	56:30	a	dmin		Login	
5	2019-07-18 18:	17:41	a	dmin		Logout	
6	2019-07-18 18:	01:11	a	dmin		Set Time	
7	2019-07-18 18:	01:11	a	dmin		Set Time	
8	2019-07-18 17:	58:51	a	dmin		Set Time	
9	2019-07-18 17:	31:36	a	dmin		Set Time	
10	2019-07-18 17:	31:36	a	dmin		Set Time	-
Detailed Inform	ation						
Time:							
Username:							
Type:							
Content:							
						≤ ≤ 1/1	1 🕨 🖹 🔳
Backup	7						
Duckup							

Figure 6-10 Log (details)

6.6.3 Remote Log

Configure remote log, and you can get the related log by accessing the set address. <u>Step 1</u> Select **Setting > Information > Remote Log**.

	Figure 6-11 Remote Lo	g	
Log Rer	mote Log		
Enable			
IP Address	180. 489. 4 . 409		
Port	514 (1	~65534)	
Device Number	22 (0	I~23)	
	Default Refres	sh Save	

- <u>Step 2</u> Select the **Enable** check box to enable remote log function.
- <u>Step 3</u> Set address, port and device number.
- Step 4 Click Save.

6.6.4 Online User

View all the current users logging in to web. Select Setting > Information > Online User.

Figure 6-12 Online user

Online User				
No.	Username	User Local Group	IP Address	User Login Time
1	admin	admin	10.000	2020-01-14 15:02:04
Refresh				

Appendix 1 Cybersecurity Recommendations

Cybersecurity is more than just a buzzword: it's something that pertains to every device that is connected to the internet. IP video surveillance is not immune to cyber risks, but taking basic steps toward protecting and strengthening networks and networked appliances will make them less susceptible to attacks. Below are some tips and recommendations on how to create a more secured security system.

Mandatory actions to be taken for basic equipment network security:

1. Use Strong Passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters;
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols;
- Do not contain the account name or the account name in reverse order;
- Do not use continuous characters, such as 123, abc, etc.;
- Do not use overlapped characters, such as 111, aaa, etc.;

2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your equipment (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the equipment is connected to the public network, it is recommended to enable the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

"Nice to have" recommendations to improve your equipment network security:

1. Physical Protection

We suggest that you perform physical protection to equipment, especially storage devices. For example, place the equipment in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable equipment (such as USB flash disk, serial port), etc.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Set and Update Passwords Reset Information Timely

The equipment supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

4. Enable Account Lock

The account lock feature is enabled by default, and we recommend you to keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.

5. Change Default HTTP and Other Service Ports

We suggest you to change default HTTP and other service ports into any set of numbers

between 1024~65535, reducing the risk of outsiders being able to guess which ports you are using.

6. Enable HTTPS

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

7. Enable Whitelist

We suggest you to enable whitelist function to prevent everyone, except those with specified IP addresses, from accessing the system. Therefore, please be sure to add your computer's IP address and the accompanying equipment's IP address to the whitelist.

8. MAC Address Binding

We recommend you to bind the IP and MAC address of the gateway to the equipment, thus reducing the risk of ARP spoofing.

9. Assign Accounts and Privileges Reasonably

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

10. Disable Unnecessary Services and Choose Secure Modes

If not needed, it is recommended to turn off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

11. Audio and Video Encrypted Transmission

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

12. Secure Auditing

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check equipment log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

13. Network Log

Due to the limited storage capacity of the equipment, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

14. Construct a Safe Network Environment

In order to better ensure the safety of equipment and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to

achieve the network isolation effect.

- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.
- It is recommended that you enable your device's firewall or blacklist and whitelist feature to reduce the risk that your device might be attacked.